

2/10/18 W 6/10/18

TELEGRAMS "HORN. WOLVERHAMPTON."  
TELEPHONE 1731 (FIVE LINES).

Height 6' 6"

# A.J.S.

## Motor Cycles



7.9 h.p. 3-SPEED A.J.S. PASSENGER COMBINATION.

1926 Models G1 and G2.

## HOW TO MANAGE THEM

APPLICABLE ALSO TO 1921-1925  
MODELS, AND ALSO IN ESSENTIAL  
DETAILS TO 6 H.P. 1920 MODEL

A. J. STEVENS & CO. (1914) Ltd.,  
GRAISELEY HOUSE, WOLVERHAMPTON

PRINTED BY THE WOLVERHAMPTON PRESS LTD.

# A.J.S. MOTOR CYCLES.

It is highly important that the side car be in perfect alignment with the cycle or all round satisfaction cannot be obtained.

The side car wheel should be fixed parallel with the wheel of cycle and also perfectly vertical. The cycle also should be quite upright, and not leaning either forward or backward. Two straight pieces of wood, about 7 or 8 feet long should be used to test the alignment. One piece should be placed alongside both wheels of cycle and the other against the side car wheel, and when measured across each end the distance should be equal.

If, although the alignment is correct, the machine has a tendency to steer to the left, the cycle should be adjusted to lean a little to the right. If the steering tends to the right, slightly lean the machine to the left towards the side car.

Always drive the machine sitting in an upright position, and do not fall into the unwholesome habit of leaning the body permanently towards the side car. It is not only unnecessary but it puts a great strain on the side car attachments.

After the machine has been in use a little time it sometimes happens that the side car fittings will take a permanent "set," causing the cycle to lean slightly towards the side car. This is easily remedied by means of the telescopic torque rod, between the mud pillar and the side car axle.

When turning a corner sharply to the left, lean the body to the left, when turning to the right lean the body to the right. It is not sufficient, however, to simply lean the body, the rider should throw the weight of his body in the direction he leans.

Always, unless you, however, to turn a corner at a reasonable speed especially when turning to the left, a centrifugal force puts a great lateral strain on the machine and tends to lift the side car wheel from the ground. When turning to the right the lateral strain is thrown in the opposite direction and has a counterbalancing effect on the side car axle in the torque rod. When taking a corner to the right at high speed this strain is terrific and is a fruitful cause of side car axle breaking.

The A.J.S. side car axle is made specially strong for this reason, but the rider will be well advised if he takes no more than a reasonable and safe speed.

When turning to the left while climbing a very steep hill at a moderate speed it is not so necessary to lean in that direction, as the natural side-drag of the side car tends to lean the machine to the left. When turning to the right under the same conditions the driver and passenger should lean well to the right.

When climbing a very steep hill the passenger should get in a position that will put as much weight as possible on the back wheel of cycle. It will prevent the wheel slipping, and will counteract the tendency of the side car to drag. When descending very steep hills it will help the steering, and if the passenger will put as much weight on the driving wheel as possible. This paragraph only refers to "steep" hills.

With the exception of the instances mentioned above, there is no necessity for the passenger to be continually leaning to the left or to the right, especially if ordinary corners are taken at a reasonable and safe speed. It is not an uncommon sight to see a passenger continually leaning in one direction or the other, even when taking a very slight curve in the road, with the mistaken idea that it helps the steering. It is not only unnecessary but it makes a lot of what might be a pleasant ride.

The old saying "the race is not always to the swift" is very true, when applied to motoring. The careful driver who keeps on a consistent reasonable speed is usually much more certain of reaching his destination, not only in good time, but in comfort and safety.

As a last word on this matter, we would extremely advise our friends to order the complete combination of this has not already been done and not fit out of the ultra cheap side cars with which the market is flooded because of the expensive ones are very badly designed. They not only give constant trouble but in some cases are positively dangerous. However reliable the motor cycle may be, a side car which is always giving trouble spoils the whole combination.

## FOREWORD.

WE have pleasure in providing the riders of A.J.S. Machines with a comprehensive Instruction Book, dealing with our 799 h.p. Motor Cycle and Sidecar.

The Booklet has been very carefully compiled, and we trust that the information contained in the following pages will be of assistance to the rider in tackling little adjustments, or elucidating any troubles which may from time to time take place.

Many adjustments and little troubles can, however, be avoided if the new rider will carefully read—and remember what he has read—that portion of this Booklet devoted to Driving Instructions, and general care of the machine, and particularly take note of those instructions which are emphasised by being printed in italics.

## RE SUPPLY OF THIS PUBLICATION.

A copy of this Booklet is supplied free with every new A.J.S. Motor Cycle. Applications for extra copies must in every case be accompanied by a remittance of 6d. to cover cost and postage.

A. J. STEVENS & CO. (1914) Ltd.

## Contents

	PAGE
Driving Instructions ..	1
Engine Lubrication ..	2
Engine Adjustments and Cleaning ..	3
Magneto ..	10
Magneto-Mechanism Point Adjustment ..	11
Timing ..	11
Ignition Trouble ..	11
Engine Timing ..	12
Gear Box ..	13
Gear Box Disassembling ..	13
Clutch Adjustment ..	14
Transmission ..	15
Adjustment of Chain ..	16
Frame of Chassis ..	17
Chain Repairs ..	17
Chain Case ..	17
Carburettor ..	
Side Running ..	
Setting and Driving ..	
Easy Starting ..	
Adjustment of Sides ..	
Fluidding ..	
Fuel Consumption ..	18
Detachable Wheels ..	19
Removal of Back Wheel ..	19
Tyre Repair ..	20
Rear Wheel Adjustment Gauge ..	21
Removal of Front Wheel ..	22
Adjustment of Hub Bearings ..	23
Heske Adjustment ..	24
Rear Sides ..	25
Replacing Front Starting Spring ..	26
Adjusting Steering Head ..	27
Adjusting Spring Fork ..	28
General Instructions ..	29
Sideline Hints ..	30



## Index to Illustrations

	PAGE
Plan View ..	2
Change Speed Gear Lever ..	3
A.J.S. T.M. Box Engine ..	4
Magneto in Position ..	5
Magneto ..	10
Magneto Timing ..	11
Arrangement of Timing Gear ..	12
Gear Box in Position ..	13
Gear Box in Position ..	14
Clutch Parts ..	15
Chain Case with Front Cover removed ..	16
Clutch Chain Adjustment ..	17
Transmission ..	18
Chain Drive Extractor ..	19
Chain Repair Parts ..	20
Back Detachable Wheel removed ..	21
Front Detachable Wheel removed ..	22

## General

Remember you have a **flywheel** as well as a power plant. Frequently oil the links of spring fork. Periodically put oil in the hubs or fill with vasoline. Oil occasionally any little running parts about the machine, such as brake shackles. However in the joints of control rods change speed lever, gear box clutch lever etc. An oil gun is a most useful accessory. A charge of oil can be drawn out of the oil tank and used for lubricating every part of the machine. If a side car is fitted, don't forget to lubricate the spring shackles, etc., if springs are to be avoided. If the leaves of the springs crack or squeak, separate them by inserting thin end of a screwdriver, and force oil between with the oil gun.

Keep the machine clean. If mud, etc., is allowed to accumulate, it will work into bearings, especially the hubs, and cause undue wear. Do not wash the machine down with a hose pipe. If so doing it is **easy** to get water in the petrol tank or carburettor, and cause trouble. Remove mud by means of a sponge and a bucket of water.

Push into tightly in the tool case with cleaning cloth, and so prevent them rattling about. Test spare parts the same, or better still, carry tools and spare parts in the locker of side car where they will not be subjected to such punishment as when packed in the passenger bags or basket. The passenger bags can be used for carrying spare tubes if they are carefully and tightly packed, but it would mean destruction if they are not.

Keep the back tyre fully inflated, but not hard, and see that security bolts are tight. It is not necessary to have the front tyre inflated as hard as the back.

When the machine is used as a solo mount do not fit all-steel spoked tyres. They are positively dangerous on granite sets or tarmac, especially if wet.

It is not necessary to carry a load of spare parts with the machine. The only parts that may be required under ordinary conditions are:-

One spare valve complete with spring, washer and cotter, a good substantial tyre repair outfit, one each spring link and half link for chains, ten good sparking plugs, an inside plaster for tyre in case of a nail cut or burst, and a good supply of petroleum cushion-rose.

For very long journeys or an extended tour it is wise to carry in addition to the above a spare front chain complete with spring link, and a spare cover and tube in case of serious tyre trouble, if a spare detachable wheel is not carried.

The T.M. box, A.J.S., is designed to carry two persons, and luggage anywhere, and do it easily, but if you have a front bag in your district, do not try to climb it with all your friends helped up in the side car and on the carrier. It is not fair to the machine, your pocket, or the riders.


Any further information required we shall only be too happy to give if communicated with direct, but it will save unnecessary correspondence if our patrons will ascertain first, that the information is not already given in this booklet.

## "Safety First" Hints.

1. **Never** drive faster than you can pull up in the distance you can see.
2. **Never** attempt to overtake another vehicle on a blind corner.
3. Always keep closely to your right side of the road when taking a blind corner.



## Steering Head.



1. Turn the Bellows four times and give it a sharp tap with hammer.
2. Slacken Nut B.
3. Adjust steering lever by Nut C.
4. Lock up Nut B and Nut A.

## Spring Fork Adjustment.

To take up any play which may have developed in the side links, unscrew the spindle lock nuts on the right-hand side of the forks looking at the machine from the front, and turn the spindles by hand or the handle on the left-hand side until all slackness is taken up. Afterwards tighten up lock nuts.

- 21 -

## Driving Instructions, &c.

For 5 & 750 c.c. Three-Speed A.J.S. Motor Cycle.

**A**FTER receiving the machine, thoroughly examine it and get conversant with its details. Fill up with petrol and oil.

Only oil suitable for air-cooled engines must be used. The oil is not supplied as standard in "Matchless" "Control C."

Turn on the petrol by passing the knob of the petrol tap which is marked "ON" and flood the carburettor by pressing the "flood" on top of float chamber. The oil tap will be found below the elbow outside the tank, and is similar in operation to the petrol tap. This tap can be left in the "ON" position while riding, and need only be closed off when the machine is left standing for a long period. For further instructions regarding lubrication see "Klubber Lubrication" on Page 8.

Inject a small quantity of petrol into the cylinder through the emergency top by means of priming pipes under the tank. It will prevent the failure of the petrol into the cylinders if the exhaust valve is closed. After the petrol has been injected see that the compression tappet is closed again.

Unless the engine is cold and difficult to turn, it is seldom necessary to inject petrol into cylinders.

To start the machine carry out the following operations.

1. See that the gear lever is in the "Neutral" position and that the clutch change quadrant is in position (Illustration 1).
2. See that the air filter (the shorter one) of each cylinder is closed and open the throttle lever (the longer one) about one-third. The levers open to the left, move to the right to close. The right is a warning. The characteristic is the A.J.S. The full details and instructions, etc., see separate instructions.
3. Lift the exhaust valve by means of the lever on the right handle bar grip.
4. Engage the foot starter with the right foot using the lower of the foot and press smartly back, forward and down, and at almost the same time release the valve lift and the engine should then start. Take the foot off the foot starter pedal immediately the engine fires, but do not allow the foot to strike the engine block or "bang" after starting the engine. Bring the foot back with the pedal, and as you start a heavy blow bring it to the stop.

Presuming these instructions have been carried out take off the clutch by means of the clutch lever on the left bar, side of handle bars place the gear lever in the low position, speed up the machine by opening the throttle a little, and really engage the clutch lever. The machine will then move forward on the low gear. When the machine has attained a fair speed on this gear, disengage the clutch and move the gear lever into second gear position, which is by moving the clutch.

Repeat this operation to engage high gear. When changing to high gear the machine must be controlled by means of the throttle lever and brakes. To stop, close the throttle, and when the machine is almost at a standstill, take off the clutch and apply the brakes.

- 22 -

Driving Instructions, etc. continued

The change speed lever is operated as follows:—  
To engage the low gear from neutral, press the lever lightly to the right and pull backwards (see important warning below). To move to second gear, again press lightly to the right and push the lever forward into second position. To engage high gear from second, press the lever to the left and move it forward into the high position. How to operate the gear lever will be explained in careful examination of the construction. The gear lever has a positive stop for each gear, which changes up or down, and is automatically locked in each position when released by the hand.


**Important Warning**  
If the change speed lever does not move quite easily into position, do not attempt to force it. Move the machine slightly backwards or forwards, or turn the handle wheel, while keeping a little pressure on the lever. This will bring the "dog clutches" in the gear box into proper position for engagement, and the gears will engage without using unnecessary force. Under no circumstances must this lever be forced into position, or the coupling joints will be strained and damage done.

This warning only applies when the machine is stationary, not when flying.

Always start with the idle lever of carburettor open as far as possible consistent with the engine firing properly. It is not always necessary to stop the engine when the machine is brought to a standstill, but it can be left quietly running until ready to start away again. This can be done by taking out the clutch immediately, and slipping the gear lever into the neutral position, afterwards releasing the clutch again. The engine will now be running free. Do not "lurch" the engine while standing; throttle it down just sufficient to keep it lit, and ready to start away again. In the case of a short stop, as when obstructed by traffic, the clutch only need be taken out, but always remember to engage new gear when starting again.

Although it is not absolutely necessary to do so, it will be found a much safer method of changing gear if the following instructions are carried out. When changing from a low to a higher gear, slightly slow the engine down by closing the throttle a little immediately before changing. When changing down let the engine accelerate slightly with the clutch out before engaging the lower gear. A little practice will soon make this quite proficient.

The most common cause of damage to gears is changing to a low gear whilst the machine is travelling fast. Many riders make a practice of approaching a corner at a high speed, and to bring the machine to a safe pace to negotiate it, they forcibly engage lower gear. If it is desired to turn a corner on a lower gear, the machine should be brought down to a safe pace by means of the throttle and brakes before changing to the lower gear. Changing from a high gear to a low one when travelling fast, for the purpose of braking the machine, is abuse which no orthodox gearbox will put up with for long.





The A.J.S. Patent Change Speed Lever

ILLUSTRATION II

## Method of Replacing Footstarter Spring

1. Hook free end of Spring over Top Spoke of Frontstarer Quadrant.



2. Turn Quadrant a complete Revolution in Direction of Arrow.

3. Push Quadrant into position, at the same time pressing with both thumbs the outer coils of the Spring down and over Footstarter



## Rear Stand.

The operation of the rear stand requires very little explanation.




ILLUSTRATION 1.




ILLUSTRATION 2.

of the machine. When the operation is completed release the lever down again and clip it to stand. To lower the machine simply reverse these operations.

Illustration 1 shows the stand in the normal position. Illustration 2 depicts the stand let down and the rider about to pull the lever over back towards, which instantly even, raises the machine on to the stand. Illustration 3 shows the final stage of the movement, the levering action being fully completed and the wheel raised clear of the ground. To bring the lever down release the clip which holds it to the stand tube, and swing it over towards the engine. Now push down the stand in the ordinary way on to the ground and pull lever upwards towards




ILLUSTRATION 3.

## Driving Instructions, etc., continued.

When climbing a steep hill, which necessitates changing down to a lower gear, always change while the machine has reasonable "way" on it. The object of the machine being allowed to stand still before changing.

If the machine will not climb a hill on top gear, do not force it to do so by slipping the clutch but change to a lower gear. If the clutch is allowed to slip for a lengthy period under such a heavy driving load it will—owing to the intense heat generated by friction—burn out the cork inside, in fact, possibly destroy, by heat, any material of which a clutch may be composed. There is really no excuse for the rider who destroys his clutch by this practice. It is not only bad driving, but it is trying to make the clutch do the work of the rear hub which is utterly impossible.

Do not run the machine unnecessarily on low gear. This gear is only provided for ease of starting, and climbing exceptionally steep hills, or when negotiating quick traffic demanding a very slow rate of progress. Using the low gear unnecessarily simply means extra wear and tear, high petrol consumption, and shortens the life of the engine, and transmission.

Never race the engine with the machine stationary. Racing the engine will reach very high speeds, and may cause serious damage to the valves, big end, and high speeds with a small throttle opening than at the same speed at full throttle with the engine under load.

When climbing an exceptionally steep hill it is sometimes an advantage to slightly retard the spark, but under normal conditions the spark lever should be kept in the "mid-speed" position. If the engine has any tendency to "kick back" when starting it with the foot starter, slightly retard the spark. The lever on the left handle bar is moved forward to advance and backward to retard.

When running at very low speeds on top gear a slight heaviness in the drive may be felt, common with all petrol driven vehicles, however well designed the engine may be. But the drive can be made just as sweet and as comfortable as ever may wish, by easing the clutch a little, by means of the clutch lever on the handle bar. A light pressure of the hand on this lever allows the clutch to slip slightly under the impulsion of the engine, and so the clutch is instantly converted into a perfect shock absorber at the will of the rider. The foregoing hints also refer to "picking up" again after slowing down for a corner, or any other occasion when the machine is to be accelerated suddenly from a slow to a higher speed. It must be quite understood, however, that the clutch is not designed so much that it slips to the extent that the engine can "race." Only just so much pressure should be exerted on the lever to allow the clutch to absorb the impulses of the engine. We earnestly commend this paragraph to those riders who are anxious to get the best results and long life from the engine, gears, and chains, to say nothing of the added comfort and satisfaction.


Do not control the speed of the machine with the free engine clutch, excepting in very congested traffic as previously mentioned. Always give "on the throttle." The object of the clutch is ~~not~~ to control the speed, the throttle or conjunction with the gear box and brakes should be used for this purpose.

After a short run it will be found that the control of the machine is quite simple, and the disposition of the levers, operating the footbrake and the clutch, give the rider absolute mastery over his mount. In low gear the machine can be driven at a perfect crawl and on high gear it is capable of maintaining a speed to satisfy even the boldest of riders.



## Care of the Machine.

## Engine.



A.J.S. 749 b.p. Engine

ILLUSTRATION C.

**Lubrication.**—The most important point in connection with the engine is lubrication. Give about one dropful every 2 miles, and rather more if fuel riding is indulged in.

The type we employ gives a direct feed to the engine, oil being delivered on the plunger rod as it ascends on the up stroke. To give a charge of oil in the engine, depress the plunger to its full extent. This will fill the barrel with oil, and the plunger being spring loaded it will automatically ascend and in so doing force the oil into the engine, the plunger rising during the process until it is in position for the next charge to be delivered.

To cut off the oil supply at any moment, such as when the machine is left standing, the tap should be turned off. As a further precautionary measure the lubricator can be put out of action by pressing down the plunger to its full extent, and fixing it in this position by means of the small latch provided.

Climate and riding conditions vary, so it is absolutely necessary to leave the question of lubrication to each individual's judgment to a certain extent.

The engine working heavily, and a falling off of power, are the usual symptoms of under lubrication. Over lubrication is shown by oil quickly working out of the valve tappets, and smoke issuing from the cylinder. Over oiling will sometimes cause the exhaust valves to stick or move sluggishly in their guides. The symptoms are mostly apparent when the engine is cold. Mistaking over-oiling for a lack of oil is a common mistake, and difficulty of starting. The remedy is to take out the valves and clean the stems and guides with petrol.

**Adjustments and Cleaning.**—See that the valve tappets are always properly adjusted. Refer to the inlet and outlet exhaust, or about the thickness of a visiting card is the correct clearance between the tappet tip and valve stem when the valve is on its seat. Check the clearance when the engine is hot, and when cold. Use two spanners to check the adjustment. The inlet valve tappet of front cylinder is free to revolve. This can be held stationary by two thin parallel iron bars in the hole drilled in the tappet stem, after the lock nut has been checked off.

## Matchless Wheels—continued.




ILLUSTRATION R.


**Front Wheel.** The front wheel is interchangeable with the back, and to ensure this, first lock up the wheel on the front stand. Unscrew the three drive bolts and take out the centre pin, which will allow wheel to be drawn off the driving stand on the hub drum exactly as in the case of the rear wheel.

The adjustment of the hub bearings is perfectly obvious. Both are self-adjusting. Don't let the hub run loosely, but take care that they are not adjusted too tightly.

This is a common cause of broken hubs and cracked ball races. When properly adjusted, the weight of tyre valve should revolve the wheel, if placed above the centre of wheel. At the same time the wheel should have no shake.

Before attempting to bring the front stand into position, always place the machine on the Rear Stand First, otherwise the machine will run backwards, throwing strain on the legs of the front stand, and with the possibility of damage to the front brake operating mechanism.

The accompanying illustration shows the Rear Brake Drum with the Expanding Shoes. Operation of the Rear Brake is by Pedal and Rod on the left-hand side of the machine, while the front, which is of identical construction, is by a Pedal and Handle Chain on the right-hand side. Both brakes follow the best and engineering practice, and their sturdy-constructed mechanism afford almost everlasting wear.



The A.J.S. Internal Expanding Rear Brake.

The Expanding Shoes are shown detached from the Drum.

ILLUSTRATION S.


The brakes require no adjustment, with the exception of occasional adjustment of the internal mechanism. In the case of the Rear Brake this is effected by turning the adjusting screw on the handle chain, and after that it remains from the operating lever.

Periodically test the centre pin and chain nuts with the spanner, and keep them tight. If the sleeve nuts are loose a dull hammering will be felt when driving at slow speeds. If this is noticed, tighten the sleeve nuts at once. When the back wheel is returned, the wheel nut is taken out, leaving the chain sprocket, back chain case, etc., remaining in their original position. If desired the wheel completely with sprocket, brake, etc., can be taken out, which is quite a simple operation. Remove the back portion of chain case and chain case's back off sprocket nuts and remove brake cable by unscrewing the pin in the cable. Take the chain off the sprocket by means of the spring link, and unscrew the anchor pin which projects into slot of brake anchor plate, sufficient to clear. The wheel will then fall out of slots in fork ends.

There should be taken to prevent the ends of chain falling back into chain case while removing the wheel. The upper portion of chain should be folded back over the top of chain case and hooked up to the pin provided. The lower portion of chain will hang down below the bottom half of case.

When replacing the chain it will facilitate the fitting of spring link if the ends of the chain are connected in central portion of the sprocket. This also applies to removing the spring link.

When the wheel is replaced, see that the brake anchor pin is screwed into the slot in anchor plate and the spindle nuts are tight.



**Rear Wheel Adjustment Gauge.** - On the right-hand side of the bottom chain stay will be found a piece of sheet metal, held in position by a clip which supports the tube.

In the tool kit will be found a flat gauge that can be fitted round the rim and illustration. When replacing the rear wheel after removal or after knocking out of the wheel to find the edge of the gauge just touches the plate that is held by the clip on the chain stay. This ensures the wheel being correctly aligned and must be done before finally tightening up the spindle nuts. Do not attempt to measure the clip from the chain stay as the position of the plate is not correctly before the mud and dirt in the fork.

When replacing the chain it will facilitate the fitting of spring link if the ends of the chain are connected in central portion of the sprocket. This also applies to removing the spring link.

When the wheel is replaced, see that the brake anchor pin is screwed into the slot in anchor plate and the spindle nuts are tight.

#### Working the cylinders.

carefully off the cylinder on both sides, taking care not to break the radiating fins. Prise upwards and downwards. When the heads are removed it is no easy matter to draw the cylinders off the pistons. In doing this the engine should be turned over until the pistons are at their lowest position, and draw off the cylinders as fully, taking care that when the pistons are free not to let them fall sharply against the connecting rod, as this may crack or break the skirt of the piston which is underneath the pistons to prevent any foreign matter or dirt getting into the crank case. If the combustion head is badly carbonised this must be cleaned. The generally accepted method being to scrape the chamber free of the burnt mixture, which can be done with an old screwdriver or similar tool. The top of the pistons should also be scraped free of all deposit, using an old blunt knife or chisel, and while carrying out this operation see that no side seals are thrown on the piston. If the rings are quite free in their grooves they need not be removed, but if they are obviously choked up with burnt oil loosen them very carefully, take them off the piston and clean the grooves thoroughly. Take the piston off the connecting rod to do this. First remove the gudgeon pin from the piston, take out the retaining washers, one of which will be found on either side of the gudgeon pin. These fit into recessed slots in the piston bosses and to withdraw must be squeezed together with the special small pliers provided. Afterwards the gudgeon pin can be pushed out from the driving side. Having got rid of all deposit from both cylinders after cleaning, carefully oil the pistons. Before replacing the pistons rings are on opposite sides of the piston. Take care when replacing the cylinders on to the crankcase to see that the packing washer is inserted between the top of crankcase and the base of cylinder. When everything is in position, fit up the inlet pipe and connections before bolting the cylinders down, as this will enable the cylinders to swing into proper position to make perfect joints at each end of the inlet pipe. This is a very important matter. The exhaust pipes can be partly screwed after the cylinders are bolted down permanently. If one cylinder only is to be taken off it is only necessary to disconnect the exhaust pipe and one side of the inlet pipe.

If it is required to remove the valves at any time for inspection, grinding in, etc., there is no need to touch the cylinders. All that has to be done is to unscrew and take out the valve cap, then place the hooked end of the special valve

extractor, which is provided in every tool kit, on the top of the valve, using the valve cap stander, which fits at the bottom of the hook, for the temporary leverings to lift the valve spring to allow the cover to be withdrawn.

The valve can then be pushed up and drawn out of the head, via the valve cap aperture. If the valve seal rings are at all pitted grind in the valves with fine emery flour, taking care that all corners are cleared out of the valve chamber after the operation. The valves should, generally speaking, be ground in about every 2,000 miles.


Drain old waste oil out of the crankcase of engine about every 1,000 miles. For this purpose a drain plug is fitted on chain case side of crankcase. See that four to five pints of Lucas oil are pumped into the engine after draining out the old oil.

Examine periodically the bolts which hold the engine in frame, and tighten at 7 nuts that may have worked loose. Keep the engine clean externally, which can be done quickly and easily with a paintbrush and a can of paraffin.

Lucas "Magdyno" in position, showing adjustment.  
Illustration D.



'Magdyno.'



Lucas "Mardvoo."

11024944 41 0000 31

age and scoring full over and placing a small quantity of grease or a few drops of oil in the bearing housing. The Magneto bearing at the contact breaker end should run perfectly without any attention owing to the magnet in which it is mounted. Should the gears run completely dry they can be packed with a high melting point grease such as Price's H.M.P. grease.

**Adjustment** The platinum contacts should be examined after every overhaul and if the break span is more than the thickness of a nickel wire they should be adjusted. The proper distance of the gap is .015 in. or roughly 1/16 in. full. To great a gap will advance the timing. A special adjustment of is needed with each machine and the range of this is the only adjustment for the make of the valve. This adjustment, which is the area of most of the contact breaker, can be carried out without, in most of the contact breaker from the timing. If it is necessary to make the contact breaker out, as is the long type, by using a new, and pull the contact breaker off. The points only need attention if very long intervals, and we warn users against unnecessarily adjusting them. The setting of the advance mechanism must only be checked with a dial indicator if it is inoperative and cannot be adjusted, and then the best possible attempt taken off. The gears must be checked, as platinum is a very expensive to find.

**Tipology.** If the "Megalodon" has been taken in, traps are made for it and he is necessary to see that the megasaur himself directly after it is killed. The engine plant the driving sprocket is connected to the shaft by means of a combination, which further stops the drum if impossible. The sprocket on the miniature shaft of the megasaur is supplied with a smaller driving pulley, which also has a very accurate and exact method of fixing the drum after the correct setting has been arrived at. The strength of this recent instrument may at first sound a little complicated, but in reality it is perfectly simple. Kept to the accuracy about of the main drive shafts, which has thirteen holes arranged in a circle. Fixing over a collar on the shaft in the chain-gearing 25, which has twelve holes similarly arranged. Now on the pulley of the driving drum 3000

The instrument, which was known as the "Luzon" "Magineto," provides lightness for the piano, and generates current for the electric lamp. It consists of a Lucas Dynamo No. 1, and a Lucas Magineto, and although the two are retained as separate units they are housed so as to form one instrument. A full treatment of the working principle and intricacy of the "Magineto" is contained in the Lucas book of同名 instrument. It is a copy of which is sent out with each new "Luzon" instrument.

**Lubrication.** The instrument is provided with ball bearings throughout, which are packed with grease before leaving the manufacturers. Fresh lubricant should not be required under normal circumstances until the machine has run from 10 to 12 thousand miles. Usually sufficient grease will work through from the gear wheel raising to lubricate all bearings on the driving end. The dynamic roller-bearing can easily be lubricated by removing the hex-

Children receive constant

The above description contains all the facts necessary to effect repairs to a pump:

To shorten a chain containing as many as 100 or more cells, replace by parts No. 30 and 29.


So, III. To shorten a clause containing an odd number of pitches replace by parts

To repair a chain with a broken roller or freddy inside link, replace by part No. 14.

For joining up any length of chain where: columns are inside 114s,  
use tool No. 34.

When it plate is joined up with a spring clip it is just impossible to plug it correctly fitted over the cover plate. The open end should always face in the opposite direction to which the chain travels.

### Detachable Wheels:



Back Detachable Wheel Removed.

10.16784-1108 P.

center. If it is secured, the wheel is hanging on one fork only. As this rough treatment must be carefully avoided, there is great danger of straining or breaking the fork end. Under no circumstances must the repair pin be removed until the machine is jacked up on the stand and the center pin fixed so that it is in position before the machine is taken off the stand again. If for any reason the wheel should be difficult to pull off the driving axle, screw in the center pin a few turns without the distance piece, this will steady the wheel while drawing it off the driving axle.

**Tyre Repair** If the rider wishes to fit a new tube without removing the wheel entire, he must first take off the top side of the tyre and remove the tube in the ordinary way. Next, take out the centre pin and dislodge piece only, leaving the flange ends intact. This will be found to give sufficient space between the hub and the fork end to allow the tube to be passed through and drawn completely out. Now insert the dislodge piece and the centre pin and proceed to fill.

**Back Wheel**—To remove the back wheel proceed as follows—First the machine on the stand and with the foot spanner provided, first unscrew the three clout nuts which pass through the hub flange. To prevent the wheel revolving while unscrewing it is necessary to place the foot against the tyre at bottom of wheel. The three clout nuts extend right through the wheel and over hub flange, and screw on to the three threaded studs in the driving sprocket. There are also three pinch studs on the sprocket which act as dummy drivers. These fit into the three remaining holes in the hub flange. After the clout nuts have been unscrewed then unscrew the centre pin and draw it completely out, together with distance piece. The space now left by the distance piece will allow the wheel to be drawn off the driving studs in sprocket. The whole operation should not take more than 10 to 15 seconds.

To replace the wheel, push it squarely on to the driving shaft and screw up the distance piece in position. Tighten the center pin moderately tight. The three sleeve nuts can now be screwed up tightly, after winding a final turn to the center pin. It is very important to palm out that when the center pin is removed, the wheel is released must be carefully avoided in taking the fork end. *Under no circumstances* will the machine be jerked up on the stand position before the machine is taken up. The wheel should be difficult to pull off the fork turns without the distance piece, thus the driving shaft.




ILLUSTRATION K.

If adjustment by adjusting nut is neglected, broken rollers may occasionally be found. The chain can, however, be easily repaired with the Permanent Chain Repair Kit. See illustration R and a few basic facts. This tool provides a simple means of removing the links, which cannot be filed down, as they are case-hardened. It can also be used for putting in a new roller link.


This tool provides a simple means of turning roller links by pushing the long handle through the plate.

The illustration shows clearly the method used in the removal of the roller link by means of this tool.

**To Remove Complete Links.**—Screw down the punch on to the joint of each rivet in turn through the top plate. Each rivet should be pushed out from the same side of the chain.

**To Remove Broken Links.**—Insert chain roller between the jaws and screw down the punch in order to press the head of the rivet through the top plate. Remove chain from cylinder, and link will fall out.

**Note.** Before attempting to extract a rivet, compress the ends of the jaws to obtain a grip on the chain roller.



Chain Repair Parts

ILLUSTRATION L.


Illustration N

each other better. Another thing to do is drive the first thing down in turning up to get these two arrows so that they are very nearly towards each other. Take this turn engine over until the arrow on the driving shaft, is pointing directly towards the arrow on the flywheel sprocket. This latter should be held free in the fingers and moved a tooth inwards or forwards in the chain until the correct setting is arrived at. When this is done, place the sprocket on to the drive shaft and turn the camshaft until the magnet is in a position to mesh with one of the two teeth on the sprocket. The magnet must be exactly opposite the center of the teeth. It will now be found that the marked holes in sleeve and sprocket respectively exactly coincide. Put a dot on the sleeve in the hole. Then the pin will be in the hole, which is effectively preventing the sprocket from moving out of its correct setting and holding it in place. The sleeve lock nut is, which can be done without fear of the timing shifting in the process, as it affects the chain with other sprockets. The magnet must be turned so that it is in the hole that has been marked. This is the back cylinder of the two. The magnet terminals are connected on the body of the instrument, and care must be taken to see that the high tension wires are correctly connected to the cylinder covers, leading with these terminals, through one link, remove the engine until the piston of No. 1 cylinder is within 1/4 in. from top of compression stroke—make sure it is on the exhaust stroke. With the engine in this position, take off the sleeve lock nut on magnet sprocket and remove the pin washer. This will leave the magnet free from the engine drive, but still connected via the chain to the engine. See that the sprocket has a flat arrow facing up and away from the cover of contact breaker and slowly turn the armature till the flat top of the magnet and drive lever rises on the inclined plane of the steel segment marked No. 1 just sufficient to separate the platinum points. This is the timing point, and in this position the markings previously referred to on the sleeve and sprocket should register if correctly fitted up. If so, the drive should be fixed up as before detailed. It is, however, always advisable to check the timing after tightening up.

It will prevent knocking, and make starting easier. If the slip ring is changed occasionally. This is done by taking out a high tension terminal and while the magnet is being revolved by hand, turn the engine round, insert a lead around the end of which is connected with a clean rag moistened with petrol. The lead will be sucked on the revolving slip ring.

**When Ignition Trouble is Suspected.** Before interfering with the magnet verify that the sparking plug, the valve, and the chamber are all in order. If these are in order, turn the engine slowly by hand and watch if the lead is sucked, whether there is an occasional tapping of the terminal switching. If this happens, ease it out very slightly. This is a fine, constant leak with which increased and should be watered gradually by means of a stick in some way to take the magnet in place and adjust it. It is really possible to do this.

**Most Important.**—If it is necessary to take out the armature first, see that the contact rollers and spring are run over, or the contact roller will be broken or damaged. Keep all parts clean and free from oil, particularly the contact breaker, oil or dirt between the points will give constant trouble.



Magnet Timing—Vernier Adjustment.  
ILLUSTRATION N



Тружениклар-ҳомеинлар,

If the chain is too slack it is apt to "whip," which intensifies the wear and tends to break the rollers, especially in the case of the front chain. If on the other hand it is too tight, a crushing effect is produced on the rollers, and the whole chain is strained thereby.

The chains should be adjusted, and kept adjusted, so that they can be passed down in the groin with the finger from the front chain, and about 1 in. on the back chain. The chains can immediately be suspended and loaded by means of the respective hooks fitted to both back and front parts of the chain case. If desired the whole of the top portion of the case can be readily taken off, whilst the lower half is correspondingly easily removed.

Engine Timing—Excerpt

Arrangement of Timing Gear 7-95 h.p. A.J.S.

LITERATURE E

The spark is timed to take place 5.5 mm or 3 in. before the top of the compression stroke, with the magneto control arm in the fully advanced position. The segment of contact breaker marked No. 1 fixes the speed of further magneto advance on "Magneto Timing" page 101.

With the exception of carrying out the above instructions, do not fiddle with the engine, nor fancy you can do better than the makers by tampering with the valve timing gear.

*Chain Case.*

**Lubrication.**—An oil gun is the best means of oiling the chains. With this instrument draw a charge of oil from the oil compartment of tank, and insert spout of oil gun in the chain case of wing bolt, which will be found on top of front of chain case above the back chain. Lift the exhaust valves, and while pressing down plunger of oil gun, slowly turn the engine round with the foot screw. Taking care that the oil from the oil gun is falling on the studs. This ensures the whole chain being well lubricated. Treat the back chain in the same way by slowly revolving the back wheel.

Long life, less need of adjustment and complete satisfaction with the transmission is what the rider will make a point of getting from a regular supply of new oil. If the knowledge that they are having a supply of fresh clean oil

### Chain Repairs.

A chain usually does break if properly adjusted (we have never yet heard of one breaking if properly adjusted) and it is usually worn out.

It will be seen that the Adjusting Pins are secured by a locking device, consisting of two short lengths of spring wire, which fit into slots in the heads of the pins. The pins have two cross-slots at their ends in each wheel, and the locking device moves are correctly set when the



clutch plates are assembled by us.

When the adjusting pins are set in position, it is then to be done to raise the spring wires out of their slots and push on one end. Afterwards, see that the wires are set properly in each of the cross-slots.

In those orders we prefer a light adjustment of the clutch, the following hint will be useful. A clutch that is lightly adjusted will sometimes slip for a time after engaging gear, but this slip will cease if the throttle is momentarily closed when the slip takes place. This is explained by the fact that for the moment the drive is taken off the clutch and allows the plates to settle down to their work.

## Transmission.

**Adjustment of Chains.**—To adjust the chain from engine to gear box it is only necessary to slack off the two nuts on top of bracket and slide the bracket sideways by means of the adjusting bolt, situated at the rear of bottom bracket.

**It is important that the nuts are secured tightly again after adjustment.**

**Back Chain.** Slack off the nuts on each side of back hub spindle, and move the wheel back and forth by means of the adjusting screws in fork ends. Care must be taken to adjust each side equally or the wheel will be out of alignment. See How to Wheel Adjustment Gauge, page 211.





Illustration D.

—11—




A.J.S. Gear Box in position

Illustration F.

removed out of the slotted end. Next remove the key which runs round the cup which holds this in the gear box cover. The clutch operating mechanism can now be taken off entirely. Take care when doing this not to lose the spring push rod. It will be found that on the end of the main shaft a thrust lock nut is fitted. This has a left hand thread, and the clutch push rod fits into the lock nut. To remove the clutch push rod, an arrow will be found on this nut pointing towards the left. This is the direction in which the nut must be turned. Hold this nut to prevent the main shaft from turning, and the thrust washer. To free this nut, push the main shaft back a distance of about the length of the washer to be withdrawn. This washer fits on a dove-tail peg and can be taken out when replacing the cover of the box, this is extremely easy. Now take out all bolts round the cover of the box and pull the cover off. The low gear dog wheel and lay shaft can then be taken out. Also the sliding sleeve. The main shaft, complete with clutch, etc., can be drawn out from the opposite side of the box. To reassemble simply reverse these operations.

**N.B.—Be sure the Thrust Lock Nut is tight after replacing.**  
Do not forget to put Grease oil in the box after dismantling.

1. Sprocket for transmitting power to Road Wheel.
2. Sliding Plate.
3. Fixed Plate.
4. Spring Plate.
5. Fixed Plate.
6. Ball Bearing for Clutch Sprocket.
7. Clutch Spring Adjusting Nut.
8. Clutch Spring.
9. Sprocket for transmitting drive to Road Wheel.
10. High Gear Dog Wheel.
11. Sliding Sleeve.
12. Main, or Primary Shaft.
13. Low Gear Dog Wheel.
14. Clutch Operating Lever.
15. Push Rod Adjusting Screw.
16. Shell Push Rod.
17. Lay or Secondary Shaft.
18. Dowel Pin which holds in Clutch Lever.
19. Road Wheel Ratchet Wheel.




Sectional view of A.J.S. 3 Speed Gear Box.  
Illustration G.

—12—



## Clutch.



AJS. 7-99 h.p. Clutch Parts.

ILLUSTRATION H.

- |  |  |
|--|--|
| 1. Clutch Sprocket fitted with<br>Clutch Fingers.                                    | 5. Shaft of 2 <sup>nd</sup> gear driven by No. 1.                          |
| 2. Sliding Plate looks key to<br>center which passes through<br>main gear box shaft. | 6. Ball housing on which No. 1<br>revolves when clutch is dis-<br>engaged. |
| 3. Front Plate, with Adjusting<br>Nuts and Locking Device.                           | 7. Clutch Spring Adjusting Nut.  |
| 4. Plate fitted with clutch fingers<br>(driven by No. 1).                            | 8. Clutch Spring.  |

The Clutch parts are assembled in the following order - No. 3, 4, 5, 1, 2, 6 and 7.

### Adjustment—

If the clutch should slip when climbing steep hills, tighten up the clutch spring a little by means of the adjusting nut on end of the clutch shaft, and when the forward clutch until there is a little play in the lever. Do not tighten up the spring more than necessary to obtain a perfect grip, as unnecessary strain will be put upon the Bowden control. *Rec., when the clutch is disengaged.*

*Do not put Oil into the Clutch under any circumstances.*


To take up excessive backlash in Bowden lever or handle but adjust by means of the operating shaft adjusting screw No. 13 (Illustration L). A further adjustment is also provided at the point through which the Bowden cable passes. (See Illustration L, No. 18). However, always allow a little backlash in the lever, as the clutch spring cannot exert all its pressure on the plates. If the clutch slips without any external reason, take it apart and revitalize if any portion of its mechanism is fouling another, and so keep the plates square. If the key in boss of clutch plate No. 2 (Illustration H) should find the end of slot in shaft it would prevent the clutch engaging.

To disassemble the clutch, take off the front cover of chain case by unscrewing the two pins on the front and rear of same like cover can then be removed (see Illustration L).

Unscrew the clutch spring adjusting nut No. 7 (Illustration H) and remove the spring No. 8. Take out the roller pin of fuel slapper crank and remove same. This will allow the starting gearwheel with its spindle to be drawn out until it can pass the stop on chain case. The gearwheel can then be swung clear of the clutch and allow the plates to be drawn off the clutch shaft. Before replacing, wipe the clutch plates clean, and smear a thin film of oil on the portions of

### Clutch—continued.

If in case, necessary to take the chain off the clutch sprocket before this can be removed (see Illustration L for location of chain link). It will be found that a dog key passes through a slot in the end of the clutch shaft, and fits in the boss of front or sliding plate. Great care must be taken to see that this key is in its proper position as the clutch cannot be disengaged. This key is clearly shown in Fig. 2 (Illustration H) across the entire of the plate. To fit this key when re-assembling the clutch, turn the shaft till the slot is perfectly horizontal. Then put key in slot with each end projecting equally on each side of the shaft. The sliding plate should then be slipped on shaft with its keyway in a corresponding horizontal position.



AJS. Chain Case with Front Cover removed, exposing Clutch and Foot Starter. The hinged covers for Chain Inspection are also shown.

ILLUSTRATION I.

If in disengage the clutch becomes difficult smear a little oil on that portion of shaft on which the outer plate slides.

If the clutch should "drag" even when fully disengaged, it will make gear changing very difficult, especially when changing down, for the reason that the drive is never properly taken off the gears, thus making it difficult to move the gear lever. This difficulty can be temporarily overcome by suddenly closing the throttle before changing down, immediately opening the throttle again after the change is made. The closing of the throttle takes the drive off the gears, and so allows easy disengagement. The cause of "drag" is usually that plate No. 4 is not lubricated (see Illustration H) and has much lateral movement, and "lifter up" the plate in front of it, when the clutch is disengaged. If the outer clutches No. 1 and 2 are removed, it will be found that plate No. 3 is driven by four pins on the back plate No. 4. There will also be seen two adjusting pins.

On the outside of plate No. 4 will be seen two small rollers. Tighten one of these in the left hand, the other in the right hand, and set if this plate can be moved backward and forward between plates 3 and 4. If so, screw up the two adjusting pins until the plates just touch each side of plate No. 4. Do not screw the two adjusting pins up tightly. The plates may be set to touch plate No. 4, but have them sufficiently loose to allow No. 4 plate to be moved from left to right or up and down, without much force.

It is, however, a very rare thing for the plates to "drag" and pass only