

Model BX125 Motorcycle

Service Manual

ROHENTWURF/ DRAFT

8.2 Fault Diagnosis.	75
8.3 Headlamp bulb replacement.	76
8.4 Replacement of the front	76
turn signal light.	76
8.5 Replacement of taillight/license plate light/rear turn signal light.	76
8.6 Instrument.	77
8.7 Main Switch.	77
8.8 Electric Horn	78
8.9 Handle Switch	78
Inspection and Maintenance of Engine	79
IX Lubricating system	- 81 -
9.1 Service Data.	- 81 -
9.2 Fault Diagnosis.	- 82 -
9.3 Engine Oil Pump	- 83 -
Cylinder head	- 84 -
10.1 Service Data.	- 85 -
10.2 Fault Diagnosis.	- 86 -
10.3 Cylinder Head	- 86 -
XI Cylinder Block and Piston	- 95 -
11.1 Service Data	- 95 -
12.2 Fault Diagnosis.	- 96 -
12.3 Cylinder Block	- 96 -
XII Crankcase.	- 101 -
12.1 Service Data	- 101 -
12.2 Fault Diagnosis.	- 102 -
12.3 Crankcase	- 103 -
12.4 Clutch	- 104 -
12.5 Gearshift Mechanism	- 110 -
13.6 Crankshaft Connecting Rod Assembly.	- 111 -
13.7 Transmission chamber	- 114 -
Exhaust System Inspection and Maintenance	- 117 -
XIII Exhaust control system.	- 117 -
13.1 Exhaust control system Guarantee	- 117 -
13.2 Periodical Maintenance Instructions	- 118 -
13.3 Mechanical Functions of Exhaust Control System.	- 119 -
13.4 Catalytic Conversion System	- 120 -
Inspection and Maintenance of Electronic Fuel Injection System	- 123 -
XIV. Electronic Fuel Injection System.	- 125 -
14.1 Introduction to Electronic Fuel Injection System.	- 125 -
14.2 Parts of Electronic Fuel Injection System	- 125 -
14.3 Fault diagnosis method.	- 134 -
14.4 Common Trouble Shooting Methods	- 141 -
14.4.3 Simple troubleshooting methods.	- 142 -
BX125 Circuit Diagram	- 147 -



Preface

The service manual contains descriptions of maintenance essentials on BX125 motorcycle.

Service data include attentions that shall be paid on all the maintenance operations in the service manual. Please read the manual carefully before operation.

Check and adjustment contains statements on the main points of inspection and adjustment, safety of the vehicle, maintenance means of each component's performance. This shall be implemented from the time of periodical inspection.

The parts after Part 1 demonstrate disassembly, assembly and main points of inspection of engine, finished motorcycle, engine and other components.

System diagrams, disassembly drawings, maintenance, fault diagnosis and explanations are presented before each part when compiled.

Notes:

If patterns or structures of the motorcycles change, or differences exist between pictures, drawings, instructions or others and physical products, please take the later as the standard. The product is subject to change without further notice.

Service Data

Maintenance Regulation

Fault Diagnosis


For the complicated assemblies, such as gearbox, keep them in a proper assembling order for the sake of easy assembly later.

以上两例都会使轴承破裂

以上两例都会使轴承破裂

Specifications (BX125)

Model			BX125		Engine	Engine type	157FMI-C
Overall Length(mm)			2020			Fuel	93# unleaded gasoline
Overall Width(mm)			910			Number of cylinders	1
Overall height(mm)			1105			Bore*stroke	57.3 mm *48.4 mm
Wheelbase(mm)			1320			Total Displacement	124.8
Weight (kg)		Front shaft	58kg			Starting mode	Electric
		Rear shaft	76kg			Cooling mode	Air cooling
		Total	134kg			Lubricating mode	Combined force splash
Tire Spec.	Cover tire of the front wheel					Air cleaner	Paper - element
	100/90-18						
	Cover tire of the rear wheel						
	120/80-17						
Drive Train	Clutch type		Wet multi-plate friction type		Performance	Fuel tank capacity	14L
	Gearshift pattern		Manual			Max. speed	101 km/h
	Transmission		Chain drive			Climbing capacity	Maximum climbing angle should not be less than 20 degrees
Electricals	Battery capacity/type		12V-10AH/ lead-acid type			Idle speed-rpm	1500± 100rpm/min
	Generator type		permanent magnet AC motor			Max. torque	11.4N.m/7000r/min
	Spark plug		D8RTC			Max. power	8.3KW/ 8500 r/min
	Spark plug stroke		0.6-0.8mm			Compression ratio	9.3:1
	Ignition type		ECU		Brake	Diameter of front brake disc	φ276mm
				Diameter of rear brake disc		φ220mm	


BX125

Inflexible rotation (low revolutions or powerless)

Fault Diagnosis

Adjustment

Fault Cause



Inflexible rotation (especially low-speed)

Fault Diagnosis

Adjustment

Fault Cause






No sparking of spark plug

Fault Diagnosis

Adjustment

Fault Cause






Spark plug

Remove the spark plug cap



Remove the spark plug with a spark plug socket.







Measure the battery voltage between terminals.

Fully charged: 13.1V

Undercharge: 12.3V

*注意 Attentions

Voltmeter shall be used for charging-state inspection.

Charging

Connection method: Positive pole of battery charger is connected to battery positive lead wire; Negative pole of battery charger is connected to battery negative lead wire.

Warning!

- Battery shall be away from fire source.
- Shut off charger switch first before or after charging in case sparks may be generated at connection parts, which may result in explosion.
- During charging, please take the current time labeled on the battery as the basic time.

* Attentions

- Battery quick charging is not recommended except in case of emergency.
- After charging, wait at least 30minutes and then measure the battery voltage.

Charging current: **Standard: 0.4A**

Quick charging: 4.0A

Charging time: **Standard: 10-15hours**

Quick charging: 30 minutes

After completion of charging: closed-circuit voltage: higher than 12.8V

Select the drive chain lubricating grease in priority. The drive chain lubricating grease may be purchased, or alternated with engine oil or other lubricating oil. Dip the joints of chain links to make the lubricating grease penetrate into chain plate, pin, lining and roller.

Do not install new drive chains onto worn sprockets or install worn drive chains onto the new sprockets.

Keep both sprocket and drive chain in good conditions, or newly replaced chain or sprocket will be worn soon.

10-20mm

Measure stroke of front brake at the tip of front brake handle.

Stroke: 10-20mm

20-30mm

Measure stroke of brake pedal at the tip of front brake handle.

Stroke: 20-30mm.

Adjust the stroke of brake pedal as per the following methods:

-

Wearing of front brake shoe

A close-up photograph of the rear suspension system of a motorcycle. It shows a black shock absorber with a silver-colored piston rod and a silver-colored mounting bracket. The shock is connected to the swingarm, which is partially visible. The background is dark and out of focus.

Wearing of rear brake shoe



Headlamp

Adjustment

Clutch

Start the engine, speed up the revolving speed slowly and check the clutch's operating condition. Check the friction block of the clutch if the motorcycle does not run or the engine is stalled. Replace it with a new one if necessary.

Stroke of clutch: 10-20mm

Adjust the stroke of clutch as per the following methods:

-

Brake disc mounting bolts	15-25N·m
Front hydraulic brake lower pump mounting bolts	25-35N·m
Front hydraulic brake oil pump mounting bolts	7-9N·m
Front axle	75-85N·m
Rear brake disc mounting bolts	15-25N·m
Rear hydraulic brake lower pump mounting bolts	25-35N·m
Rear hydraulic brake oil pump mounting bolts	7-9N·m
Rear axle	75-85N·m

- Improper brake adjustment
- Wearing of braking shoe assembly and hydraulic brake disc
- Improper installation of braking shoe assembly
- Contamination of braking shoe assembly and hydraulic brake disc

- Improper brake adjustment
- Wearing of braking shoe assembly and hydraulic brake disc
- Improper installation of braking shoe assembly

- Wearing of braking shoe assembly and hydraulic brake disc
- Contamination of braking shoe assembly and hydraulic brake disc

- Air found in hydraulic system
- Leakage of hydraulic system
- Dirty brake pedal/disc
- Caliper piston seal wear
- Brake pedal/disc wear
- Dirty caliper
- Improper sliding of caliper
- Small quantity of brake fluid
- Brake fluid passage blockage
- Caliper piston bending / incompleteness

- Master cylinder piston bending / incompleteness
- Dirty master cylinder piston
- Brake handle / pedal bending

1.2.5 Brake Jammed Or Aside

- Dirty brake pedal/disc
- Wheel bias
- Brake hose junction clogged or restricted
- Brake disc bending / incompleteness
- Improper sliding of caliper

1.2.6 Brake Drag

- Dirty brake pedal/disc
- Wheel bias
- Brake pedal/disc wear
- Brake disc bending / incompleteness
- Improper sliding of caliper

5.2.7 Hard Brake Handle/Pedal

- Braking system clogged / restricted
- Caliper piston adhesion/abrasion
- Improper sliding of caliper
- Brake fluid pipe clogged / restricted
- Caliper piston seal wear
- Master cylinder piston adhesion / abrasion
- Brake pedal/disc bending

1.3 Front Hydraulic Brake


1.3.1 Removal

* Attentions

- Replacement of brake shoe assembly group.
- If the brake shoe is reused, it shall be marked on its side before demolition so that it can be installed back to its original position.

Release the brake cylinder assembly mounting bolts.

Remove the brake cylinder assembly from



the front shock absorber.

Remove the following components from the front shock absorber

Front hydraulic brake

1. Brake shoe
2. Front hydraulic brake tube
3. **Brake cylinder assembly**

*注意 Attentions

- Please do not contaminate braking shoe assembly with oil while assembly or disassembly
- Please use specified detergent to clean the braking assembly, or it may reduce braking performance.

Remove the front axle.

Remove the front wheel.

Remove the front hydraulic brake disc from the front wheel


1.3.2 Inspection

Check whether the braking shoe is worn out. Replace the braking shoe if necessary.

Measure the braking shoe and brake disc, and record the maximum value.

Measure the thickness of braking shoe.

Allowable limit: brake shoe 4.5mm




Specifications

Diameter of front hydraulic brake disc: $\phi 276\text{mm}$

* Attentions

- The brake disc shall be wrapped with #120 abrasive paper in case of rustiness.
- A micrometer shall be used for the measurement.

If brake disc and braking shoe are contaminated by grease or their thickness is smaller than service limit, replace them.



* Attentions

- Measure with vernier caliper and

Remove the following assemblies from the rear wheel

Rear brake:


1. Rear hydraulic brake assembly
2. Braking shoe assembly
3. Lining
4. Disc brake bracket

1.4.2 Inspection

Check whether the braking shoe is worn out. Replace the braking shoe if necessary.

Measure the braking shoe and brake disc, and record the maximum value.

Measure the thickness of braking shoe.




Service limit: braking shoe: 4.5mm

Specifications

Diameter of rear hydraulic brake disc: $\phi 220\text{mm}$

* Attentions

- If the hydraulic brake disc is rusty, please polish it with #120 abrasive paper
- A micrometer shall be used for the measurement.



If the brake disc and braking shoe are contaminated by grease or their thickness is smaller than the service limit, replace them.

* Attentions

- The vernier caliper and micrometer shall be used for the measurement.

1.4.3 Installation

Install the rear wheel.

Install the rear brake disc.

Install the brake cylinder of rear brake.

* Attentions

A contaminated braking shoe will decrease braking performance and result in braking failure.

Tighten bolts and nuts to their specified torque value.

3.2.7 Soft front shock absorber

- Inadequate fluid in the shock absorber
- Infirm shock absorber spring
- Low tire pressure

3.2.8 Too hard front shock absorber

- Inappropriate fluid weight
- Blocked shock absorber fluid channel

3.3 Front wheel

3.3.1 Removal

Support the vehicle bottom to make the front wheel lifted

Unscrew the locknut of front axle

Remove the front wheel shaft

Remove the front wheel

Remove the oil seal and bearing of oil seal remover and shaft bearing replacer.




3.3.2 Inspection

3.3.2.1 Inspection of wheel shaft bending

Place the wheel shaft onto a V-shaped base, and the measure eccentricity with a micrometer gauge.

Service limit: replacing in case of exceeding 0. 2mm.




3.3.2.2 Inspection of wheel disk

wobbling

Service limit:

Longitudinal direction: replacing in case of exceeding 2.0mm

Horizontal direction: replacing in case of exceeding 2.0mm



S/N	Name	S/N	Name
1	Rear-view assembly	8-1	Hexagon socket head bolts M6×22
1-1	Right rear-view mirror	8-2	Fixed half cover
1-2	Left rear-view mirror	8-3	Left handle seat
2	Right balancer	8-4	Left handle
3	Right handle grip	9	Left brake handle switch
4	Right brake handle switch	10	Left handle grip
5	Throttle cable	11	Left balancer
6	Handlebar tube	12	Rear brake arm
7	Clutch cable	13	Rear brake return spring
7-1	Clutch cable sleeve	14	Bolt M8×16
8	Clutch handle assembly		

3.4.1 Removal

Remove front brake handle and left handle assembly

Remove the throttle seat and right handlebar assembly

Remove the throttle cable assembly

Remove the left direction handlebar sleeve

Remove the clutch cable assembly and valve cable assembly

Remove the mounting bolts of handle and remove the handle


3.4.2 Installation

It should be installed in reversing sequence of disassembly.

Mounting bolt

Torque value: 25-35N·m

3.5 Front fork



S/N	Name	S/N	Name
-----	------	-----	------

1	Decorative buckle	2-10	Steering stem upper washer
2	Steering stem assembly	2-11	Steering stem cover nut
2-1	Steering handle clamp	3	Headlight bracket
2-2	Steering handle holder	3-1	Screw M6×16
2-3	Steering handle holder damped adhesive	4	Front left shock absorber
2-4	Upper steering	4-1	Front shock absorber boot
2-5	Hexagon socket cap head screws M8×30	4-2	Front shock absorber seal
2-6	Holder washer	5	Speedometer cable clip
2-7	Nut M8	6	Bolt M6×12
2-8	Steering stem	7	Side reflector
2-9	Steering bearing	8	Front right shock absorber

3.5.1 Removal

Remove the front fender.

Remove the front wheel.

Remove the brake hose and speedometer cable.

Remove the front shock absorber.

Remove the steering fixing nut.

Remove the steering handle.

Tools:

Steering handle fixing screw wrench.

Fixing nut wrench.

3.5.3 Installation

Tools:

Fixing nut wrench.

Turn the front fork left and right to confirm its smoothness without any looseness.

Steps:

Install the steering handle.

Install the front shock absorber.

Install the front wheel.

[illegible]

* Attentions

Do not attempt to straighten bent shaft.

Clean parts of rear swing arm mounting shaft with a solvent.

Check rear swing arm shaft sleeve component and intermediate sleeve and if any damage is found, replace it.


4.6 Drive Chain

4.6.1. Removal

Stop the motorcycle on the flat ground, and support it securely.

Remove the shifting lever arm, left rear cover, and drive sprocket.

Remove the rear wheel, chain guard, and chain drive.




4.5.2. Inspection

Clean the drive chain, put it into kerosene, brush the dirt,

and then take out the chain from the kerosene and make it dry.

Check the roller ① and side panel ②,
if damaged or worn, replace the drive chain,



Lubricate the drive chain with the lubricant purchased from the store.

Check the drive chain, if it is hard, clean, lubricate or replace it.





Maintain the chain looseness within the specified limits.

8. Inspect the entire electric load.
9. Quick charging is forbidden except in emergency.
10. During quick charging, the battery must be removed from the motorcycle first and then be charged.
11. While battery is exchanged, please do not use liquid-feeding battery.
12. A voltmeter shall be employed to check the state of charged battery.

Service Data

Item			Specification
Battery	Capacity/type		12V-10AH/ lead-acid type
	Voltage (20℃)	Fully charged	13.5V
		Must be charged	12.3V(stop working for one hour)
	Charging current		Standard: 0.9A, Quick: 9A
	Charging time		Standard: 10-15hours; Quick: 30minutes
Magneto	Capacity		150W/1500rpm
	Coiling impedance value (20℃)		White-white 0.5-10Ω
Voltage regulator	Type		Full-wave rectification
	Battery charging voltage		14.5V±0.4V/5.000rpm

Tightening torque value

Tools

Rectifier bolt	5.0 N·m	Universal non-adjustable spanner
High-voltage coil pinch bolt	9.0 N·m	Flywheel remover
	Testing device	
	Multimeter	

5.2 Fault Diagnosis

No power

- Battery over discharged
- Wiring of battery is not connected.
- Fuse fails.
- Failure of power switch

Low voltage


- Battery is poorly charged.
- Poor contact.
- Failure of charging system
- Failure of voltage and current regulator

the state of charged battery.

5.3.2 Charging

Connection method: Positive pole of battery charger is connected to battery positive pole;

Negative pole of battery charger is connected to battery negative pole.



Warning!

- Battery shall be away from fire sources.
- Shut off charger first before or after charging in case that sparks may be generated at connection parts, which may result in explosion.
- During charging, please take the current time labeled on the battery as the basic time.

* Attentions

- Battery quick charging is not recommended except in case of emergency.
- After charging, measure the battery voltage in 30minutes' time.

Charging current: Standard: 0.4A

Quick charging: 4.0A

Charging time: Standard: 10-15 hours

Quick charging: 30 minutes

Charging completed: open circuit voltage: higher than 12.8V

5.4 Charging System

5.4.1 Short circuit test

Disconnect the grounding wire from the battery and use a voltmeter to connect battery negative lead wire with grounding wire. Set the switch at OFF position and check if it is shorted.

* Attentions

Positive lead wire of multimeter is connected to negative lead wire of battery.

If abnormality is found, check if there is short circuit on ignition switch and main wiring.

5.4.2 Charging State Inspection

While in inspection, if the battery is fully charged, a multimeter shall be used for the test.

Warm up the engine and then install the fully charged battery onto the motorcycle.

Connect voltmeter between terminals of the battery.

Remove the main fuse and connect an ammeter between the two terminals.

Start engine and slowly raise RPM. Measure limited voltage and current.

Limited voltage/rpm: 14-15V (5.000rpm)

If limited voltage is beyond the specified range, check the voltage regulator.

Check the limited voltage of lighting system.

* Attentions

A multimeter shall be set at AC voltage.

Limited voltage: 13.5(+/-)0.5V/5.000rpm

If limited voltage is beyond the specified range, check the voltage and current regulator.


5.5 Voltage-current Regulator

5.5.1 Loop inspection on main wiring

Disconnect the 6P plug on the voltage-current regulator.

Check continuity between main wiring terminals in the following way:

Item (wire color)	Judgment
Between battery (red) and ground of vehicle block	There is battery voltage.
Between ground wire (black) and ground of vehicle block	There is a lead wire.
Between charging coils (yellow 1 and yellow 3)	There is resistance between coils
Between charging coils (yellow 1 and yellow 2)	There is resistance between coils
Between charging coils (yellow 2 and yellow 3)	There is resistance between coils





Align the groove on the flywheel with the fixed key on the shaft

*** Note**

If the inner face of the flywheel is magnetic, make sure no any bolt

Fix the flywheel using a universal non-adjustable spanner and then tighten the locknut.

Torque value: 9.0 N·m

Install the left rear cover.



VI Ignition System

Service Data-----6.1	Ignition Coil-----6.4
Fault Diagnosis-----6.2	Trigger-----6.5
Ignition System Inspection-----6.3	

6.1 Service Data

Precautions on operation

1. Ignition system inspection: please perform inspection in accordance with the sequence listed in the fault diagnosis table.
2. The ignition system is solidified in the ECU assembly, so ignition time adjustment is unnecessary.
3. Ignition system inspection: please perform inspection in accordance with the sequence listed in the fault diagnosis table.
4. Ignition system ECU shall not be dropped and hung, or heavily knocked (this is also the main reason for its failure). Pay special attention to this while removing it.
5. Most of the ignition system problems are due to poor contact of sockets. Please check first if parts of the connector are well contacted.
6. Check if heat value of spark plug is proper. Improper spark plug may result in unsmooth engine running or burnt of spark plug.

7. The maximum voltage is taken to introduce inspection items in this Part. Inspection methods for impedance value of ignition coil are also recorded and judged.
8. Check ignition switch according to the continuity test table.
9. Remove generator and stator on operation instructions.

Service data

Item		Standard Value
Recommended Spark plug	Standard	D8RTC
Spark plug stroke		0.5-0.7mm
Ignition coil impedance value (20℃)	Primary coil	0.4Ω (+/-) 10%
	Secondary coil	4.5-5.5KΩ
Impedance value of trigger (20℃)		100-200Ω
Ignition coil primary peak voltage		95-400V
Trigger voltage		1.7V 以上

工具 Tools

Accessories for maximum voltmeter
Multimeter

6.2 Fault Diagnosis

No sparking of spark plug


Ignition coil	Symptom	Possible causes(Determine the cause from 1 in sequence)
	When the high voltage power is too low.	<p>①When inner impedance is too small, use the appointed tester to test.</p> <p>②Crankshaft rpm is too low.</p> <p>③Tester is disturbed (it is normal when several times' measured voltages are above the basic) .</p> <p>④ Wiring of ignition system is poorly contacted.</p> <p>⑤Ignition coil is no good.</p> <p>⑥ Charging coil is bad. (Peak voltage measurement)</p>

Secondary side voltage	While no high-voltage power supply, high voltage power is sporadic.	①Tester is wrongly connected. ②Poor ignition switch. ③Poor contact of joint ④Short-circuit or poor contact of bond strap ⑤ Poor charging coil (Peak voltage measurement) . ⑥ Defective trigger (Peak voltage measurement) . ⑦ Poor connector of high voltage wire. ⑧ Inferior ECU assembly.(after items ①-⑦ are tested and proved abnormal or spark plug no sparking.)
	High-voltage power is normal, spark plug no sparking.	①Inferior spark plug or secondary leakage of the ignition coil. ② Poor ignition coil.
Charging and lighting coils	No high-voltage power supply	①Inner impedance is too low. Use appointed tester to test. ②Crankshaft rpm is too low. ③Tester is disturbed (it is normal when more than one time's measured voltage is above the basic) . ④Poor charging coils (when items (①-③ are proved normal)
	No high-voltage power supply or high voltage power is sporadic.	② Poor ignition coil. ②Poor charging coil.
Trigger	High-voltage power supply is too low.	①Inner impedance is too low. Use appointed tester to test. ②Crankshaft rpm is too low. ③Tester is disturbed (it is normal when more than one time's measured voltage is above the basic) . ④ Poor trigger (when items (① - ③ are proved normal)
	No high-voltage power supply or high voltage power is sporadic.	①Poor ignition coil. ②Poor trigger.

6.3 Ignition System Inspection

* Attentions


- When the spark plug is not sparking, check if components of wiring are loosened or badly contacted and make sure all the voltage values are normal.



6.3.1 Primary voltage of ignition coil

* Attentions

Normal cylinder compression pressure means to test with spark plug installed on the cylinder head.




Press starter motor button or kick starter pedal to measure primary peak voltage of ignition coil.

* Attentions

6.3.2 Charging and lighting coil

* Attentions

Minimum voltage: 95V or more.




Starter motor clutch cap bolt	12 N·m
Starter motor clutch locknut	95 N·m

Universal un-adjustable wrench

Stator motor cannot run does not	Stator motor runs weakly	Starter motor rotates but the engine
•Broken Fuse	•Low battery	•Defective starter clutch
•Low battery	•Poor connecting wire contact	•Starter motor counter-rotate
•Defective ignition switch	•Stator motor gear stuck by foreign substances	•Low battery
•Defective starter clutch		
•Defective braking switch		
•Defective starter relay		
•Defective connecting wire contact		
•Defective starter motor		

7.3.1 Removal

Before removing starter motor, the ignition switch must be set at “OFF” position. Disconnect battery grounding wire and then turn on the power supply to check if the starter motor runs to confirm safety.

[illegible]

Take off the light.

8.5.3.2 Installation


Install the bulb in the reverse order of removal.

8.6 Instrument

Remove the meter connectors.

Remove the meters.

Install the instrument orderly in the reverse order of removal.





8.7 Main Switch





8.7.1 Inspection

Disconnect connector of main switch lead wire.

Check the connector terminal for continuity.



接线原理图

	红	黑	黑/白	绿
□N				
□F				

turning the dry friction on the surface into liquid friction between lubrication oil particles, thus mitigating part wearing, cooling down parts with high thermal load, absorbing impact from bearing and the elements and consequently reducing noises, increasing tightness between cylinder ring and wall, and cleaning and taking away foreign matters from surface of parts.

Precautions:

After engine oil pump is disassembled, carefully clean its parts and purge the surface with high-pressure gas.

To disassemble engine oil pump, it is important to prevent any foreign matter from falling into crankcase.

Standard Value and Allowable Limit of Reference Items

Item			Standard	Allowable limit
Engine oil capacity	For changing oil		1L	-
	For disassembly		1.2L	-
Pump rotor	Radial stroke between inner and outer rotors	Oil pressure pump	0.025-0.175	0.23
		Oil suction pump	0.025-0.175	0.23
	Stroke between outer rotor and pump	Oil pressure pump	0.11-0.163	0.22
		Oil suction pump	0.11-0.163	0.22
	Rotor face-to-face stroke	Oil pressure pump	0.05-0.11	0.15
		Oil suction pump	0.05-0.11	0.15

9.2 Fault Diagnosis

Engine oil decreases

Engine oil is consumed naturally.


Engine oil leakage

Engine damaged


No or too low oil pressure

Oil circuit clogged.


Discharge: 0.09mm



Fix cylinder head, and use the guide disassembly tool to remove the guide out of the head.



Attention: Do not damage the head when fit the valve.



		Oil ring	0.15-0.6	-
	Piston pin end ID		13.990-14.017	14.067
	Stroke between connecting rod and piston pin		0.010-0.021	0.089

12.2 Fault Diagnosis

Low compression pressure

Piston worn, burnt or broken

Cylinder and piston worn or damaged

Gasket damaged and air leakage between crankcase and gas

Too high compression pressure

Too much carbon deposits in combustion chamber

White smoke from discharge duct

Piston ring worn or damaged

Cylinder and piston worn or damaged

Abnormal noise from piston

Cylinder, piston and piston ring damaged

Piston pin hole and piston pin worn

12.3 Cylinder Block

Disassembly

Remove the cylinder block.

Inspection

Check wearing of inner wall of cylinder.

If serious wearing is found, replace it.

Remove the gasket and locating pin.



Piston

Disassembly

Remove the piston retaining ring.

Attention: During removal, do not fall the retaining ring into crankcase.

Take out the piston pin and remove the piston.

Remove the piston ring.

Check piston, piston pin and piston ring.




B B


Note: do not damage the surface of the case.

Allowable limit: 0.5mm


Measure the stroke along X-Y direction of the big end
Allowable limit: 0.002-0.010mm



Measure the dislocation of the crank shaft.
Allowable limit: 0.03mm



Check if the crank shaft is noisy or loose while restoring the engine.
Replace it if so.




Inspection

A diagram showing a curved surface with a vertical line segment labeled "千分尺" (micrometer) indicating a measurement.

Measure the the shifting fork thickness.

Allowable limit: 4.7mm

游标卡尺




Measure the gearshift drum OD.

Allowable limit: 35.75mm

Measure gearshift drum lock groove width

Allowable limit: 7.35mm

锁槽宽度




13.7 Transmission chamber

Remove the primary shaft assembly.

Remove the secondary shaft assembly.

副轴组件



主轴组件

speeds.

Please notice the following items to ensure consistence with emission standards:

- 1) Fuel: only E5 or above unleaded gas can be used.
- 2) Engine oil: only specified engine oil can be used.
- 3) Maintain it according to the instruction in the periodic maintenance table.
- 4> No private adjustment or replacement can be done to the exhaust control system, including: use of spark plug, idling adjustment, ignition timing and adjustment to the throttle.
- 5) Notes:

Problems in ignition system, charging system and fuel system have great impacts on the catalytic device, so if there are problems in the engine, please send it to the franchisers or service centers for check, adjustment or repair without delay.

6) The exhaust control system of this vehicle complies with the national regulation, so only the components produced in our company can be used while replacing any components in the system, and it should be done in our franchisers or service centers.

13.3 Mechanical Functions of Exhaust Control System

Overview

The exhaust solution is based on the use of the four-stroke single cylinder engine and the throttle, air inhaling device, high standards of emission control and use of charcoal canister for emission evaporation.

※ Improvements in the engine

Central spark plug are improved by improving the compression ratio, ignition time and exhaust system in the engine to improve the efficiency of fuel.

✕ **Air inhaling device**


Air is led into the exhaust pipe to compose the CO and HC that are not completely burned into harmless emission.

Division	Device	Component	Purposes and functions
Combustion system	Combustion chamber	Hemispherical combustion chamber	The hemispherical combustion chamber with a centrally-placed spark plug ensures the combustion safety.
Exhaust system	Catalytic device	Catalytic converter	Canned oxidation catalyst contained in the center of the exhaust pipe oxidizes CO, HC and NO _x .

—Adjustable parameters and recommended setpoint


Idle speed adjustment - engine speed 1500 ± 100 rpm / min

CO concentration of 0.5-1.2%





Notes:

- 1: Test it according to the idling testing procedure.
2. Adjust the engine idle speed to the specific value, and test CO/HC in idling.



装置号	装置描述
JH-1	超速控制开关1组
JH-2	
JH-3	位置灯
JH-4	
JH-5	
JH-6	灯罩盖
JH-7	CAN通信号线
JH-8	CAN通信号箱
JH-9	电源（系统）模块
JH-10	
JH-11	超速控制开关2组
JH-12	超速控制开关3组
JH-13	超速控制开关4组
JH-14	
JH-15	
JH-16	诊断开关
JH-17	
JH-18	空档开关
JZ-1	点火线圈驱动A（1缸）
JZ-2	电源（系统）模块
JZ-3	ECU/ECM
JZ-4	燃油信号箱
JZ-5	燃油泵
JZ-6	
JZ-7	废气涡轮增压
JZ-8	进气温度信号
JZ-9	进气压力信号
JZ-10	风泵/电压互感器 （信号地）
JZ-11	进气压力信号
JZ-12	节气门位置信号
JZ-13	25油压信号
JZ-14	机油温度信号
JZ-15	点火电路
JZ-16	200V电压
JZ-17	废气温度信号
JZ-18	水泵电路



File Clear Gauge Setup Playback Slew Help


Time 00:00:00

Protocol: ALDL Device Code: (in dec) Keyword2000 17



Cancel OK

Unit	Value	Unit	Value	Unit	Value	Unit	Value
VRPM	0.00 pct	FCNO	0 cellNo	MALFCURR	0 NA		
0	200.00	255	1000				
VTHROT	0 CA	FBLMCR2	0.000 factor	MALFHIST	0 NA		
0.0	300	0.000	2.000				
VBARO	0.0 CA	FBLMCR1	0.000 factor	RUNTIME	0 Sec		
0.0	256.0	0.000	2.000				
VMAP	0 count	FBLMCR2	0.000 factor	Undefined Parameter			
0.0	256.0	32768	0.000	2.000			
VMAPEXP	0.0 kpa	FCLCINT2	0 count	ARDRPM	0 rpm	VAFCLNUM	0 cellNo
0.0	256.0	32768	32767	0	2000	0	32
VIGN	0.0 voltage	VAFCMULT	0.00 factor	VAFCMULT	0.00 factor	VCSPC	0 count
0.0	65535	0.00	2.00	0.00	2.00		65535
VCLTS	0.0 degC	IACVDSMP	0 step	VO2B	0.00 mV	VTHROTRAW	0 count
-256.0	256.0	255	0.00	1023.98			65535
VIAT	0.0 degC	IACVDSMP	0 step	VO2	0.00 mV	STATUSBYTE1	00000000
-256.0	256.0	255	0.00	1024.00			
STATUSBYTE5	00000000	STATUSBYTE2	00000000	STATUSBYTE1	00000000	STATUSBYTE4	00000000
VAFCMET		FCLCEN1		FUELCOFF		CYCSENBL	
VBAROCMET		PPDSEBL		FCOCRFLD		VCSINSYN	
VCSINSYN	SPRK	FPENABL		DFCOCMET		IDLCONM	
SATITRIG		FTRNSAES		DFCOENBL		FPESTAT	
CATLOENB		FTRNSDES		DFCOENBL		FPEAFREN	
IF ENGSTATE=3		FTRNSAEDCLOAD		FCOHRPM		PNSWITCH	
NISTBLIDL		FTRNSDEINLOAD		YRLVENBL		DIAGSWTCH	
FO2REDY2		FCLCEN2		FCLREST2		VbVios_MIL_Status	

(5) If the software interface cannot display communication data after the computer is powered, it is necessary to conduct the following work: inspect whether COM port is correctly arranged in the state of "Setup" (generally set as COM Port: 4. Baud Rate: 10400; don't select "DTR high at startup"),



Then the software interface will recover communication, display current fault code at "MALFCURR" and past fault code at "MALFHIST", and inquire the corresponding faults as per the List of Fault Codes.

MALFCURR	0 NA
	
0	1000
MALFHIST	0 NA
	

Schedule 2: List of Fault Codes

– 139 –

诊断仪

[illegible]

- b) Check fuel level in fuel tank and fuel filter;
- c) Check whether the exhaust system is blocked, e.g., three-way catalytic converter is blocked due to burn fuel or break-up;
- d) Inspect fuel path pressure and nozzle;
- e) Check whether the fault indicator blinks and whether the reason is that only one cylinder can normally ignite.

16.4.3.8 Symptom - Slight sparking

Check whether the spark plug clearance is in line with the specification (0.6 ~ 0.8 mm)

16.4.3.9 Symptom - Fault indicator blinks but fault code is inconsistent with actual fault

The fault may be caused by loose connection of ground wire of the system; re-connect the ground wire, then disconnect the power cord of the accumulator for 3 minutes and re-connect the cord, and start the engine.

16.4.3.10 Symptom - Abnormally high fuel consumption

- Inspect the oxygen sensors of two cylinders are installed in place; if loose, the oxygen sensor erroneously judges there is little burning in the cylinder and the fuel is added, resulting in abnormally high fuel consumption.
- After confirming the engine mechanical components and oxygen sensors are in normal state, operate the engine to observe the reading of oxygen sensor, if always greater than 500 mV at normal water temperature, inspect whether the fuel injector has leakage.

Precautions

- Most parts of EFI are non-repairable and generally replaced if confirmed as being damaged.
- No mechanism is allowed to operate at engine startup (including the accelerator, i.e., start the engine without pulling the accelerator).
- If engine fault indicator blinks in engine running, it is required to find out the causes and eliminate the fault as soon as possible.
- Leaded gasoline shall not be used, because lead will damage the oxygen sensor and three-way catalytic converter.
- For abnormally rapid fuel consumption, it is necessary to resolve the fault immediately, because some matter in the fuel will damage the oxygen sensor and three-way catalytic converter.
- Valve clearance shall not be too small; if the exhaust port is not tightly closed, the service life of three-way catalytic converter will be shortened by higher exhaust temperature.

- When the temperature is lower than 10°C and the whole vehicle and engine operate at low speed for a long time, the exhaust pipe may have carbon deposit and become black, which is normal, and will be eliminated after a period of high-speed operation. Optionally, appropriate measures can be taken to make the temperature of coolant liquid of the engine within the range of specified temperature.

BB