





Owner's manual

ENGLISH





Dear Ducatista,

thank you for trusting us with the purchase of your new Diavel 1260 / 1260 S.

We recommend that you **read the use and maintenance manual carefully**, to quickly get familiar with your Ducati and **make the most of all its features**. In the manual, we provide lots of useful advice and information on your **safety**, on how to **take care** of your bike and on how to maintain its value through **correct maintenance** by specialist Service Centres.

You can also find this manual in **digital format, always up-to-date, in the dedicated area of the Ducati website** and **in the MyDucati App**, which can be consulted both from a PC and a phone.



In this way, you will always have the **most up-to-date version of the manual** available and you will also find **information and frequently asked questions** regarding your bike and the world of Ducati.

You can send suggestions for improvement regarding the contents of this Use and maintenance manual to the following address: OwnerManual@ducati.com

This manual forms an integral part of the motorcycle and must be kept with it for its whole service life. If the motorcycle is resold, the manual must always be handed over to the new owner. The quality standards and safety of Ducati motorcycles are steadily improved as new design solutions, equipment and accessories are developed. While the information contained in this manual is current at the time of going to print, Ducati Motor Holding S.p.A. reserves the right to make changes at any time without notice and without any obligations. For this reason, the illustrations in this manual might differ from your motorcycle. Any and all reproduction or spreading of the contents herein in whole or in part is forbidden. All rights reserved to Ducati Motor Holding S.p.A. Any request for written authorisation shall be addressed to this company, specifying the reasons for request. For any servicing or suggestions you might need, please contact our authorised service centres.

For further information, please contact us at: contact_us@ducati.com
Our Advisors are available to give you suggestions and useful tips.

Important

For further information, please contact the Ducati Support by clicking on "Contact us" in the Services and Maintenance section of the www.ducati.com website.

Our Advisors are available to give you suggestions and useful tips.

Enjoy your ride!

Roadside Assistance



ACI Global Servizi

Important
The "ACI Global Services" roadside assistance is

in force only in the following countries:
Denmark, Belgium, France, Luxembourg,
Switzerland, Ireland, United Kingdom, Italy, Norway,
Holland, Spain, Austria, Germany, Sweden, Portugal,
Canary Islands, Cyprus, Croatia, Czech Republic,
Estonia, Latvia, Lithuania, Finland, Greece, Hungary,
Malta, Poland, Serbia and Montenegro, Slovakia,
Slovenia, Turkey, Ukraine.

The Ducati Card Assistance Programme, created in collaboration with Ducati and ACI Global Services, offers assistance in case of breakdown and/or accident to the Ducati Customer. The service is active 24 hours a day, 365 days a year, for 24 months (in case of extended warranty the relevant conditions will apply) from the date of delivery of the

motorcycle or for the period of coverage of the Ever Red warranty extension.

The roadside assistance services include:

- Roadside assistance and towing
- Transport of passengers following roadside assistance
- Return of passengers or continuation of the journey
- Recovery of the repaired motorcycle
- Repatriation of the motorcycle from abroad
- Search and sending of spare parts abroad
- Hotel expenses
- Recovery of the motorcycle off the road in case of accident
- Advance payment of bail abroad

and may be requested in the following countries: Andorra, Austria, Belgium, Bulgaria, Croatia, Cyprus, Czech Republic, Estonia, Finland, France (including Corsica, roads open to ordinary traffic) Fyrom (the former Yugoslav Republic of Macedonia), Germany, Gibraltar, Greece, Hungary, Ireland, Iceland, Italy (including San Marino and the Vatican), Latvia, Lithuania, Luxembourg, Malta, Montenegro, the Netherlands, Norway, Poland, Portugal, Monaco,

Romania, Serbia, Slovakia, Slovenia, Spain, Sweden, Switzerland, Turkey, Ukraine, United Kingdom.

Important

All information is detailed and available on the Ducati website of the respective country.

Call Centre telephone numbers

The numbers to contact to request the services listed above are the following:

Andorra	+34-91-594 93 40	+34-91-594 93 40
Austria	0800-22 03 50	+43-1-25 119 19398
Belgium	0800-14 134	+32-2-233 22 90
Bulgaria	(02)-986 73 52	+359-2-9867352
Cyprus	22 31 31 31	+357-22-31 31 31
Croatia	0800-79 87	+385-1-464 01 41
Denmark	80 20 22 07	+45-80 20 22 07
Estonia	(0)-69 79 199	+372-69 79 199
Finland	(09)-77 47 64 00	+358-9-7747640 0

France (+Corsica)	0800-23 65 10	+33-4-72 17 12 83
FYROM	(02)-3181 192	+389-2-3181 192
Germany	0800-27 22 774	+49-89-76 76 40 90
Gibraltar	91-594 93 40	+34-91-594 93 40
Greece	(210)-9462 058	+30-210-9462 058
Ireland	1800-304 500	+353-1-617 95 61
Iceland	5 112 112	+354-5 112 112
Italy	800 744 444	+39 02 66.16.56.10
Latvia	67 56 65 86	+371-67 56 65 86
Lithuania	(85)-210 44 25	+370-5-210 44 25
Luxembourg	25 36 36 301	+352-25 36 36 301
Malta	21 24 69 68	+356-21 24 69 68
Monaco	+33-4-72171283	+33-4-72 17 12 83
Montenegro	0800-81 986	+382-20-234 038

Norway	800-30 466	+47-800-30 466
Holland	0800-099 11 20	+31-70-314 51 12
Poland	061 83 19 885	+48 61 83 19 885
Portugal	800-20 66 68	+351-21-942 91 05
United King- dom	00800-33 22 88 77	00800-33 22 88 77
Czech Republic	261 10 43 48	+420-2-61 10 43 48
Romania	021-317 46 90	+40-21-317 46 90
Serbia	(011)-240 43 51	+381-11-240 43 51
Slovakia	(02)-492 05 963	+421-2-49 20 59 63
Slovenia	(01)-530 53 10	+386-1-530 53 10
Spain	900-101 576	+34-91-594 93 40
Sweden	020-88 87 77	+46-771-88 87 77 (+46 8 5179 2873)

Switzerland (+Liechten- stein)	0800-55 01 41	+41 58 827 60 86
Turkey	(216) 560 07 50	+90 216 560 07 50
Ukraine	044-494 29 52	+380-44-494 29 52
Hungary	(06-1)-345 17 47	+36-1-345 17 47

Table of contents

Dangerous products - warnings 26

	M Po Ta Se
Warranty information12 General warranty conditions12	M Sid Pa
	Βl
General Information17	Fr
Acronyms and abbreviations used in the	Re
Manual17	
Warning symbols used in the manual 17	Cd
Intended use18	Po
Rider's obligations19	Sv
Rider's training20	Lic
Apparel21	"H
Safety "Best Practices"	Ke
Refuelling24	Re
Carrying the maximum load allowed 25	PI
Information about carrying capacity 25	CI.

Engine identification number	29
Main components and devices Position on the vehicle Tank filler plug Seat lock	30 31 32
Maintaining the battery charge Side stand	
Passenger grab handle	
Bluetooth control unit	
Front fork adjusters	
Rear shock absorber adjusters	46
Controls	50
Position of motorcycle controls	50
Switchgears	
Light control	
"Hands free" system	
Keys	75
Restoring motorcycle operation via the	
PIN code	
Clutch lever	
Throttle twistgrip	86

Vehicle identification number.....

Front brake lever87	Engine rpm indication	140
Rear brake pedal88	Clock	144
Gear change pedal89	Engine Coolant temperature	145
Adjusting the position of the	Fuel level	
gearchange pedal and rear brake pedal 90	Riding Mode (RIDING MODE)	148
	DTC indicator	155
	ABS indicator	160
Riding the motorcycle91	DWC indicator	165
Running-in recommendations91	DQS indicator	.17
Pre-ride checks92	Function menu	173
Engine start/stop95	Odometer (TOT)	175
Moving off99	Trip meter 1 (TRIP 1)	176
Braking 100	Trip meter 2 (TRIP 2)	177
Anti-Lock Braking System (ABS)101	Residual range (RANGE)	178
Stopping the motorcycle103	Average Fuel Consumption (CONS. AVG)	179
Parking104	Instantaneous fuel consumption (CONS.).	181
Refuelling107	Average speed (SPEED AVG)	183
Tool kit and accessories110	Trip time (TRIP TIME)	
	Ambient air temperature (T AIR)	187
	Setting menu (SETTING MENU)	189
Instrument panel (Dashboard)111	Setting menu - riding mode (RIDING	
Instrument panel111	MODE)	193
Parameter displaying116	Setting menu - riding mode- setting the	
Main and auxiliary functions136	engine (ENGINE)	196
Vehicle speed indication137	Setting menu - riding mode- setting the	
Gear indication139	DTC (DTC)	199

Setting menu - riding mode- setting the ABS (ABS)		Setting menu - Se SET)
Setting menu - riding mode- setting the DWC (DWC)		Setting menu - se (INFO SERVICE).
Setting menu - riding mode- setting the DQS (DQS)	208	Setting menu - se measurement (UI
Setting menu - riding mode - restore all values for each single riding mode	200	Setting menu - tu setting (TURN IN
(DEFAULT)		Setting (Fortivity
Setting menu - riding mode - value reset (ALL DEFAULT)	213	devices - accessor Setting menu - in
Setting Menu - display mode setting (INFO MODE)	214	LAP TIME
Setting menu - lap time (LAP)	217	DPL)
Setting menu - pin code activation (PIN CODE)	223	Cruise Control Infotainment
Setting menu - pin code modification (PIN CODE)	227	Service indication OIL SERVICE zero
Setting menu - DRL light mode setting (DRL CONTROL)		OIL SERVICE or A
Setting menu - tyre setting and drive	. 234	OIL SERVICE or A
Setting menu - setting the backlighting (BACKLIGHT)		Light mode indicated Viewing side standard
Setting menu - setting the date (DATE SET)		Warnings/Alarms Error warnings
		-

Setting menu - Setting the time (CLOCK SET)	248
Setting menu - service information	
(INFO SERVICE)	. 252
Setting menu - setting the unit of	
measurement (UNITS SETTING)	. 253
Setting menu - turn indicator mode	
setting (TURN INDICATORS)	26
Setting menu - setting Bluetooth	
devices - accessory (BLUETOOTH)	
Setting menu - information (INFO)	
LAP TIME	. 2/5
Assisted start (LAUNCH CONTROL -	276
DPL)	
Cruise Control	
Infotainment(SER)/(SE)	
Service indication (SERVICE)	
OIL SERVICE zero warning OIL SERVICE or ANNUAL SERVICE or	. 296
DESMO SERVICE of ANNOAL SERVICE of DESMO SERVICE countdown indication.	200
OIL SERVICE or ANNUAL SERVICE or	. 293
DESMO SERVICE indication	300
Light mode indication (DRL)	
Viewing side stand status	
Warnings/Alarms (WARNING)	
Error warnings	

Main use and maintenance operations	313	So
Checking coolant level and topping up, if necessary	. 313 . 315 . 317 . 318	Te W
Lubricating the drive chain	326 . 331 .332 334	Fi Ei Ti Pi Si
Check engine oil level	.337 339 .341 342	Fit Bit Tr Fr W Ty Sit
Scheduled maintenance chart3	344	E)

operations to be carried out by the dealer 344

operations to be carried out by the customer	348
Technical data	349 350 35 35 35
Fuel system	
Brakes	
Transmission	356
Frame	35
Wheels	35
Tyres	
Suspension	
Exhaust system	
Available colours	
Electric system	360

Open source software.....364

Information about open source software. 364

Declarations of conformity	365
Declarations of conformity	365

Warranty information

General warranty conditions 1. Warranty content

- 1.1. Ducati Motor Holding S.p.A. A Sole partner company- a Company of the Audi Group, with headquarters in via Cavalieri Ducati no. 3, 40132, Bologna, Italy (hereafter "Ducati") guarantees anywhere in the world where its official service network is present (list available at www.ducati.com) that all of its new motorcycles, manufactured for road use, for a period of twenty-four (24) months with no mileage/km limitation from the delivery date of the motorcycle to the first owner, shall be free of defects in workmanship as ascertained and recognised by Ducati.
- 1.2. In such cases, the Customer has the right to the repair or replacement of defective parts, free of charge.
- 1.3. The defective parts replaced under warranty become the property of Ducati.

- 1.4. The new parts replaced under warranty or repaired are covered by warranty for the remaining outstanding warranty period of the motorcycle.
 1.5. Also, through a specific insurance policy, Ducati offers the Customer additional roadside and health assistance services in the Countries listed in the "Owner's manual", according to the specific terms and procedures reported therein.
- 1.6. The present general warranty conditions (hereafter "Warranty Conditions") do not in any way compromise the unalienable rights granted to individuals falling under the definition of "consumer" under the law of their respective countries. These warranty conditions are without prejudice to national provisions transposing and implementing Directive 99/44/EC in force in EU countries (in Italy, Legislative Decree no. 206 of 6 September 2005 Consumer Code). In the event any one provision of these Warranty Conditions should conflict with mandatory law in force in the country of residence or domicile of the "consumer", such provision shall be treated as null and void.

2. Exclusions

2.1. This warranty offered by Ducati is not applicable to:

- a) to the Motorcycle that has not fully complied with the scheduled maintenance plan provided for in the Owner's Manual;
- b) to the Motorcycle with incorrect maintenance or repair operations carried out by parties other than the Ducati Authorised Dealers and/or Service Centres;
- c) to faults due to neglect of the Motorcycle;
- d) to faults concerning parts subject to wear and tear during normal operation of the Motorcycle (such as: tyres, filters, bulbs, final drive, belts, flexible controls, spark plugs, brake and clutch parts subject to friction, such as brake plates and pads, etc.);
- e) to aesthetic defects in painted or chromeplated surfaces, such as oxidation of the Motorcycle and/or components thereof, natural discolouring, etc.;
- f) to faults involving Motorcycle battery if not properly kept charged with a Ducati charge maintainer:
- g) if the Motorcycle is used in sporting competitions of any kind or for damage

- resulting from improper use of the Motorcycle, on the track or on the road;
- h) to the Motorcycle to which modifications not approved by the manufacturer have been made, or that has been tampered with in any way and/ or tuned in order to alter its performance, or with odometer tampered with;
- i) to the Motorcycle used in commercial or rental services or otherwise used for professional use;
- j) to the Motorcycle fitted with non-original Ducati spare parts or accessories or not authorised by Ducati;
- k) to the use of lubricants with specifications that do not comply with Ducati's requirements for the Motorcycle in question;
- I) to failure to comply with the prescriptions for the use of the Motorcycle and its equipment as indicated in the Owner's Manual;
- m) to modifications to the Motorcycle made by the Customer and / or third parties without the express approval of Ducati;
- n) to the Customer's failure to adhere to any recall and/or update campaigns planned by Ducati on the Motorcycle.

3. Responsibilities of the Customer

- 3.1. To activate this warranty and maintain its validity, the Customer is required to:
- a) notify one of the Ducati Authorised Dealers and/or Workshops (list available at www.ducati.com) of any defects of the motorcycle within two (2) months after Customer discovered said defects.
- b) keep adequate documentation of any maintenance and/or repair work carried out on the vehicle (receipts/invoices with details of the activities carried out and the parts used). You can consult the history of the ordinary maintenance of your motorcycle on the website www.ducati.com in the MyDucati section or on the MyDucati app.
- 3.2. In order to maintain the validity of the warranty in the event of a change of motorcycle ownership, the new owner must promptly notify Ducati of the change of ownership of the motorcycle, by communicating it on the website www.ducati.com in the MyDucati section or at the Ducati Authorised Dealers and/or Workshops.
- 3.3. If the provisions of points 3.1. and 3.2 are not observed, this warranty offered by Ducati will not

longer be in effect and the Customer rights to warranty performance will become null and void.

4. Limitations of liability

- 4.1. Without prejudice to the national regulations applicable to the "consumer" and relating provisions on manufacturer liability, Ducati shall not be held liable in case of damage to people and/or property caused by the motorcycle or while using the same. 4.2. Any defects or delays in the repairs or replacements relating to the motorcycle caused by Ducati Authorised Dealers and/or Workshops shall not give the buyer the right to claim damages of any kind from Ducati, nor to extend the warranty per the present Warranty Conditions, without prejudice to the Customer's rights and actions with respect to the Ducati Authorised Dealer and/or Workshop that may be negligent/defaulting.
- 4.3. This warranty, under the terms specified here, constitutes the sole warranty offered by Ducati.
- 4.4. Ducati reserves the right to make changes and improvements to any model of its motorcycles, without the obligation to make said changes to motorcycles already sold.
- 4.5. These Warranty Conditions also extend to subsequent owners of the Ducati motorcycle,

provided that the provisions under art. 3 above are complied with.

4.6. Except as for the "consumer", or as otherwise provided by a mandatory regulation in force in the country of the Customer, the Court of Bologna (Italy) shall have sole jurisdiction over any controversies that may arise in connection with these Warranty Conditions.

4.7. These Warranty Conditions are governed by Italian law.

5. Additional warranty and warranty extensions

5.1 Additional warranties may be provided or purchased depending on the product and the country (e.g. 4|Ever Multistrada, Factory Ever Red and Ever Red). For further details please refer to the Warranty Contract delivered by your Dealer when handing over your new motorcycle to the first owner or on the website www.ducati.com in the MyDucati section or on the MyDucati app.

6. Scheduled maintenance plan and pre-delivery

- 6.1. The pre-delivery operations are carried out by the seller.
- 6.2. Ducati has defined the scheduled maintenance plan included in the "Owner's Manual" to keep their motorcycles at the best possible levels of efficiency, performance and safety.
- 6.3. Exact observance of the coupons, under the terms set forth herein, is a necessary condition to ensure the maintenance of the vehicle in correct usage status and the validity of this warranty. The following compulsory coupons must be carried out and paid for:
- first coupon: within six (6) months of delivery of the motorcycle to the Customer, or within the first 1000 km/600 miles travelled;

- second coupon: upon reaching the mileage specified in the maintenance schedule and in any case within twelve (12) months from previous service coupon. Customer is solely liable for all costs related to coupons (labour and materials), including the one at 1,000 km /600 miles.
- 6.4. Every maintenance operation on the motorcycle must be carried out in compliance with Ducati's recommendations and procedures, without limitations, including those reported in the "Owner's Manual". Any defect/damage to the vehicle caused by improper or insufficient maintenance will preclude the applicability of the warranty. 6.5. In order to certify that the operations specified for each service coupon have been duly performed, the Dealer and/or Authorised Ducati Workshop shall place their stamp and/or and write the necessary notes and/or perform the digital recording on the Service Booklet and/or in the dedicated area of the website ducati.com; it is also necessary to preserve the receipts/invoices for the service coupons that detail the operations performed. This documentation may be verified by the Ducati

Technical Service for the purpose of providing the services set forth in these Warranty Conditions. 6.6 Ordinary maintenance will be digitally recorded by the Ducati Dealer and available in the MyDucati app or on the ducati.com website.

General Information

Acronyms and abbreviations used in the Manual

ABS	Anti-lock Braking System
BBS	Black Box System
CAN	Controller Area Network
DPL	DUCATI Power Launch
DQS	DUCATI Quick Shift
DRL	Daytime Running Light
DSB	Dashboard
DTC	DUCATI Traction Control
DWC	DUCATI Wheelie Control
ECU	Engine Control Unit
IMU	Inertial Measurement Unit
LIN	Local Interconnect Network
	•

Warning symbols used in the manual

Several kinds of warnings are used as an alert of the possible hazards for you or other persons such as:

- Safety labels on the motorcycle;
- Safety messages preceded by a warning symbol and either WARNING or IMPORTANT.

Attention

Failure to comply with these instructions may put you at risk, and could lead to severe injury or even death of the rider or other persons.

Important

Possibility of damaging the motorcycle and/or its components.

Note

Additional information about the current operation.

The terms RIGHT and LEFT are referred to the motorcycle viewed from the riding position.

Intended use

Attention
This motorcycle was o

This motorcycle was designed for both road use and for light off-road and dirt road use. Heavy duty off-road use is not advised and can result in the rider losing control of the vehicle, thereby increasing the risk of accidents.

Attention

This motorcycle may not be used to tow any trailers or with a side-car attached; this can lead to loss of control and result in an accident.

This motorcycle carries the rider and can carry a passenger.

Attention

The total weight of the motorcycle in running order including rider, passenger, luggage and additional accessories should not exceed 440kg/970lb.

Attention

The passenger seat must only be used for short distances and at moderate speeds.

Important

Using the motorcycle under extreme conditions, such as very damp and muddy roads or dusty and dry environment, could cause aboveaverage wear of components like the drive system, the brakes or the air filter. If the air filter is dirty, the engine could get damaged. Therefore, this might translate in required service or replacement of the wear parts earlier than specified in the scheduled maintenance chart.

Rider's obligations

All riders must hold a valid licence.

Attention

Riding without a licence is illegal and is prosecuted by law. Always make sure you have your licence with you when riding. Do not let inexperienced riders or persons without a valid licence use your motorcycle.

Do not ride under the influence of alcohol and/or drugs.

Attention

Riding under the influence of alcohol and/or drugs is illegal and is prosecuted by law.

Do not take prescription or other drugs before riding unless you have consulted your doctor about their side effects.

Attention

Some medications and drugs may cause drowsiness or other effects that slow down reaction time and the rider's ability to control the motorcycle, possibly leading to an accident.

Some states require vehicle insurance.

Attention

Check your state laws. Obtain insurance coverage and keep your insurance document secure with the other motorcycle documents.

To protect rider and passenger safety, some states mandate the use of a certified helmet.

Attention

Check your state laws. Riding without a helmet may be punishable by law.

Attention

Riders without helmets are more likely to suffer severe bodily injury or die if they are in an accident.

Attention

Check that your helmet complies with safety specifications, permits good vision, is the right size for your head, and carries a certification label indicating that it conforms to the standards in force in your state. Road traffic laws differ from state to state. Learn about traffic laws in your state before riding and always obey them.

Rider's training

Accidents are frequently due to inexperience. Riding, manoeuvres and braking must be performed in a different way than on the other vehicles.

Attention
Untrained riders or a wrong use of the vehicle may lead to loss of control, serious injuries or even death

Apparel

Riding gear is very important for safety. Unlike cars, a motorcycle offers no impact protection in an accident.

Proper riding gear includes helmet, eye protection, gloves, boots, back protector, long sleeve jacket and long trousers.

- The helmet must meet the requirements listed at "Rider's obligations"; if your helmet does not have a visor, use suitable eye wear;
- Use certified, five-finger gloves made from leather or abrasion-resistant material; with knuckle protectors and reinforcements on the fingers;
- Riding boots or shoes must have non-slip soles and offer ankle protection;
- The back protector must be certified and sized based on the physical constitution of the rider, according to the manufacturer's specifications;
- Jacket, trousers or riding suit must be certified, made from leather or abrasion-resistant material and have high-visibility colours and inserts. Select products with certified protectors.

Important

Never wear loose clothing, items or accessories that may become tangled in motorcycle parts.

Important

For your safety, always wear suitable protective gear, regardless of season and weather.

Important

Have your passenger wear proper protective clothing.

Safety "Best Practices"

These few simple operations are critical to people safety and to preserving the full performance of your motorcycle. Never forget to perform them before, while and after riding.

Important

Closely follow the indications provided at chapter "Riding the motorcycle" during the running-in period.

Failure to follow these instructions releases Ducati Motor Holding S.p.A. from any liability whatsoever for any engine damage or shorter engine life.

Attention

Before riding your motorcycle, become familiar with the controls you will need to use when riding.

Perform the checks recommended in this manual under "Checks before riding" before each ride.

Attention

Failure to carry out these checks before riding may lead to motorcycle damage and injury to rider and/or passenger.

Attention

Start the engine outdoors or in a well ventilated area. The engine should never be started or run indoors.

Exhaust gases are poisonous and may lead to loss of consciousness or even death within a short time. Use proper body position while riding and ensure your passenger does the same.

Important

Rider must hold the handlebar with both hands at ALL TIMES while riding.

Important

Both rider and passenger should keep their feet on the footpegs when the motorcycle is in motion.

Important

The passenger should always hold on to the grab handles under the seat with both hands.

Important

Be very careful when tackling road junctions, or when riding in areas near exits from private grounds, car parks or on slip roads to access motorways.

Important

Be sure you are clearly visible and do not ride within the blind spot of vehicles ahead.

Important

ALWAYS signal your intention to turn or pull to the next lane in good time using the suitable turn indicators.

Important

Park your motorcycle where no one is likely to knock against it, and use the side stand. Never park on uneven or soft ground, or your motorcycle may fall over.

Important

Visually inspect the tyres at regular intervals for detecting cracks and cuts, especially on the side walls, bulges or large spots that are indicative of internal damage. Replace them if badly damaged. Remove any stones or other foreign bodies caught in the tread.

∧ Attention

Engine, exhaust pipes and silencers stay hot long after the engine is switched off; pay particular attention not to touch the exhaust system with any body part and do not park the vehicle next to flammable material (wood, leaves etc.). Do not cover the motorbike with the canvas, when the engine and exhaust system are hot, to avoid damaging it.

Refuelling

Refuel outdoors with engine off.

Do not smoke or use open flames while refuelling. Be careful not to spill fuel on engine or exhaust pipe. Never completely fill the tank when refuelling. Fuel should never be touching the rim of filler recess. When refuelling, avoid breathing the fuel vapours and prevent fuel from reaching your eyes, skin or clothes

Fuel label

Fuel identification label

lAttention

The motorcycle is only compatible with fuel having a maximum content of ethanol of 10% (E10). Using fuel with ethanol content over 10% is forbidden. Using it could result in severe damage of the engine and motorcycle components. Using fuel with ethanol content over 10% will make the warranty null and void.



Fia 1

Attention

In case of indisposition caused by breathing fuel vapours for a long time, stay in the open air and contact your doctor. In case of contact with eyes, thoroughly flush with water; in case of contact with skin, immediately clean with water and soap.

lAttention

Fuel is highly flammable, in case of accidental spillage of fuel on your clothes it is necessary to change into clean clothes.

Carrying the maximum load allowed

Your motorcycle is designed for long-distance riding, carrying the maximum load allowed in full safety. Even weight distribution is critical to preserving these safety features and avoiding trouble when performing sudden manoeuvres or riding on bumpy roads.

Attention

Do not exceed the total permitted weight for the motorcycle and pay attention to information provided below regarding load capacity.

Information about carrying capacity

Important Arrange your luggage or heavy accessories in the lowest possible position and close to motorcycle centre

Important

Never fix bulky or heavy objects to the handlebar or to the front mudguard as this would affect stability and cause danger.

Important

Be sure to secure the luggage to the supports provided on the motorcycle as firmly as possible. Improperly secured luggage may affect stability.

Important

Do not insert any objects you may need to carry into the gaps of the frame as these may foul moving parts.

Attention

Make sure the tyres are inflated to the proper pressure and that they are in good condition.

Refer to chapter "Technical data", paragraph "Tyres".

Dangerous products - warnings Used engine oil

Attention

Prolonged or repeated contact with used engine oil may cause skin cancer. If working with engine oil on a daily basis, we recommend washing your hands thoroughly with soap immediately afterwards. Keep away from children.

Brake dust

Never clean the brake assembly using compressed air or a dry brush.

Brake fluid

Attention

Spilling brake fluid onto plastic, rubber or painted parts of the motorcycle may cause damages. Protect these parts with a clean shop cloth before proceeding to service the system. Keep away from children

Attention

The fluid used in the brake system is corrosive. In the event of accidental contact with eyes or skin, wash the affected area with abundant running water.

Coolant

Engine coolant contains ethylene glycol, which may ignite under particular conditions, producing invisible flames. Although the flames from burning ethylene glycol are not visible, they are still capable of causing severe burns.

Attention

Take care not to spill engine coolant on the exhaust system or engine parts.

These parts may be hot and ignite the coolant, which will subsequently burn with invisible flames. Coolant (ethylene glycol) is irritant and poisonous when ingested. Keep away from children. Never remove the radiator cap when the engine is hot. The coolant is under pressure and will cause severe burns.


The cooling fan operates automatically: keep hands well clear and make sure your clothing does not snag on the fan.

Battery

Attention
The battery gives off explosive gases; never cause sparks or allow naked flames and cigarettes near the battery. When charging the battery, ensure that the working area is properly ventilated.


Vehicle identification number

Note
These numbers identify the motorcycle model and should always be indicated when ordering spare parts.



Engine identification number


Note
These numbers identify the motorcycle model and should always be indicated when ordering spare parts.



Main components and devices

Position on the vehicle

- 1) Tank filler plug.
- 2) Seat lock.
- 3) Side stand.
- 4) Rear-view mirrors.
- 5) Front fork adjusters.
- 6) Rear shock absorber adjusters.
- 7) Catalytic converter.
- 8) Exhaust silencer.



Tank filler plug

Opening

Lift flap (1) and insert the active or passive key in the lock. Turn the key clockwise by 1/4 of a turn to release the lock

Lift the plug (2).

Closing


Close the plug (2) with the key inserted and push it down into its seat. Remove the key and close flap (1) protecting the lock.




Note
Plug can only be closed when key is inserted.



After refuelling, always make sure that the plug is perfectly in place and closed.






Seat lock

By working on the lock (1), it is possible to remove the seat, to reach the devices placed below it.

Removing the seat


Insert the active or passive key into the catch (1) and turn it clockwise (OPEN) until the rider seat latch disengages with an audible click.


To remove the rider seat (2), pull up the seat rear end and slide it backwards to release retainer (A).



With the seats removed, the connector (5) for the battery maintainer is accessible.

To use it, slide it out from support (C) and connect it to maintainer (6), as described in chapter "Maintaining the battery charge".






Refitting the seats

Fit the seat (2) by sliding it towards motorcycle front end: make sure that seat tab (B) engages into recess (A) on tank.

Push down seat rear end and slide the seat forward until engaging the rear side pin (3) in hole (4) by pressing down until latch clicks in place.

Make sure the seat is properly fastened by moderately pulling it up.

Take key out of the lock.




Maintaining the battery charge


Your motorcycle is equipped with a connector (1) to which you can connect a special battery charger (2) (Battery maintainer kit part no. 69924601A - various countries: Battery maintainer kit part no. 69924601AX - for Japan, China and Australia only) available from our sales network.

Note
The electric system of this model is designed so as to ensure there is a very low power drain when the motorcycle is OFF. Nevertheless, the battery features a certain self-discharge rate that is normal and depends on ambient conditions as well as on "non-use" time

Important

If battery is not kept at a minimum charge level by a suitable battery charge maintainer, sulphation may occur and this is an irreversible phenomenon causing decreasing battery performance.





Note
When the motorcycle is left unused (approximately for more than 30 days). We recommend owners to use the Ducati battery charge maintainer (Battery maintainer kit part no. 69924601A - various countries: Battery maintainer kit part no. 69924601AX - for Japan, China and Australia only) since its electronics monitors the battery voltage and features a maximum charge current of 1.5 Ah. Connect the maintainer to the diagnostics socket located in the rear side of the motorcycle.

Note

Using charge maintainers not approved by Ducati could damage the electric system; motorcycle warranty does not cover the battery if damaged due to failure to comply with the above indications, since it is considered as wrong maintenance.

Side stand

Important


Place the motorcycle on the side stand only when you are not going to use it for short periods of time. Before lowering the side stand, make sure that the bearing surface is hard and flat.

Do not park on soft or pebbled ground or on asphalt melted by the sun, etc. or else the motorcycle may fall over. When parking downhill, always position the motorcycle with the rear wheel facing downhill. To pull down the side stand, hold the motorcycle handlebars with both hands and push down on the side stand (1) with your foot until it is fully extended. Tilt the motorcycle until the side stand is resting on the ground.

To move the side stand to its rest position (horizontal position), lean the motorcycle to the right while lifting the thrust arm (1) with your foot.

To ensure trouble-free operation of the side stand

joint, thoroughly clean it and then use SHELL Alvania R3 grease to lubricate all friction points.



Attention

Do not sit on the motorcycle when it is supported on the side stand.

Note Check for proper operation of the stand mechanism (two springs, one into the other) and the safety sensor (2) at regular intervals.

Note
The engine can be started with the side stand down and the gearbox in neutral. If starting with a gear engaged, pull in the clutch lever (in this case the side stand must be up).


Passenger grab handle


Passenger grab handle (1) is located inside the tail guard; to take it out, remove the seat (see "Removing the seat"), pull knob (2) while taking out the grab handle (1) from its housing until it is fully extended.

Attention

Before use, pull grab handle back and forth to ensure that it is locked in the correct position.

To put it back, pull knob (2), push grab handle (1) in its housing until it is completely flush with the tail guard and refit the seat (see "Refitting the seat").





Bluetooth control unit

The Bluetooth control unit (if equipped) works as a hub between the various supported electronic devices relying on a Bluetooth communication interface.

Attention

Smartphone and Bluetooth Headset device manufacturers may incorporate certain changes within the standard protocols over the course of the lifecycle of the device (Smartphones and Earphones).

Attention

These changes are outside the control of Ducati and may result in Bluetooth Headset devices functionality becoming impaired (sharing Music, multimedia player, etc.) and may equally affect some types of Smartphones (depending on supported Bluetooth profiles). This is why Ducati cannot guarantee multimedia player proper operation for:

- any earphones not coming with the "Ducati Kit part no. 981029498";
- any Smartphones not supporting the required Bluetooth profiles (even though paired to earphones coming with the "Ducati Kit part no. 981029498").

Attention

In case of interference or noise due to particular conditions of the external environment, the Ducati earphone kit part no. 981029498 also allows sharing the music being played directly from rider helmet to passenger helmet (for further details please refer to the manual of the earphones coming with the Ducati kit part no. 981029498).

○ Note

The Ducati kit part no. 981029498 can be purchased separately at a Ducati Dealer or Authorised Service Centre.

Check that your Smartphone supports the following profiles:

- MAP profile: for a correct display of SMS and MMS notifications;
- PBAP profile: for a correct display of the Smartphone contact list.

Attention

Ducati does not ensure a correct connection to the Ducati Multimedia System of Bluetooth navigators that are not provided in the following kits:

- Kit of Ducati Zumo satellite navigator 350
- Kit of Ducati Zumo satellite navigator 390
- Kit of Ducati Zumo satellite navigator 395

Note

The Ducati kits mentioned above can be purchased separately at a Ducati Dealer or Authorised Service Centre.

Front fork adjusters

Front fork adjuster (DIAVEL 1260)

The front fork used on this motorcycle has rebound (return), compression and spring preload adjustment.

It is possible to adjust the spring preload and compression on the left leg whereas the rebound can only be adjusted on the right leg.

Adjustment is done by external screw adjusters:


- 1) for rebound adjustment;
- 2) to adjust the preload of the inner springs;
- 3) to adjust the compression damping.

Position the motorcycle on its side stand so that it is stable.

Turn the adjuster (1) at the top end of the RH fork leg with a suitable screwdriver to adjust rebound damping.

Turn adjuster (3) at the top end of the LH fork leg with a screwdriver to adjust compression.

By turning adjuster screws (1) and (3) you will hear some clicks; each click corresponds to a damping setting.



The stiffest damping setting is obtained with the adjuster turned fully clockwise to the "0" (fully closed) position.

Starting from this position, by turning it counter clockwise, count the "opening" turns corresponding to the decreasing of damping.

To change internal spring preload turn adjuster (2) with a 17 mm (0.67 in) hexagon wrench, completely counter clockwise, to obtain fully uncompressed position.

From this position, adjust the spring preload by turning the adjuster clockwise. Every turn corresponds to 1 mm (0.04 in) of spring preload.

STANDARD settings are as follows:

- compression (LH leg): 2 turns (from fully closed);
- rebound (RH leg): 2 turns (from fully closed);
- spring preload: +5 turns (from fully unloaded).

Calibration for RIDING WITH PASSENGER AND AT FULL LOAD:

- compression (LH leg): 1.5 turns (from fully closed);
- rebound (RH leg): 1.5 turns (from fully closed);
- spring preload: +10 turns (from fully unloaded).



Adjust both fork legs to same settings.

Front fork adjuster (DIAVEL 1260 S)

The front fork used on this motorcycle has rebound (return), compression and spring preload adjustment.

It is possible to adjust the spring preload on both legs whereas compression and rebound can only be adjusted on the LH and RH legs, respectively.

Adjustment is done by external screw adjusters:

- 1) to adjust the hydraulic damping in rebound;
- 2) to adjust internal spring preload;
- 3) to adjust the compression damping.


Position the motorcycle on its side stand so that it is stable

Turn adjuster (1) at the top end of the RH fork leg with a suitable hexagon wrench to adjust rebound damping.

Turn adjuster (3) at the top end of the LH fork leg with a suitable hexagon wrench to adjust compression damping.

By turning adjuster screws (1) and (3) you will hear some clicks; each click corresponds to a damping setting.

The stiffest damping setting is obtained with the adjuster turned fully clockwise to the "O" (fully



closed) position. By turning counter clockwise starting from this position, count the clicks that will correspond to positions "1", "2" etc.

To change preload of the spring inside each fork leg, turn adjuster, with a 17 mm (0.67 in) hexagon wrench, completely counter clockwise, to obtain fully open position. From this position, adjust the spring preload by turning the adjuster clockwise. Every turn corresponds to 1 mm (0.04 in) of spring preload.

STANDARD settings are as follows: - compression: - rebound: ; - spring preload: .

- compression (LH leg): -17 clicks (from fully closed position);
- rebound (RH leg): -12 clicks (from fully closed position);
- spring preload: 4 turns (4 mm) (0.16 in) from fully open, for each one of the two adjustments (2) (RH and LH).

Calibration for RIDING WITH PASSENGER AND AT FULL LOAD:

- compression (LH leg): 12 clicks (from fully closed position);
- rebound (RH leg): 8 clicks (from fully closed position);
- spring preload: +10 turns (from fully unloaded).



Attention

Adjust both fork legs to same settings.

Rear shock absorber adjusters

Rear shock absorber adjuster (DIAVEL 1260)

The rear shock absorber has adjusters that enable you to suit the setting to the load on the motorcycle. Adjuster (1) adjusts the damping during the rebound phase (return).

STANDARD setting from the fully closed position (clockwise):

turn adjuster (1) clockwise to stiffen the damping, or counter clockwise to soften it.


The two ring nuts (2), located in the shock absorber upper side, adjust the external spring preload.

To change spring preload, slacken the upper locking ring nut.

Then TIGHTEN or SLACKEN the lower ring nut to INCREASE or DECREASE spring preload.

STANDARD setting from the fully closed position (clockwise):

- rebound: loosen adjuster (1) by 8 positions from fully closed;
- spring preload: 19 mm (0.75 in) from Min. (fully uncompressed, factory adjustment).



Calibration of RIDING WITH PASSENGER AND AT FULL LOAD:

- rebound:, loosen by 4 positions from fully closed:
- spring preload: MAX (fully screwed ring nut) + 10 mm (0.39 in) compared to standard preload calibration of 29 mm (1.14 in).

Attention

To turn the preload adjuster ring nut use a pin wrench. Pay attention to avoid hand injuries by hitting motorcycle parts in case the wrench tooth suddenly slips on the ring nut groove while moving it.

Attention
The shock absorber is filled with gas and oil under high pressure and may cause severe damage if taken apart by unskilled persons.

Attention

The shock absorber is filled with gas under pressure and may cause severe damage if taken apart by unskilled persons.

When carrying a passenger and luggage, set the rear shock absorber spring to maximum preload, i.e. until mechanical retainer on shock absorber, to improve motorcycle handling and keep safe clearance from the ground.

Adjust also the rebound adjuster screwing it to the desired value

Recommended value: screw by 4 clicks/positions from the factory value, i.e. loosen by 4 clicks/ positions starting from the fully closed position.

Rear shock absorber adjuster (DIAVEL 1260 S)

The rear shock absorber has adjusters that enable you to suit the setting to the load on the motorcycle. Adjuster (1) located on the expansion reservoir adjusts the hydraulic damping during the compression phase


The adjuster (3), located on the lower mount which fastens the shock absorber to the swinging arm, adjusts the hydraulic damping during the rebound phase (return).

Turn adjusters (1) or (3) clockwise to stiffen the damping, or counter clockwise to soften it. The two ring nuts (2), located in the shock absorber upper side, adjust the external spring preload. To change spring preload, slacken the upper locking ring nut.

Then TIGHTEN or SLACKEN the lower ring nut to INCREASE or DECREASE spring preload.

STANDARD setting from the fully closed position (clockwise):

- rebound: loosen adjuster (3) by 12 clicks from fully closed;
- compression: loosen adjuster (1) by 12 clicks from fully closed;



 spring preload: 19±5 mm (0.75± 0.2 in) from fully uncompressed spring.

Calibration of RIDING WITH PASSENGER AND AT FULL LOAD (recommended values)

When carrying a passenger and luggage, set the rear shock absorber spring to maximum preload, set both rebound and compression damping adjusters to improve motorcycle handling and keep safe clearance from the ground:

- rebound: loosen by 6 clicks from fully closed;
- compression: loosen by 6 clicks from fully closed;

Rear shock absorber maximum adjustment range

- rebound: 30 clicks from fully closed;
- compression: 20 clicks from fully closed.

Attention
To turn the preload adjuster ring nut use a pin wrench. Pay attention to avoid hand injuries by hitting motorcycle parts in case the wrench tooth suddenly slips on the ring nut groove while moving it.

Attention

The shock absorber is filled with gas and oil under high pressure and may cause severe damage if taken apart by unskilled persons.

Controls


Position of motorcycle controls

Attention
This section shows the position and function of the controls used to ride the motorcycle. Be sure to read this information carefully before you use the


- 1) Instrument panel on handlebar.
- 2) "Hands free" system.
- 3) Left-hand switch.
- 4) Clutch lever.

controls

- 5) Rear brake pedal.
- 6) Right-hand switch.
- 7) Throttle twistgrip.
- 8) Front brake lever.
- 9) Gear change pedal.



Switchgears



1	Û	Control button up
2	4	Control button down
3	MODE ● ENTER ○	Button for Riding Mode change and ENTER function
4	+ RES	Cruise control RES/+
5	SET -	Cruise control SET/-
6	ON OFF	Cruise control ON/OFF
7		Hazard lights (red)
8	令⇔ OFF	 3-position turn indicator control: position (8a), left turn indicator centre position, OFF position (8b), right turn indicator
9	Þ	Warning horn
10	≣ D ∄ D ≣ D	Light selector: high beam, pushed up low beam, at the centre high-beam flasher and "Start/Stop Lap" function, pushed down
11	:: :: D	DRL (if present)


12	DPL	Assisted start (DPL - Ducati Power Launch)
13	A	Electronic steering lock
14	(\$)	Engine start
15	Ø	Engine kill, pushed down (red)

Light control

Low/high beam (version without DRL)

At Key-On, the high beam and low beam lights are OFF: only the parking lights are turned on. Once the engine is started, the low beam is automatically turned on; it is possible to switch from low beam to high beam and vice versa by pressing button (3) in positions (A) and (B). If engine is not started upon key-on, it is anyway possible to switch high/low beams on by pushing button (3) position (C) on I. H. switch

If within 60 seconds from the "manual" switching on of the low / high beam the engine is not started, the lights are disabled again (off).




Low/high beam (version with DRL)

At Key-On, the high beam and low beam lights are OFF: only the parking lights and the DRL light are turned on.

After starting the engine the high beam is automatically turned on if the AUTO mode is set and the instrument panel detects poor ambient light (NIGHT): if, on the other hand, the instrument panel detects good light conditions (DAY), the DRL light remains on and the low beam remains off; it is possible to switch the DRL light to low beam (and vice versa) with button (9).

It the low beam is activated, it is possible to switch on the high beam with button (3), position (A). If engine is not started upon key-on, it is anyway possible to switch high/low beams on by pushing button (3) position (C) on LH switch.

If within 60 seconds from the "manual" switching on of the low / high beam the engine is not started, the lights are disabled again (off).



High/low beam switching off during vehicle start (version without DRL light).

To preserve the motorcycle battery, if when starting the engine the high/low beams are ON, the headlight is automatically switched off and then on again when the engine is started.

High/low beam switching off during vehicle start (version with DRL lights).

To preserve the motorcycle battery, if when starting the engine the high/low beams or the DRL lights are ON, the headlight is automatically switched off and then on again when the engine is started.


DRL (Daytime Running Light) — only for version with DRL lights


Upon each Key-On, the DRL lights are turned on. It is possible to switch off the DRL lights by means of button (9) on the left-hand switch. By pressing button (9) again, the DRL lights are switched on again.

○ Note

Every time button (9) is pressed, the DRL light automatically switches to MANUAL mode. To go back to the AUTO mode, turn the Key Off and On or set the AUTO mode by means of the DRL CONTROL function in the Setting Menu.

By pressing button (3), the high and low beams are turned on whereas the DRL light is turned off. Upon releasing the light button (3), the DRL light is automatically switched on again.





DRI in AUTO mode

If the DRL is in this mode, when starting the engine it automatically switches off and the low beam is activated if the instrument panel detects poor light conditions (NIGHT). If the instrument panel detects good light conditions (DAY), the DRL remains on and the low beam off: in this mode, the instrument panel automatically switches from the DRL light to the low beam and vice versa, according to the detected ambient light conditions. The display shows the green logo with letter A.

Attention

Using the DRL light in AUTO (automatic) mode in case of poor light conditions, especially in case of fog or clouds, could impair safety: in this case DUCATI recommends to manually activate the low beam.

DRL in MANUAL mode

If the DRL light is in this mode, it does not change status when starting the engine. To switch on or off the DRL light it is necessary to press button (9). The display shows the vellow logo with letter M.

Attention
Using the DRL light in poor light conditions (dark) could compromise the riding visibility and dazzle who is coming on the opposite lane.

Note

Using the DRL light during the day improves visibility as it is easier to perceive by those coming on the opposite side compared with the low beam.

Turn indicators

To activate the left turn indicators, press button (10) in position (I); to activate the right turn indicators, press button (10) in position (L).

Turn indicators can be cancelled by pressing button (10) on LH switch.


Automatic switch-off

The turn indicators switch off automatically after the turn, as calculated based on vehicle speed, lean angle and in general according to the analysis of vehicle dynamic conditions.

This means that automatic switch-off is triggered when vehicle speed exceeds 20 km/h (12.4 mph) after the turn indicator button was pressed.

Turn indicators also switch off automatically if they remained on for a long mileage (which can range between 200 and 2000 metres (656-6562 feet), depending on vehicle speed when the turn indicator button was pressed).

If the turn indicator switch is again operated, while turn indicator is still on, automatic switch-off feature is re-initialised.




Attention

The automatic deactivation systems are assist systems helping the rider control the turn indicators in the most comfortable and easy way. Such systems have been designed to work in most riding manoeuvres, nonetheless the rider must pay attention to the turn indicator operation (disabling or enabling them by hand if needed).

Hazard function (4 turn indicators)

The "Hazard" function turns all four turn indicators on at the same time to signal an emergency condition. Push button (11) to activate the "Hazard" function. It can only be activated when vehicle is turned on (Key-ON). When the "Hazard" function is active, all four turn indicators blink at the same time as well as warning lights on the instrument panel. The "Hazard" function can be manually turned off exclusively when vehicle is on (Key-ON), by pressing button (11).





Once the "Hazard" function is activated, if vehicle is turned off (key turned to "OFF"), the function stays active for 2 hours. After 2 hours, the turn indicators switch OFF automatically in order to save battery charge.

Note

When turning the vehicle key ON with "Hazard" function still active, the function remains active.

Note If there is a sudden interruption in the battery


while the function is active, the instrument panel will disable the function when the voltage is restored.

Note
The "Hazard" function has higher priority compared to normal operation of the single turn indicators, this means that, as long as it is active, it will not be possible to activate the single right or left turn indicators.

"Hands free" system

The Hands free system consists of:

- 1) Hands free unit;
- 2) Antenna;
- 3) Active key;
- 4) Passive key; 5) Electric plug (Optional).




Important


Conditions affecting the correct operation of the Hands Free system.

The wireless key operation could be impaired in the following situations.

- Near a TV tower, radio station, electric power plant, airport, gas station or other facility that generates strong radio waves.
- When carrying a portable radio, cellular phone or another wireless communication device.
- When multiple wireless keys are nearby.
- When a wireless key comes into contact with or is covered by a metallic object.
- When a wireless key (that emits radio waves) is being used nearby.
- When a wireless key is left near an electrical appliance such as a Personal Computer.

The Hands Free unit (1) is located in front of the tank. Antenna (2) is positioned under the headlight fairing (7).





Hands free system "Key-On" and "Key-Off"


Key-On consists in turning on the hands free system and all electronic devices


Key-On is done using button (6) on the right switch on the handlebar or using the hands free button (1) on the Hands free lock

Key-Off consists in turning off the hands free system and all electronic devices, and ensures engine is turned off.

Key-Off is done using button (6) on the right switch on the handlebar or using button (1) on the Hands free lock

Note
The use of one of the two buttons, (6) on handlebar or on Hands free unit (1), does not exclude the other: if you use one for switch-on, you can switch off with the other and vice versa.





Key-On can only occur in the presence of one of the two active (3) or passive (4) keys or using the pin code.


Key-Off can also occur without any active (3) or passive (4) key.


Key-Off occurs when the speed of the motorcycle is equal to zero, by pressing button (6) on the handlebar or by pressing the Hands free unit button (1). When speed is not equal to zero, perform key-off by pressing the Hands free unit button (1).

Important

If active key battery is flat, the key works as a passive key so its range is reduced to a few inches (cm) from antenna (2).


Instrument panel shows when battery is flat. If active key battery is flat, the key can still be used as a passive key.






Recovery mode for Key-On with passive key and/or active key with flat battery.

The active key (3) with flat battery and the passive key (4) have a range of action of a few inches (cm), therefore it is necessary to position one of the two keys very close and in correspondence of the symbol (X) of the hands free key on the headlight fairing (7); this symbol, on the headlight fairing (7), above the headlight at the front of the bike, indicates the presence of antenna (2, Fig 32)under the headlight fairing (7).







If when performing the described procedure you have a negative outcome, and both the active (3) and passive (4) keys are nor detected by the Hands free system, proceed as follows.

Remove the headlight fairing (7) and place the active (3) or passive (4) key on the symbol (Y) of the Hands free key printed on the plate (8) that supports the headlight fairing (7).

Important


After performing the key-on in passive mode, you have 15 seconds to start the engine; otherwise, an automatic key-off is possible as soon as the key is moved away from symbol (X) of the Hands free key placed on the headlight fairing (7).





The mechanical part (A) of the key (3) is used to open the fuel filler cap, the seat latch and bag locks. The metal part (A) of the key (3) remains hidden inside its housing, you can take it out by pressing button (B).

Note
With the vehicle in "Key-On" and "engine off" condition, if the presence of the active key (3) is not detected for fifteen consecutive seconds, the motorcycle will turn off automatically without any action by the rider.




Key-On/Key-Off with the active key using the button on the handlebar


Key-On can be performed by pressing button (6) on the handlebar and with the presence of the active key (3).

Note

In case of active key (3) with flat battery, refer to paragraph "Recovery mode for Key-On with passive key and/or active key with flat battery".

Key-Off can be performed by pressing the button (6) on the handlebar. It can also be performed without the active key (3) only if motorcycle speed is equal to zero.






Key-On/Key-Off using the button on the Hands free lock with the active key


Key-On can be performed by pressing button (1) on the Hands free unit and with the presence of the active key (3).

Key-Off can be performed by pressing button (1) on the Hands free unit and also without the key (3).

○ Note

In case of active key (3) with flat battery, refer to paragraph "Recovery mode for Key-On with passive key and/or active key with flat battery".






Key-On/Key-Off using the button on the handlebar with the passive key

Key-On can be performed by pressing the grey button (6) on the handlebar and with the presence of the passive key (4).

Note
In case of key-On with passive key (4) refer to paragraph "Recovery mode for Key-On with passive key and/or active key with flat battery".

Key-Off can be performed by pressing the grey button (6) on the handlebar. It can also be performed without the key (4) only if motorcycle speed is equal to zero




Key-On/Key-Off using the button on the Hands free lock with the passive key


Key-On can be performed by pressing button (1) on the Hands free unit and with the presence of the passive key (4).

Note

Passive key (4) must be positioned very close and in correspondence of symbol (X) of the Hands free key, placed near the antenna (2) under the headlight fairing (7).

Key-Off can be performed by pressing button (1) on the Hands free unit and also without the key (4).





Key-On/Key-Off using the pin code (immobilizer override)

Key-On can be performed by pressing button (1) on the hands free unit without the presence of the active (3) and passive (4) keys and entering the pin code on the instrument panel.

Key-Off can be performed by pressing button (6) on the handlebar.


After each Key-Off, if the key is not present upon next Key-On, the pin code must be entered. The pin code is set by the customer upon delivery of the motorcycle.


The function is not enabled unless a pin code has been set.

When the Hands Free button (1) is pressed, the instrument panel activates the backlighting and the round display to allow the rider to enter the four-digit pin code.

Entering the correct pin turns on the instrument panel and enables engine starting.

Pin code must be entered within 120 seconds, after which a Key-Off occurs automatically.





Entering PIN CODE function for overriding purposes


This function allows the rider to "temporarily" turn on the motorcycle in case of HF (Hands Free) system "malfunction".

If the motorcycle cannot be turned on using the normal starter button, press the Hands Free button (1) to activate the function.

After pressing the button, the instrument panel activates the page for entering the override code. Refer to the "Restoring motorcycle operation via the PIN CODE" procedure.

Important

If this procedure is necessary in order to start the motorcycle, contact an Authorised Ducati Service Centre as soon as possible to fix the problem.



Keys


The Owner receives a set of keys comprising:


- 1 active key (1);
- 1 passive key (2).

They contain the code used by the "Hands free" system for the Key-On, in different modes.

The active key (1) is the one that is normally used and has a button (A) that, when pressed, makes the metal part exit (B).

The metal part returns inside the grip by pushing it in.





The active key contains a battery (3) that must be replaced when the message "low level" is displayed under the key and battery symbols when the instrument panel is turned on.

Note

In this case, replace the battery as soon as possible.


When the charge level goes below a certain limit, the key can only work in passive mode, like the passive key: in this case, the instrument panel will not display any message.


Attention

Do not ride with the (active or passive) key inserted in the lock of the tank cap or in the seat lock as it could come out and represent a potential danger. Furthermore, if bumped, the key mechanism and the integrated circuit could be damaged.

Also riding in poor weather conditions with the key inserted could cause damage to its integrated circuit.

Do not leave the key on the motorcycle when washing it as it could be damaged, not being watertight.





Replacing the battery

Attention

Symbol (A) indicates to pay attention when removing the key battery


Attention

Danger of explosion in case of battery improper replacement. For replacement, use only the same or an equivalent type of battery.

Attention
Do not expose the key to high temperatures, such as on the instrument panel, and under direct sunlight.

Attention
This symbol (B) warns the user about important use and maintenance instructions contained inside the documents provided with the equipment.

Note
The keys do not need to be reprogrammed after replacing the battery.



Remove the rear plastic shell (1) of the grip by pushing it forward and lifting it as shown in the figure.

After separating the plastic shells, using a coin of appropriate size applied to the slot (2) on the battery (3), turn it clockwise for removal (as indicated by the "OPEN" indication on the battery).

Remove battery (3) and install a new one.



Attention

Do not swallow the battery, danger of chemical hurn

This product contains a button battery. Should the button battery be swallowed, it could cause severe internal burns and lead to death in just 2 hours. If battery swallowing, i.e. its positioning inside any part of your body, is suspected, seek for immediate medical advice.






Fig 57



Insert the new battery (3) into the battery compartment with the slot (2) facing upwards. Using a coin of appropriate size applied to the slot (2), rotate the battery (3) anticlockwise to fix it (as indicated by the "CLOSE" indication on the battery).




Important
Only use the required type of battery.




Reinstall the rear plastic shell (1) and push it slightly as shown in the figure.

Insert tab (D) inside its seat.

Make sure shell closes properly and that the key is well closed.





Immobilizer system

To further improve the anti-theft protection, the motorcycle is equipped with an engine electronic block system (IMMOBILIZER) that is automatically activated every time the instrument panel is switched off.

The grip of each ignition key contains an electronic device that modulates the output signal from a special antenna in the headlight fairing when the ignition is switched On. The modulated signal is the "password", different upon every Key-On, used by the control unit to acknowledge the key. Engine can be started only after key acknowledgement.

Duplicate keys

When a customer needs spare keys, he/she shall contact a Ducati authorised service centre and bring all keys he/she still has.

The Ducati authorised service centre will program all new and old keys.

The Ducati authorised service centre may ask to the customer to prove to be the motorcycle owner.

The codes of the keys missing during the programming procedure will be erased to ensure that any lost key can not start the engine.

Restoring motorcycle operation via the PIN code


In case of key acknowledgement system or key malfunction, the instrument panel allows the user to enter his/her own PIN code to temporarily restore motorcycle operation.

If the PIN CODE function is active, the instrument panel shows the message "INSER PIN" and four zeros ("0") to enter the release PIN CODE.

Entering the code:

- Press button (4), only one digit indicating "0" is highlighted;
- each time you press the button (2) the displayed number increases by one (+ 1) up to "9" and then starts back from "0";
- each time you press the button (1) the displayed number decreases by one (-1) up to "1" and then starts back from "0":
- 4) to confirm the number, press the button (4).

Repeat the procedures until you confirm all the four digits of the PIN CODE. $\label{eq:confirm}$





When you press button (4) to confirm the fourth and last digit:

- if the PIN code is not correct, the instrument panel displays PIN CODE WRONG for three seconds and then highlights the string of four zeros ("0") to allow you to try again. The number of possible attempts is determined by a preset time-out of two minutes.
- if the PIN CODE is correct, the instrument panel shows PIN CODE CORRECT for three seconds, and then displays the "standard screen".

Important

If this procedure is necessary in order to start the motorcycle, contact an Authorised Ducati Service Centre as soon as possible to fix the problem.





Clutch lever

Lever (1) disengages the clutch. It features a dial adjuster (2) for lever distance from the twistgrip on handlebar. The lever distance can be adjusted through 10 clicks of the dial (2). Turn clockwise to increase lever distance from the twistgrip. Turn the adjuster counter clockwise to decrease lever distance. When the clutch lever (1) is operated, drive from the engine to the gearbox and the drive wheel is disengaged. Using the clutch properly is essential to smooth riding, especially when moving OFF.




Attention
Set clutch lever when motorcycle is stopped.

✓ Important Using the clutch properly will avoid damage to transmission parts and spare the engine.


Note

The engine can be started with the side stand down and the gearbox in neutral. If starting with a gear engaged, pull in the clutch lever (in this case the side stand must be up before engaging the gear).



Throttle twistgrip

The twistgrip (1) on the right handlebar opens the throttles. When released, it will spring back to the initial position (idling speed).




Front brake lever

Pull in the lever (1) towards the twistgrip to operate the front brake. The system is hydraulically operated and you just need to pull the lever gently.

The brake lever (1) has a dial (2) for adjusting the distance between lever and twistgrip on the handlebar.

The lever distance can be adjusted through 10 clicks of the dial (2).


Turn clockwise to increase lever distance from the twistgrip. Turn the adjuster counter clockwise to decrease lever distance.



Rear brake pedal

Press pedal (1) down with your foot to operate the rear brake.

The control system is of the hydraulic type.




Gear change pedal

When released, the gear change pedal automatically returns to rest position N in the centre. This is indicated by the instrument panel light N coming on. The pedal can be moved:


- down = press down the pedal to engage the 1st gear and to shift down. The N light on the instrument panel will go out;
- upwards= lift the pedal to engage 2nd gear and then 3rd, 4th, 5th and 6th gears.


Each time you move the pedal you will engage the next gear.



Adjusting the position of the gearchange pedal and rear brake pedal

Note
Gear change pedal position can be adjusted with respect to the motorcycle: please contact a Dealer or Ducati authorised service centre to have this adjustment performed.





Riding the motorcycle

Running-in recommendations

Maximum rotation speed

Rotation speed for running-in period and during standard use (rpm):

- 1) Up to 621 mi (1000 km);
- 2) From 1000 km (621 mi) to 2500 km (1553 mi).

Up to 1,000 Km (621 mi)

During the first 1000 km (621 mi), keep an eye on the rev counter. It should never exceed: 5,500÷6,000 rpm.

During the first hours of riding, it is advisable to run the engine at varying load and rpm, though still within recommended limit.

To this end, roads with plenty of bends and even slightly hilly areas are ideal for a most efficient running-in of engine, brakes and suspensions. For the first 100 km (61 mi) use the brakes gently. Avoid sudden or prolonged braking. This will allow the friction material on the brake pads to bed in against the brake discs.

So that the mechanical parts of the motorcycle can adapt to each another, and especially so the life of the basic engine parts is not affected, avoid harsh accelerations and do not run the engine at a high rpm for an extended time, especially uphill. We further recommend to check the drive chain often.

Pre-ride checks

Attention
Failure to carry out these checks before riding,

may lead to motorcycle damage and injury to rider and passenger.

Before riding, perform a thorough check-up on your motorcycle as follows:

- FUEL LEVEL IN THE TANK
 Check the fuel level in the tank. Refuel, if necessary ("Refuelling").
- ENGINE OIL LEVEL
 Check oil level in the sump through the sight glass. Top up if necessary ("Engine oil level check").
- BRAKE AND CLUTCH FLUID
 Check liquid level in the corresponding reservoirs (see "Checking brake and clutch fluid level").
- COOLANT
 Check the level of coolant in the expansion reservoir; top up if necessary ("Checking and topping up the coolant level").
- TYRE CONDITION Check tyre pressure and condition ("Tyres").

CONTROLS

Work the brake, clutch, throttle and gear change controls (levers, pedals and twistgrip) and check for proper operation.

- LIGHTS AND INDICATORS
 - Make sure lights, indicators and horn work properly. In case of light malfunction, contact a Ducati Dealer or Authorised Service Centre.
- KEY LOCKS
 Check the tightening of the filler plug ("Filler plug") and of the seat ("Seat lock").
- STAND

Make sure side stand operates smoothly and is in the correct position ("Side stand").

ABS light

After Key-ON, the ABS light stays ON. When the motorcycle speed exceeds 5 km/h (3.12 mph), the warning light switches OFF to confirm the correct operation of the ABS system.

Attention In case of malfunction, do not ride the

In case of malfunction, do not ride the motorcycle and contact a Ducati Dealer or authorised Service Centre.

ABS device


Check that the front (1) and rear (2) phonic wheels are clean.


▲ Attention

Clogged reading slots would compromise system proper operation. It is recommended to disable ABS system in case of muddy road surface because under this condition the system might be subject to sudden failure.

Attention

Prolonged wheelies could deactivate the ABS system.





Engine start/stop


Attention

Before starting the engine, become familiar with the controls you will need to use when riding.

Attention

Never start or run the engine indoors. Exhaust gases are poisonous and may lead to loss of consciousness or even death within a short time.

In the presence of the active or passive key, perform a Key-On (turning on the "Hands free" system and all on-board electronic devices) by taking the red switch (1), on the right side of the handlebar, upward and pressing button (2). The instrument panel will perform the initialisation and will control the onboard systems, turning on all lights in sequence, from the bottom to the top, for a few seconds. After this control, only the green light (3) and the red light (4) must remain on.





Attention


The side stand must be fully up (in a horizontal position) as its safety sensor prevents engine starting when down.

After Key-On, but with the engine not yet started, the system will perform a Key-Off automatically if the presence of the active key is not detected within 10 seconds.

○ Note

It is possible to start the engine with side stand down and the gearbox in neutral. When starting the motorcycle with a gear engaged, pull the clutch lever (in this case the side stand must be up).

Move the red switch (1) up to uncover button (5). Push the button (5) to start the engine.




Important
Do not rev up the engine when it is cold. Allow some time for oil to be heated and reach all points that need lubricating.

∧ Attention

Keeping the engine running for too long with the vehicle stationary can cause damage because of overheating due to insufficient cooling. Do not keep the engine on unnecessarily while the vehicle is stationary. Move off with the motorcycle immediately after starting the engine.

The red oil pressure warning light (4, Fig 75) should go out a few seconds after the engine has started. The engine will shut off by turning the red button (1) on the handlebar to RUN OFF. To turn on the "Hands free" system and all electronic onboard systems, refer to "Hands Free System" Chapter.





Important
Conditions affecting the correct operation of the Hands Free system.

The wireless control operation could be impaired in the following situations.

- Near a TV tower, radio station, electric power plant, airport, gas station or other facility that generates strong radio waves.
- When carrying a portable radio, cellular phone or another wireless communication device
- When multiple wireless keys are nearby.
- When a wireless key comes into contact with or is covered by a metallic object.
- When a wireless key (that emits radio waves) is being used nearby.
- When a wireless key is left near an electrical appliance such as a Personal Computer.

Hands Free unit (7) position. Antenna (6) position.





Moving off

- 1) Lift the side stand until it is horizontal.
- 2) Squeeze the control lever to disengage the clutch.
- 3) Push down on gear change lever sharply with the tip of your foot to engage the first gear.
- Speed up the engine by turning the throttle twistgrip while gradually releasing the clutch lever; the motorcycle will start moving off.
- 5) Let go of clutch lever and speed up.
- 6) To shift up, close the throttle to slow down engine, disengage the clutch, lift the gear change lever and let go of clutch lever. To shift down, proceed as follows: release the twistgrip, pull the clutch lever, shortly speed up to help gears synchronise, shift down (engage next lower gear) and release the clutch.

The controls should be used correctly and timely: when riding uphill do not hesitate to shift down as soon as the motorcycle tends to slow down, so you will avoid stressing the engine and the motorcycle abnormally.

▲ Attention

Avoid harsh acceleration, as this may lead to misfiring and transmission snatching. The clutch lever should not be held in longer than necessary after a gear is engaged, otherwise friction parts may overheat and wear out.

Attention

Prolonged wheelies could deactivate the ABS system.

Braking

Slow down in time, shift down to use engine brake and then brake by operating both front and rear brakes. Pull the clutch before the motorcycle stops to avoid engine from suddenly stalling.

Anti-Lock Braking System (ABS)

Using the brakes correctly under adverse conditions is the hardest – and yet the most critical – skill to master for a rider. Braking is one of the most difficult and dangerous moments when riding a two wheeled motorcycle: the possibility of falling or having an accident during this difficult moment is statistically higher than any other moment. A locked front wheel leads to loss of traction and stability, resulting in loss of control.

The Anti-Lock Braking System (ABS) has been developed to enable riders to use the motorcycle braking force to the fullest possible amount in emergency braking or under poor pavement or adverse weather conditions.

ABS is an electro-hydraulic device that controls the pressure in the brake circuit when the control unit, by processing information from wheel sensors, determines that one or both wheels are about to lock up. In this case, pressure decrease in the brake circuit allows the wheel to carry on turning, thereby preserving grip.

After that, the control unit restores the pressure in the brake circuit, to resume the braking action. This cycle is repeated many times until the problem is completely eliminated.

Normally, the rider will perceive ABS operation as a harder feel or a pulsation of the brake lever and pedal. The front and rear brakes use separate control systems.

The Diavel ABS also features a "cornering" function that widens ABS functionality to the conditions where the motorcycle is leaning over, thus controlling the front and rear brake systems depending on the vehicle lean angle with the purpose of preventing wheel lockup and slipping as much as possible, within the physical limits allowed by the vehicle and by the road conditions. If desired, the system can be deactivated from the instrument panel, setting the level to OFF within the Riding Mode for which you wish to disable it.

Attention
Using the two brake controls separately reduces the motorcycle braking power. Never use the front brake control harshly or suddenly as you may cause rear wheel lift-up and lose control of the motorcycle (if the ABS is enabled). When riding in the rain or on slippery surfaces, braking will become less effective. Always use the brakes very gently and carefully when riding under these conditions. Any sudden manoeuvres may lead to loss of control


When tackling long, high-gradient downhill road tracts, shift down gears to use engine braking. Apply one brake at a time and use brakes sparingly. Keeping the brakes applied all the time would cause the friction material to overheat as well as a possible generation of vapour lock (brake fluid boiling) with a considerable reduction of the braking power. Underinflated and overinflated tyres reduce braking efficiency, handling accuracy and stability in a bend.

Stopping the motorcycle

Reduce speed, shift down and release the throttle twistgrip. Shift down to engage first gear and then neutral.

Apply the brakes and bring the motorcycle to a complete stop.


Stop the engine by pushing the red switch (1) down. Press button (2) for Key-off.



Parking

Park the stopped motorcycle on the side stand. Fully steer handlebar to the left or to the right. If this operation is performed within 60 seconds from engine stop it will be possible to engage the steering lock.

If you wish to engage the steering lock, during this interval press button (1) and hold it depressed for 3 seconds with steering turned completely to the left or to the right. After 1 second, the message "KEEP PRESSED TO LOCK" will be displayed on instrument panel and will stay on for 2 seconds; steering lock will be engaged after this time.





After this 3 second time, if steering lock is properly engaged, the message "STEERING LOCKED" will be displayed on instrument panel.


In case of failed engagement of steering lock. contact a Ducati Authorized Service Centre

Attention

The exhaust system might be hot, even after engine is switched OFF; pay particular attention not to touch the exhaust system with any body part and do not park the motorcycle next to inflammable material (wood, leaves etc.).

lAttention

Using padlocks or other locks designed to prevent motorcycle motion, such as brake disc locks, rear sprocket locks, and so on is dangerous and may impair motorcycle operation and affect the safety of rider and passenger.




Attention

Engine, exhaust pipes and silencers stay hot long after the engine is switched off; pay particular attention not to touch the exhaust system with any body part and do not park the vehicle next to flammable material (wood, leaves etc.). Do not cover the motorbike with the canvas, when the engine and exhaust system are hot, to avoid damaging it.

Indication of No Key Detected (upon Key-Off)

This function informs that it is not possible to engage the steering lock since the key is not detected.

The display shows "NO KEY DETECTED".



Refuelling

Never overfill the tank when refuelling. Fuel should never be touching the rim of filler recess.

Warning

The fuel pressure inside the tank may, in extreme cases, cause fuel to "spray" when opening the fuel cap.

Always open the fuel cap slowly and carefully during the refill.


If you hear an audible hiss from the cap while opening it, wait until the stop of the hissing before opening it completely.

The sound is residual pressure escaping from the fuel tank, therefore the stop of the hiss indicates that there is no more residual pressure.

The situation described above is more likely in hot weather conditions.

Attention

Use fuel with low lead content and an original octane number of at least 95.




Attention
The motorcycle is only compatible with fuel having a maximum content of ethanol of 10% (E10). Using fuel with ethanol content over 10% is forbidden. Using it could result in severe damage of the engine and motorcycle components. Using fuel with ethanol content over 10% will make the warranty null and void.

Fuel label

The label identifies the fuel recommended for this vehicle.

- 1) The E5 reference inside the label indicates the use of fuel with a maximum oxygen content of 2.7% by weight and a maximum ethanol content of 5% by volume, according to EN 228.
- 2) The E10 reference inside the label indicates the use of fuel with a maximum oxygen content of 3.7% by weight and a maximum ethanol content of 10% by volume, according to EN 228.




Tool kit and accessories

The tool kit (2) is located under the seat (1) and includes:

- fuse pliers;
- screwdriver;
- screwdriver handgrip;
- box wrench 14/16 mm (0.55/0.63 in);
- fixed wrench 8/10 mm (0.31/0.39 in);
- Allen wrench 3 mm (0.12 in).
- Allen wrench 5 mm (0.20 in).
- Allen wrench 6 mm (0.24 in).

To access the compartment, remove the seat (1).



Instrument panel (Dashboard)



If the ENGINE OIL light stays ON, stop the engine or it may suffer severe damage.

Instrument panel

- 1) Display.
- 2) NEUTRAL LIGHT N (GREEN).

Comes on when in neutral position.

3) CRUISE CONTROL LIGHT (GREEN).

Comes on to indicate operation of the Cruise Control.

4) HIGH BEAM LIGHT ≣O (BLUE).

It turns on to indicate that the high beam lights are on and when the flasher is activated.

- 5) FUEL WARNING LIGHT 🗈 (AMBER YELLOW).
- Comes on when fuel is low (see chapter Top-ups).
- 6) TURN INDICATOR LIGHTS ⇔ (GREEN).

Illuminates and flashes when the turn indicator is in operation.

7) ENGINE OIL PRESSURE LIGHT № (RED).

Comes on when engine oil pressure is too low. It must turn on at "KEY-ON", but must turn off a few seconds after the engine has started. It may shortly come on when the engine is hot, however, it should go out as the engine revs up.

8) DTC LIGHT (AMBER YELLOW).

This light indicates DTC system enabling/disabling status.

Speed below 5 Km/h (3 mph)			
Light OFF	Light flashing	Light steady on	
_		DTC disabled and/or not functioning due to a fault in the BBS controlunit	
Speed above 5 Km/h (3 mph)			
Light OFF	Light flashing	Light steady on	
		DTC disabled and/or not function- ing due to a fault in the BBS control unit	

9) "ENGINE/VEHICLE DIAGNOSIS - MIL" LIGHT 🖒 (AMBER YELLOW).

- The warning light turns steady on in case of error in engine management. Proceed slowly, avoid harsh acceleration and overtaking, take the vehicle to a Ducati authorised service centre to eliminate the malfunction.
- The warning light turns on flashing to warn about a critical emission-related error that could damage
 the catalytic converter. If possible, have the vehicle be taken to a Ducati authorised service centre and
 the malfunction eliminated and at any rate proceed slowly, avoid harsh acceleration and overtaking.

10) ABS LIGHT (M) (AMBER YELLOW). Indicates ABS status.

Speed below 5 Km/h (3 mph)		
Light OFF	Light flashing	Light steady on
- ABS enabled but not yet function- ing since initialisation is in progress or there is a fault of the IMU control unit		due to a fault in the ABS control
Speed above 5 Km/h (3 mph)		
Light OFF	Light flashing	Light steady on
ABS enabled and functioning	,	ABS disabled and not functioning due to a fault in the ABS control unit

11) GENERIC ERROR WARNING LIGHT (AMBER YELLOW).

It turns on when there are any "vehicle" errors, i.e. active errors triggered by any control unit other than the engine control unit.

12) OVER REV / DTC INTERVENTION / IMMOBILIZER SYSTEM (RED).

	DTC
No intervention	Light OFF
Spark advance cut	Light steady ON
Injection cut	Light steady ON

	Over rev
No intervention	Light OFF
First threshold (N RPM before the lim- iter kicks in)	Light steady ON
Limiter	Light ON flashing

Note

Each calibration of the Engine Control Unit may have a different setting for the thresholds that precede the rev limiter and the rev limiter itself.

	Immobilizer
Key-ON status	Light OFF
Key-OFF status	Light ON flashing

Key-off status for	Light OFF
over 1 hour	


13) DRL LIGHT (GREEN)

Only for the Diavel S model (except for China, Japan and Canada versions) Indicates DRL light status.

	DRL
Function not active	Light OFF
Function active	Light steady ON
Function active but with an error	Light ON flashing

Important

If the display shows the message "TRANSPORT MODE", immediately contact your Ducati Dealer that will delete this message and ensure the full operation of the motorcycle.



Parameter displaying


Upon key-on, the instrument panel displays the DUCATI logo and switches on the LED warning lights in two steps ("initial check routine").

At the end of the check, the instrument panel shows the main screen in the CORE mode which is the default one for all riding styles.

It is possible to change the display mode with the INFO MODE function in the Setting Menu.

During this first check stage, if the motorcycle speed exceeds 10 km/h (6 mph) (actual speed), the instrument panel will stop:


- the display check routine and display the standard screen containing updated information;
- the warning light check routine and leave ON only the warning lights that are actually active at the moment.



The main screen can have four different layouts: CORE, TRACK, FULL and CITY.


Data displayed on the main screen for CORE layout are as follows:

- 1) Rev counter (RPM).
- 2) Motorcycle speed.
- 3) Gear indication.
- 4) Set Riding Mode.
- 5) Fuel level.
- 6) Menu 1: Odometer, Engine coolant temperature, Trip meter 1, Trip meter 2, Range, Average consumption, Instant fuel consumption, Average speed, Trip time, Ambient air Temperature.
- 7) Bluetooth indication.
- 8) DRL light status (Auto / Manual).
- 9) DPL level indication (assisted start): active only during an assisted launch.
- 10) Cruise Control indication.
- 11) LAP.




Data displayed on the main screen for TRACK layout are as follows:

- 1) Rev counter (RPM).
- 2) Motorcycle speed.
- 3) Gear indication.
- 4) Set Riding Mode.
- 5) ABS level.
- 6) DTC level.
- 7) DWC level.
- 8) DQS status.
- 9)
- 10) Menu 1: Odometer, LAP Time (only if active), Engine coolant temperature, Trip meter 1, Trip meter 2, Range, Average consumption, Instant fuel consumption, Average speed, Trip time, Ambient air Temperature.
- 11) Cruise Control indication.
- 12) Bluetooth indication.
- 13) DRL light status (Auto / Manual).
- 14) DPL level indication (assisted start): active only during an assisted launch.
- 15) LAP.




Data displayed on the main screen for FULL layout 15) LAP. are as follows:

- 1) Rev counter (RPM).
- 2) Motorcycle speed.
- 3) Gear indication.
- 4) Set Riding Mode.
- 5) Fuel level.
- 6) Clock.
- Menu 1: Odometer, Engine coolant temperature, Player On / Off (active only if the Bluetooth module is available and at least one Smartphone is connected), Range, Trip meter 1, Trip meter 2.
- 8) Menu 2: Average consumption, Instant fuel consumption, Average speed, Trip time, Ambient air temperature).
- 9) Cruise Control indication.
- 10) Bluetooth indication.
- Infotainment: Smartphone connected, Helmet 01 connected, Helmet 02 connected, Navigator connected.
- 12) DRL light status (Auto / Manual).
- 13) DPL level indication (assisted start): active only during an assisted launch.
- 14) Infotainment: received message/s, missed call.




Data displayed on the main screen for CITY layout are as follows:

- 1) Motorcycle speed.
- 2) Gear indication.
- 3) Set Riding Mode.
- 4) Fuel level.
- 5) Clock.
- 6) Menu 1: Odometer, Engine coolant temperature, Player On / Off (active only if the Bluetooth module is available and at least one Smartphone is connected), Trip meter 1, Trip meter 2, Range, Average consumption, Instant fuel consumption, Average speed, Trip time, Ambient air temperature.
- 7) Bluetooth indication
- Infotainment: Smartphone connected, Helmet 01 connected, Helmet 02 connected, Navigator connected, received message/s, missed call, Player + volume, incoming call, track name.
- 9) DRL light status (Auto / Manual).
- 10) Cruise Control indication.
- 11) LAP.




From the main screen of the CORE mode, pressing button (1) on the left-hand switch allows displaying Menu 1 information.

- · Odometer;
- Engine coolant temperature;
- TRIP 1;
- TRIP 2;
- RANGE;
- Average Fuel Consumption (CONS. AVG);
- Instant fuel consumption (CONS);
- Average speed (SPEED AVG);
- Trip time (TRIP TIME);
- Air temperature (T-AIR).



From the main screen of the TRACK mode, pressing button (1) on the left-hand switch allows displaying Menu 1 information.

- Odometer;
- LAP time (only if active);
- Engine coolant temperature;
- TRIP 1;
- TRIP 2;
- RANGE:
- Average Fuel Consumption (CONS. AVG);
- Instant fuel consumption (CONS);
- Average speed (SPEED AVG);
- Trip time (TRIP TIME);
- Air temperature (T-AIR).




From the main screen of the FULL mode, pressing button (1) on the left-hand switch allows displaying Menu 1 information.

- Odometer;
- Engine coolant temperature;
- PLÄYER ON/OFF (active only with connected Smartphone);
- RANGE;
- TRIP 1;
- TRIP 2.


Press button (2) on LH switch to view Menu 2 information

- Average Fuel Consumption (CONS. AVG);
- Instantaneous fuel consumption (CONS.);
- Average speed (SPEED AVG);
- TRIP TIME;
- Air temperature (T-AIR).



From the main screen, with CITY layout, press button (1) on LH switch to view Menu 1 information.

- · Odometer;
- Engine coolant temperature;
- Player On / Off (active only if the Bluetooth module is available and at least one Smartphone is connected)
- TRIP 1;
- TRIP 2;
- RANGE;
- Average Fuel Consumption (CONS. AVG);
- Instant fuel consumption (CONS);
- Average speed (SPEED AVG);
- Trip time (TRIP TIME);
- Air temperature (T-AIR).



For the FULL display mode, the instrument panel stores Menu 1 and Menu 2 settings in use upon KEY-OFF. Upon the following KEY-ON, the previously stored Menu 1 and Menu 2 screens are displayed. In case of sudden and unexpected power off, the instrument panel displays the Menu 1 and Menu 2 default settings upon the following KEY-ON:

- Menu 1 default page = TOT (Odometer);
- Menu 2 default page = RANGE.

For the CORE, TRACK and CITY display modes, the instrument panel stores Menu 1 settings in use upon KEY-OFF. On the following KEY-ON, previously stored Menu 1 page is displayed.


In case of sudden and unexpected power OFF, the instrument panel displays the default settings for Menu 1 upon the following KEY-ON; in particular:

• Menu 1 default page = TOT (Odometer).


When the standard screen of set layout is displayed, hold button (4) for 2 seconds to enter the Setting menu, where you can set any function.

○ Note

You can enter the Setting MENU only when the actual vehicle speed is lower than or equal to 5 km/h (3 mph). Within the Setting Menu, if vehicle actual speed exceeds 5 km/h (3 mph), the instrument panel automatically quits the menu and shows the standard screen.



If the key is not acknowledged upon Key-On and once the check routine is over, if the PIN CODE function is active the instrument panel shows a screen where it is possible to enter the release PIN CODE. Use button (1) and button (2) to enter the code digit and confirm by pressing button (4).



Main and auxiliary functions

Information displayed in the standard screen of the selected display layout (CORE, TRACK, FULL or CITY) are the following:

Main information

- Engine rpm indication (RPM)
- Motorcycle speed
- Fuel level
- Riding Mode
- ABS
- DTC
- DWC
- DQS
- Gear
- Clock
- the menus display the following functions:
 - Odometer (TOT)
 - Engine Coolant temperature
 - Residual range (RANGE)
 - Trip meter 1 (TRIP1)
 - Trip meter 2 (TRIP2)
 - Trip time (TRIP TIME)
 - Instantaneous fuel consumption (CONS)
 - Average Fuel Consumption (CONS. AVG)
 - Average speed (SPEED AVG)
 - Ambient air temperature

- I AP time
- LAP time (only if active)
- Player On / Off (active only if the Bluetooth module is available and at least one Smartphone is connected)

Additional information

- DRL status
- DPL level
- Infotainment Bluetooth
- Cruise Control
- Service indication (SERVICE)
- Warning/Alarm indication (Warning)

Vehicle speed indication

The instrument panel receives information about the actual vehicle speed (calculated in km/h) and displays the value increased by 5% and converted in the set unit of measurement (mph or km/h).


A string of dashes "- - -" is displayed with the set unit of measurement if:

- speed is equal to 299 km/h or 186 mph or if instrument panel is not receiving the speed value ("- - -" steady ON);
- the rear speed sensor is in fault (flashing "- -").

Considering that the TRACK, FULL and CITY layouts show the values for this function in a similar way to the CORE layout, the example shown depicts the function in CORE layout.

Note

If the instrument panel does not receive any information on the unit of measurement, the last unit of measurement set is displayed flashing.




Gear indication

The instrument panel receives information about the gear engaged and displays the corresponding value.

If a gear is engaged, the displayed value may range from 1 to 6, while if in neutral N is displayed. A string of flashing dashes "--" is displayed if gear teach-in procedure has not been carried out yet, or if instrument panel is not receiving gear information. If the gear sensor is in fault, a string of dashes "--" is displayed steady on.

Considering that the TRACK, FULL and CITY layouts show the values for this function in a similar way to the CORE layout, the example shown depicts the function in CORE layout.



Engine rpm indication


The instrument panel receives the engine rpm information and displays it on the relevant bargraph (in TRACK, FULL and CORE display modes only). The information is displayed by the bargraph filling from the left to the right according to the engine rpm and with the enlargement of the numerical digit of the relevant miles (e.g., if the RPM value is "8000" or higher, number "8" is displayed bigger).

The range between 9000 and 10000 rpm (prewarning area) is displayed in orange both for the bargraph filling and for the indication of value "9" (orange area).


The range between 10000 and 10500 rpm (warning area) is displayed in red both for the bargraph filling and for the indication of value "10" (red area).



CORE layout indicates rpm in a different way compared to TRACK and FULL layouts.
CITY layout does not provide for rpm indication.



When the threshold before the rpm limiter is reached, the corresponding warning lights will turn on.



Clock


The instrument panel receives information about the time to be displayed.

The instrument panel shows the time in the following format:

- hh (hours): mm (minutes);
- followed by a.m. (from 12:00 to 11:59) or p.m. (from 12:00 to 11:59).

In case of a power off (Battery Off), upon the following Key-On, the instrument panel displays 4 dashes " - - : - - " steadily and with flashing colon, until clock is set through the Setting Menu.

Considering that the CITY layout shows the values for this function in a similar way to the FULL layout, the example shown depicts the function in FULL layout. This function is not displayed in the CORE and TRACK modes.




Engine Coolant temperature

The instrument panel receives information about the engine temperature (already calculated in °C) and displays the value in the set unit of measurement (°C or °F), followed by the unit of measurement and the engine temperature symbol. The temperature display range goes from 40 °C to ± 120 °C (± 104 °F $\pm \pm 248$ °F). If reading is:

- <= (lower than or equal to) -40 °C (-40 °F), a string of flashing dashes " - - - " is displayed;
- within the range -39 °C (-38 °F) to +39 °C (+102 °F), "LOW" is displayed steadily;
- within the range +40 °C (+104 °F) to +120 °C (+248 °F), the value is displayed steadily;
- >= (higher than or equal to) +121 °C (+250 °F),
 "HIGH" is displayed flashing and in red, the
 Coolant Temperature symbol is steady and red.

If the coolant temperature sensor is in fault, a string of flashing dashes "---" is displayed with the set unit of measurement and the MIL light turns on. If the instrument panel is not receiving coolant temperature value, a string of steady dashes "---" is displayed, followed by the unit of measurement.



Note
If the instrument panel does not receive any information on the unit of measurement, the last unit of measurement set is displayed flashing.

Fuel level

This function displays the fuel level.


The low fuel light turns on when the level goes down to 2 steady marks that become orange and the fuel pump symbol is steady and orange.

If the level goes further down, the last mark will be red and flashing and the fuel pump symbol will be steady and red.

Considering that the FULL and CITY layouts show the values for this function in a similar way to the CORE layout, the example shown depicts the function in CORE layout. In the TRACK mode, this function is not shown.

Note

In case of fault or error of the fuel level sensor, no level marks will be displayed, the fuel pump symbol will be red and flashing, and the Fuel Range warning light will be on.



Riding Mode (RIDING MODE)

The Riding Mode can be selected from the instrument panel. Preset riding modes are three: SPORT, TOURING and URBAN.


The selected and active riding mode is displayed on the instrument panel in all four layouts. Every Riding Mode contains the following parameters, set by Ducati or customised by the user through the setting function pages:

- a specific engine power that will change throttle behaviour (HIGH, MED, LOW);
- a specific level of intervention for the DTC traction control (1, 2, 3, 4, 5, 6, 7, 8, OFF);
- a specific ABS calibration (1, 2, 3);
- a specific level of intervention for the DWC (1, 2, 3, 4, 5, 6, 7, 8, OFF);
- a specific DQS status (U/D, OFF);

For each riding mode there are four information display layouts (TRACK, FULL, CORE and CITY) that can be set by the user in the setting function pages: the layout set by default by Ducati is CORE.

▲ Attention

Ducati recommends changing the Riding mode when the motorcycle is stopped. If the riding mode is changed while riding, be very careful (it is recommended to change the Riding mode at a low speed).



Selecting the Riding Mode

Press CONFIRM MENU button (4) to view the menu for selecting the Riding Mode (A). The instrument panel displays the speed indication (on the RH side) and displays riding mode name (on the LH side):

- SPORT
- TOURING
- URBAN

One of them will be marked to indicate the last memorised condition that is currently active.

For the marked Riding Mode, instrument panel always displays information concerning some of the associated parameters:


- engine power (ENGINE): ENGINE lettering followed by set engine power (HIGH, MED, LOW);
- DTC system: DTC lettering followed by the set level (1, 2, 3, 4, 5, 6, 7, 8) in case DTC is active or followed by OFF in case DTC is disabled;
- ABS system: the ABS text followed by the level of calibration set (1, 2, 3);
- DWC: the DWC text followed by the level of intervention set (1, 2, 3, 4, 5, 6, 7, 8) in case the

- DWC is active or by OFF in case the DWC is disabled;
- DQS: the DQS text followed by set status (U/D, OFF) in case the DQS is active or by OFF in case the DOS is disabled:

Any time the CONFIRM MENU button (4) is pressed, you highlight a riding mode and the associated parameters are displayed (A, Fig 109).

Once the desired riding mode (A, Fig 109) is highlighted, confirm the selection by holding down the CONFIRM MENU button (4) for 2 seconds: the new riding mode selection is stored and the standard screen (C, Fig 109) is displayed for the selected riding mode.

Once the desired riding mode is highlighted, if the CONFIRM MENU button (4) is not pressed within 5 seconds, the new riding mode selection is not stored and the Standard screen is displayed.




Displayed information includes the values stored for each single Riding Mode. The stored settings may be the factory ones (Ducati default settings) or the ones customised by the owner.

In the screen that allows changing the Riding Mode, the instrument panel, besides displaying information concerning each riding mode (ENGINE, DTC, ABS, DWC, DQS) shows other information regarding functions that are active but could not be shown in the set display mode: for example in the TRACK display mode the fuel level is not shown as it is in the Riding mode change screen.

Available information:


- fuel level (L);
- DRL light status (D): indication displayed if the DRL lights are active; available only in the Diavel S model, excluded the China, Japan and Canada versions:
- Cruise Control (E) status: indication shown only if the Cruise Control function is active:
- Service (F) indication: shown only if one Service function is active (OIL SERVICE, ANNUAL SERVICE or DESMO SERVICE);
- Infotainment indication (Call/Track) (G): shown only if the Bluetooth function is available;

 Infotainment indication (paired devices) (H): shown only if the Bluetooth function is available.



When system requests rider to confirm the riding mode change, the procedure will output an error if:

- the vehicle is stopped, the instrument panel only checks whether the throttle control is closed / open by indicating CLOSE THROTTLE if so;
- the vehicle is moving, the instrument panel checks whether the throttle control is open / closed or whether the brakes are pulled or not; the instrument panel may display CLOSE THROTTLE AND RELEASE BRAKES or CLOSE THROTTLE or RELEASE BRAKES.



DTC indicator

The instrument panel displays DTC status as follows:


- if DTC is active, DTC lettering and the Traction Control intervention level number (1 to 8);
- if DTC is active, but system is in degraded operation due to a fault, DTC lettering and the DTC intervention level number, 1 to 8 (flashing); also the DTC warning light starts flashing;
- if DTC is not active, DTC OFF warning;
- if system is in fault, DTC lettering and the intervention level number (1 to 8) in orange.

The DTC function status is shown only in the TRACK display mode.

If DTC is in fault or the Black Box is in fault, the instrument panel will display DTC Err and DTC warning light will be steady on.

Attention

In case of system malfunction, contact a Ducati Dealer or Authorised Service Centre.



Attention

DTC is a rider aid that can be used on the track, on the road and off road. The system is designed to make riding easier and to enhance safety, but in no way relieves the rider of the obligation to drive responsibly and to maintain a high standard of riding in order to avoid accidents, whether caused by his own errors or those of other road users, through making emergency manoeuvres, in accordance with the prescriptions of the road traffic code.

The rider must always be aware that active safety systems have a preventive function. The active

elements help the rider control the motorcycle, making it as easy and safe to ride as possible. The presence of an active safety system should not encourage the rider to ride at speeds beyond the reasonable limits, not in accordance with the road conditions, the laws of physics, good riding standards and the requirements of the road traffic code.

The following table indicates the most suitable level of DTC intervention for the various riding modes as well as the default settings in the "Riding Modes" that can be selected by the rider.

DTC	RIDING MODE	USE	DEFAULT
OFF			
1	SPORT	Sports style for very expert riders. System permits sliding sideways.	NO
2	SPORT	Sports style for expert riders. System permits sliding sideways.	NO
3	SPORT	Sports style for medium-expert riders. System permits sliding sideways.	It is the default level for the "SPORT" Riding Mode
4	TOURING	Fast touring style.	It is the default level for the "TOURING" Riding Mode
5	TOURING	Touring style.	NO
6	URBAN	"Very safe" style on any kind of path.	It is the default level for the "URBAN" Riding Mode
7	RAIN	For riding on slightly wet or moist road. ENGINE LOW setting recommended.	NO
8	HEAVY RAIN	For riding on wet road. ENGINE LOW setting recommended.	NO

Tips on how to select the sensitivity level

Attention

The calibration of all levels of the DTC system your motorcycle is equipped with was carried out with original equipment tyres: front TL PIRELLI Diablo Rosso III D in size 120/70 ZR17 M/C (58W), and rear TL PIRELLI Diablo Rosso III in size 240/45 ZR17 M/C (82W).

The use of tyres of different size and characteristics to the original tyres may alter the operating characteristics of the system.

In the case of minor differences, such as for example, tyres of a different make and/or model than the OE ones, but with the same size (front = 120/70 - 17, rear = 240/45 - 17), it may be sufficient to simply select the suitable level setting from those available in order to restore optimal system operation. If tyres of a different size class are used or if the tyre size differs significantly from the original tyres, it may be that the system operation is affected to the point where none of the 8 available level settings will give satisfactory results. In this case it is advisable to deactivate the traction control system.

If level 8 is selected, the DTC system will kick in at the slightest hint that the rear wheel is starting to spin. Between level 8 and level 1 there are intermediate levels. DTC intervention decreases from level 8 to level 1. Levels 1, 2 and 3 allow both spinning and skidding of the rear wheel out of a corner: these levels are recommended only for expert riders.

The choice of the correct level mainly depends on the following parameters:

- The tyre/asphalt grip (type of tyre, amount of tyre wear, the road/track surface, weather conditions, etc.);
- The characteristics of the path/circuit (bends all taken at similar speeds or at very different speeds);
- 3) The riding mode (whether the rider has a "smooth" or a "rough" style).

Level depends on grip conditions

The choice of level setting depends greatly on the grip conditions of the track/path (see below, tips for use on the road).

Level depends on type of track

If the track/path features bends all taken at similar speeds, it will be easier to find a level suitable for all bends; while a track/path with bends all requiring different speeds will require a DTC level setting that is the best compromise for all bends.

Level depends on riding style

The DTC will tend to kick in more with a "smooth" riding style, where the motorcycle is leaned over further, rather than with a "rough" style" where the motorcycle is straightened up as quickly as possible when exiting a turn.

Tips for use on dry road

Activate the DTC, select level 6 and ride the motorcycle in your usual style; if the level of DTC sensitivity seems excessive, try levels 5, 4, etc., until you find the one that suits you best. If changes occur in the grip conditions and/or circuit characteristics and/or your riding style, and the level setting is no longer suitable, switch to the next level up or down and proceed to determine the best setting (e.g. if with level 5 the DTC intervention seems excessive, switch to level 4; alternatively, if on

level 5 you cannot perceive any DTC intervention, switch to level 6).

Tips for use on wet road

Level 7 is recommended when road is slightly wet or damp and level 8 on wet road. It is also recommended to select ENGINE LOW in these conditions.

ABS indicator

The motorcycle is equipped with ABS, the instrument panel indicates ABS status (on or off) by switching off, on or flashing the ABS warning light. The instrument panel displays:

- if ABS is active, ABS indication and intervention level number (1 to 3) (steadily);
- if ABS is active, but system is in degraded operation due to a fault (no "cornering" feature"), ABS lettering and the ABS intervention level number, 1 to 3 (flashing); also the ABS warning light starts flashing;
- if system is in fault, ABS lettering and the intervention level in orange.


The ABS function status is shown only in the TRACK display mode.

If the ABS is in fault, the instrument panel will display ABS Err and ABS warning light will be steady on.

Attention

In case of system malfunction, contact a Ducati Dealer or Authorised Service Centre.

Using the brakes correctly under adverse conditions is the hardest – and yet the most critical - skill to



master for a rider. Braking is one of the most difficult and dangerous moments when riding a two wheeled motorcycle: the possibility of falling or having an accident during this difficult moment is statistically higher than any other moment. A locked front wheel leads to loss of traction and stability, resulting in loss of control.

The Anti-Lock Braking System (ABS) has been developed to enable riders to use the motorcycle braking force to the fullest possible amount in emergency braking or under poor pavement or adverse weather conditions. ABS is an electro-

hydraulic device that controls the pressure in the brake circuit when the control unit, by processing information from wheel sensors, determines that one or both wheels are about to lock up. In this case, pressure decrease in the brake circuit allows the wheel to carry on turning, thereby preserving grip. After that, the control unit restores the pressure in the brake circuit, to resume the braking action. This cycle is repeated many times until the problem is completely eliminated. Normally, the rider will perceive ABS operation as a harder feel or a pulsation of the brake lever and pedal. The front and rear brakes use separate control systems.

The ABS system fitted to the Diavel 1260 is a safety system preventing wheel lockup while braking, adopting different strategies depending on the selected level. The active presence of strategies and their intervention level depend on the selected level. The ABS features 3 levels, one associated to each Riding Mode.

The Diavel 1260 ABS features a "cornering" function that optimises ABS functionality to the conditions where the motorcycle is leaning over, thus preventing wheel lockup and slipping as much as possible, within the physical limits allowed by the

vehicle and by the road conditions. The cornering feature is active in ABS levels 2 and 3.

According to the selected level, the Diavel 1260 ABS implements the anti lift-up function for the rear wheel so as to guarantee not only a reduced stopping distance under braking, but also the highest possible stability. This is active in levels 2 and 3.

Attention

Using the two brake controls separately reduces the motorcycle braking power.

Never use the front brake control harshly or suddenly as you may cause rear wheel lift-up and lose control of the motorcycle.

When riding in the rain or on slippery surfaces, braking will become less effective. Always use the brakes very gently and carefully when riding under these conditions. Any sudden manoeuvres may lead to loss of control.

When tackling long, high-gradient downhill road tracts, shift down gears to use engine braking. Apply one brake at a time and use brakes sparingly. Keeping the brakes applied all the time would cause

the friction material to overheat and reduce braking power dangerously.

Underinflated and overinflated tyres reduce braking efficiency, handling accuracy and stability in a bend.

The following table indicates the most suitable level of ABS intervention for the various riding types as well as the default settings in the "Riding Mode" that can be selected by the rider:

ABS	RIDING MODE	CHARACTERISTIC	DEFAULT
1	EXPERT	This level is thought for extremely expert users. ABS in this level only controls the front wheel, and thus allows rear wheel lockup. The system in this level does NOT control lift-up and the cornering feature is NOT active.	
2	SPORT	This level is designed for use with good grip conditions. ABS in this level controls both wheels, the cornering function is active and controls lift-up. This calibration focuses on braking power.	the "SPORT" Riding Mode
3	SAFE & STABLE	This level is designed for use in any riding conditions to provide a safe and consistent braking action. ABS in this level controls both wheels, the cornering and anti-lift-up functions are active. This calibration focuses on vehicle stability.	the "TOURING" and "UR- BAN" Riding modes.

Tips on how to select the sensitivity level

Attention

Excellent operation of the ABS system, for all available levels, is ensured only with the OE brake system and with OE tyres and/or with the ones recommended by Ducati. In particular, OE tyres for this motorcycle are TL PIRELLI Diablo Rosso III D at the front, 120/70 ZR17 M/C (58W), and TL PIRELLI Diablo Rosso III at the rear, 240/45 ZR17 M/C (82W). The use of tyres of different size and characteristics to the original tyres may alter the operating characteristics of the system thus making it unsafe. It is recommended not to install tyres of different size than the ones approved for your vehicle.

Selecting level 3, the ABS will ensure a very stable braking also thanks to lift-up control, and the motorcycle will keep a good alignment during the whole braking action. ABS level 3 features active cornering function which, with vehicle leaning over, prevents wheel lockup and slipping as much as possible, within the physical limits allowed by the vehicle and by the road conditions.

Selecting level 2, the ABS will privilege more the braking power than stability. ABS level 2 features active cornering function which, with vehicle leaning over, prevents wheel lockup and slipping as much as possible, within the physical limits allowed by the vehicle and by the road conditions.

ABS level 1 is conceived for very expert riders and ABS is active only on the front wheel to help performance. In this level there is no lift-up control nor cornering feature.

The choice of the correct level mainly depends on the following parameters:

- The tyre/road grip (type of tyre, amount of tyre wear, the road/track surface, weather conditions, etc.).
- 2) The rider's experience and sensitivity: expert riders can tackle a lift-up in trying to reduce the stopping distance to a minimum, while less expert riders are recommended to use setting 3, that will help them keeping the motorcycle more stable even in emergency braking.

DWC indicator

The instrument panel displays DWC status as follows:

- if the DWC is active, the message "DWC" and the set intervention level number "1" to "8":
- if DWC is active, but system is in degraded operation, "DWC" indication and the number (flashing); also the DTC/DWC warning light starts flashing;
- when in fault, the "DWC" indication and the red "Err" message; also the DTC/DWC warning light turns on;
- if DWC is disabled, "DWC" "OFF" indication.


Attention

In case of system malfunction, contact a Ducati Dealer or Authorised Service Centre.

Note

If DTC is set to OFF, DWC is also forced to OFF.

The Ducati Wheelie Control system (DWC) supervises control of wheelie movement and settings vary through eight different levels that are calibrated to offer a different prevention and



reaction to wheelies. Each Riding Mode features a pre-set intervention level. Level eight indicates a setting that minimises motorcycle tendency to shift up in a wheelie and maximises reaction to the same, if it occurs. While level one is for expert riders and features a lower wheelie control in terms of prevention and less strong reaction to the same, if it occurs.

Attention
DWC is a rider aid that can be used on both the track and the road. The system is designed to make riding easier and to enhance safety, but in no way relieves the rider of the obligation to drive responsibly and to maintain a high standard of riding in order to avoid accidents, whether caused by his own errors or those of other road users, through making emergency manoeuvres, in accordance with the prescriptions of the road traffic code.

The rider must always be aware that active safety systems have a preventive function. The active elements help the rider control the motorcycle. making it as easy and safe to ride as possible. The presence of an active safety system should not encourage the rider to ride at speeds beyond the reasonable limits, not in accordance with the road conditions, the laws of physics, good riding standards and the requirements of the road traffic code.

The following table indicates the most suitable level of DWC intervention for the various riding types as well as the default settings in the "Riding Mode" that can be selected by the rider:

DWC LEVEL	USE		DEFAULT
OFF		The DWC is disabled.	NO
1	HIGH PERFORMANCE	Level for expert riders. The system allows wheelies, but decreases the speed at which the front wheel lifts.	NO
2	PERFORMANCE	Level for expert riders. The system allows wheelies, but decreases the speed at which the front wheel lifts.	
3	SPORT	Level for expert riders. The system reduces the motorcycle's proneness to do wheelies and intervenes in case of wheelie.	It is the default level for the "SPORT" Riding Mode
4	SPORT	Level for all kinds of riders. The system reduces the motorcycle's proneness to do wheelies and intervenes in case of wheelie.	

DWC LEVEL	USE		DEFAULT
5	SAFE & STABLE	Level for all kinds of riders. The system reduces the motorcycle's proneness to do wheelies and sensitively intervenes in case of wheelie.	
6	SAFE & STABLE	Level for all kinds of riders. The system reduces the motorcycle's proneness to do wheelies and sensitively intervenes in case of wheelie.	
7	HIGH SAFE & STABLE	Level for all kinds of riders. The system reduces the motorcycle's proneness to do wheelies and sensitively intervenes in case of wheelie.	
8	HIGH SAFE & STABLE	Level for all kinds of riders. The system reduces the motorcycle's proneness to do wheelies to a minimum level and sensitively intervenes in case of wheelie	

Tips on how to select the sensitivity level

Attention

excellent operation of the DWC system, for all available levels, is ensured only with the OE final drive and with OE tyres and/or with the ones recommended by Ducati. The use of tyres of different size and characteristics to the original tyres may alter the operating characteristics of the system thus making it unsafe. It is recommended not to install tyres of different size than the ones approved for your vehicle.

At level 8 the DWC system reduces the motorcycle's proneness to do wheelies to a minimum level and sensitively intervenes in case of wheelie. Between level 8 and level 1 there are further intermediate levels of intervention for the DWC. Levels 1, 2 and 3 allow easier wheelies, but reduce their speed: these levels are recommended only for track use and for expert riders who can control wheelies on their own and exploit the system feature that reduces the speed at which the front wheel tends to lift.

The choice of the correct level mainly depends on the following parameters:

The rider's experience;

 The characteristics of the path/circuit (bend exit with low or high gear engaged).

The rider's experience

The choice of level setting depends greatly on the riders' experience and ability to control wheelies on their own. Levels 1, 2 and 3 require a great experience to ensure proper control.

Level depends on type of track

If the track/path features bends where out speed and gear are low, a lower level will be necessary; while a track/path with faster bends will allow the use of a higher level setting.

Tips for use on the road

Activate the DWC, select level 8 and ride the motorcycle in your usual style; if the level of DWC sensitivity seems excessive, try levels 7, 6, etc., until you find the one that suits you best. If changes occur in the circuit characteristics, and the level setting is no longer suitable, switch to the next level up or down and proceed to determine the best setting (e.g. if with level 7 the DWC intervention seems excessive, switch to level 6; alternatively, if on level 7

you cannot perceive any DWC intervention, switch to level 8).


DQS indicator

The instrument panel displays DQS status as follows:

- if DQS system is enabled, the indication to engage the gears DQS U/D" is displayed;
- if DQS system is in reduced performance mode, the indication to engage the gears "DQS U/D" is displayed flashing;
- if the DQS system or the control unit is in fault, the "DQS Err" message is displayed in red;
- if DQS system is disabled, "DQS OFF" is displayed.

The DQS with up/down feature allows the rider to upshift and downshift without using the clutch lever. It includes a two-way microswitch - built in the lever mechanism - that outputs a signal to the engine control unit whenever the gearshift is operated. The system works in a separate way for upshifting and downshifting, and combines the action on ignition advance and injection, available in the upshift system, with controlled throttle opening for operation during downshifting.

Here below are some tips that will ensure you properly exploit this feature:



 The Ducati Quick Shift takes the same shift lever operation as with vehicle not equipped with the Ducati Quick Shift.
 Ducati Quick Shift is not designed for shifting

automatically.

 For any gearshift request (upshifting or downshifting) the rider has to move the shift lever from its idle position in the desired direction against the force of the spring through a certain over-travel, then keep the shift lever in this position until the gearshift is completed.
 Once the gearshift has been completed, the

- lever has to be fully released in order to allow another gearshift acted by Ducati Quick Shift. If the rider does not move the shift lever up to end stroke during a Ducati Quick Shift request, gears may not be fully engaged.
- Ducati Quick Shift provides no assistance for the gearshift if the rider uses the clutch lever.
- Ducati Quick Shift electronic shifting will not activate when the clutch lever is pulled.
- Ducati Quick Shift will shift down (downshifting) only when the throttle control is completely closed.
- If the Ducati Quick Shift strategy does not work properly, it is always possible to complete the gear shifting using the clutch lever.
- If the gear lever is held pressed up or down for more than 30 seconds (even if just by accident) a plausibility error can be memorised in the electronic control unit and the Ducati Quick Shift system could be disabled; in this case, to reactivate the system, it is necessary to release the lever, switch the instrument panel off, wait for 5 minutes and switch the instrument panel on again.
- Ducati Quick Shift is designed to operate above 2.500 rpm.

- No matter the gear engaged, downshifting with Ducati Quick Shift (downshifting) only woks below a set threshold, so as to avoid exceeding the maximum rpm allowed when the lower gear is engaged.
- It is not possible to downshift using the DQS when the Cruise Control is on.


Function menu

For each of the three riding modes (SPORT, TOURING, URBAN) menu functions can be displayed in one of the following four modes:

- CORE;
- TRACK;
- FULL;
- CITY.

Available functions are:

- Odometer (TOT);
- Engine Coolant temperature
- Residual range (RANGE);
- Trip meter 1 (TRIP1);
- Trip meter 2 (TRIP2);
- Trip time (TRIP TIME);
- Instant fuel consumption (CONS);
- Average Fuel Consumption (CONS. AVG);
- Average speed (SPEED AVG);
- Ambient air temperature;
- LAP time (if active);
- LAP time (only if active)
- Player On / Off (active only if the Bluetooth module is available and at least one Smartphone is connected).



Odometer (TOT)

The odometer counts and displays the total distance covered by the motorcycle with the set unit of measurement (km or mi).


The odometer number (in km or miles) is displayed with the message TOT and the indication of the unit of measurement. When the maximum value is reached (199999 km or 199999 mi) the instrument panel will permanently display said value. The odometer value is saved permanently and cannot be reset under any circumstances. Considering that the TRACK, FULL and CITY layouts show the values for this function in a similar way to

the CORE layout, the example shown depicts the function in CORE layout.

The reading is not lost in case of a power OFF (Battery OFF).

Note

If a string of flashing dashes " ----- " is displayed within odometer function, please contact a Ducati Dealer or Authorised Service Centre.




Trip meter 1 (TRIP 1)

The trip meter counts and displays the partial distance covered by the motorcycle with the set unit of measurement (km or mi) and is used as a basis to calculate average fuel consumption, average speed and trip time. The TRIP1 number (in km or miles) is displayed with the message TRIP1 and the indication of the unit of measurement.

When the reading exceeds the maximum value of 9999.9 km or 9999.9 mi, distance travelled is reset and the meter automatically starts counting from 0 again.

While the trip meter is displayed, press button (1) for 2 seconds to reset TRIP 1. When TRIP1 is reset, the average fuel consumption, average speed and trip time data are reset as well.

Considering that the TRACK, FULL and CITY layouts show the values for this function in a similar way to the CORE layout, the example shown depicts the function in CORE layout.



The TRIP1 counter is automatically reset in case the system unit of measurement is changed manually or after a Battery-OFF: the counter will then start back from zero, considering the new units of measurement.

Trip meter 2 (TRIP 2)

The trip meter counts and displays the partial distance covered by the motorcycle with the set unit of measurement (km or mi).


The TRIP2 number (in km or miles) is displayed with the message TRIP2 and the indication of the unit of measurement.

When the reading exceeds the maximum value of 9999.9 km or 9999.9 mi, distance travelled is reset and the meter automatically starts counting from 0 again.

While the trip meter is displayed, press button (1) for 2 seconds to reset TRIP 2.

The TRIP2 counter is automatically reset in case the system unit of measurement is changed manually or after a Battery-OFF: the counter will then start back from zero, considering the new units of measurement.

Considering that the TRACK, FULL and CITY layouts show the values for this function in a similar way to the CORE layout, the example shown depicts the function in CORE layout.



Residual range (RANGE)

This function displays the range according to the remaining fuel in the tank.

Information is indicated as RANGE, in the set unit of measurement.


If there is any function fault, the instrument panel will display three flashing dashes "- - -".

If the instrument panel is not receiving RANGE information, a string of three steady dashes "- - -" is displayed, followed by the unit of measurement.

○ Note

If the instrument panel does not receive any information on the unit of measurement, the last unit of measurement set is displayed flashing.

Considering that the TRACK, FULL and CITY layouts show the values for this function in a similar way to the CORE layout, the example shown depicts the function in CORE layout.



Average Fuel Consumption (CONS. AVG)

The instrument panel calculates and displays the vehicle average fuel consumption, the set unit of measurement and CONS. AVG text.

The calculation is made considering the quantity of fuel used and the distance travelled since TRIP1 was last reset.

Note


It is possible to change the units of measurement for consumption (both average and instantaneous) through the Setting Menu using the "UNITS SETTING" function.

When TRIP1 is reset, the value is reset and the first value available is displayed 10 seconds after the reset

During the first 10 seconds when the value is not available on the display, three steady dashes "- - . - " steadily as average fuel consumption. Value is expressed in the set unit of measurement (litres / 100 km or mpg UK or mpg US).

The active calculation phase occurs when the engine is running and the motorcycle is stopped: (moments

when the motorcycle is not moving and the engine is OFF are not considered).




Instantaneous fuel consumption (CONS.)

The instrument panel calculates and displays the vehicle instantaneous fuel consumption, the set unit of measurement and CONS. text.

The calculation is made considering the quantity of fuel used and the distance travelled during the last second. Value is expressed in the set unit of measurement: litres / 100 km or mpg UK or mpg US. The active calculation phase only occurs when the engine is running and the motorcycle is moving (moments when the motorcycle is not moving when speed is equal to 0 and/or when the engine is OFF are not considered). When the calculation is not made, a string of three dashes is displayed " - - . - " steadily as instantaneous fuel consumption.

Note

It is possible to change the units of measurement for consumption (both average and instantaneous) through the Setting Menu using the "UNITS SETTING" function.



Average speed (SPEED AVG)

The instrument panel calculates and displays the vehicle average speed, the set unit of measurement and SPEED AVG text.

The calculation considers the distance and time since TRIP1 was last reset.

The average speed value displayed is calculated by adding 5% so as to be consistent with motorcycle speed indication.


Note

You may change the units of measurement of speed and distance travelled through the Setting Menu using the "UNITS SETTING" function.

When TRIP1 is reset, the value is reset and the first value available is displayed 10 seconds after the reset

During the first 10 seconds, when the value is not yet available, the display will show a string of three dashes " - - - " steadily as average speed.

The active calculation phase occurs when the engine is running and the vehicle is stopped (moments when the vehicle is not moving and the engine is off are not considered).



Trip time (TRIP TIME)


The instrument panel calculates and displays the trip time as hhh:mm followed by TRIP TIME. The calculation considers the time since TRIP1 was last reset. When TRIP1 is reset, this value is reset as well. The time count active phase occurs when the engine is running and the motorcycle is stopped (the time is automatically stopped when the motorcycle is not moving and the engine is OFF and restarts when the counting active phase starts again).

When the reading exceeds 511:00 (511 hours and 00 minutes), the meter is reset and automatically starts counting from 0 again.

If you change the unit of measurement for an item connected to Speed (and distance) or Consumption or after a Battery-OFF, the trip time value will be automatically reset.

Note

If you change the unit of measurement for an item connected to Speed (and distance) or Consumption or after a Battery-OFF, the trip time value will be automatically reset.




Ambient air temperature (T AIR)

The instrument panel displays the ambient temperature in the set unit of measurement (°C or °F), followed by the set unit of measurement, the message T AIR and the thermometer symbol. The temperature value is displayed when ranging from -39 °C to +125 °C (or -38 °F \div +257 °F). For any different temperature (below -39 °C (-38 °F) or above +125 °C (+257 °F)) a string of three dashes " - - " is steadily displayed, followed by the unit of measurement.

If the air temperature sensor is in fault, the instrument panel will show three flashing dashes " - - - " as air temperature value, followed by the unit of measurement and the Generic Error light will turn on.

Note When the motorcycle is stopped, the engine heat could influence the displayed temperature.



Setting menu (SETTING MENU)

This menu allows enabling, disabling and setting some motorcycle functions.


To enter the Setting Menu hold button (4) for three seconds, with Key-On and vehicle actual speed \leq (lower than or equal to) 3.1 mph (5 km/h): once inside this menu, you may no longer view any other function.

The Setting Menu displays the following functions:

- RIDING MODE
- INFO MODE
- LAP
- PIN CODE
- DRL CONTROL (active only if the DRL function is available)
- BACKLIGHT
- DATE SET
- CLOCK SET
- INFO SERVICE
- UNIT SETTING
- BLUETOOTH (only if the Bluetooth module is available)
- INFO
 - BATTERY
 - RPM
 - BLUETOOTH version

Important

For safety reasons, it is recommended to use this Menu with the motorcycle at a standstill.



Press buttons (1) and (2) to highlight the customisable parameters one by one: in particular, use button (2) to highlight the following item and button (1) to highlight the previous item.


After highlighting the required parameter, press button (4) to open the corresponding menu page. At the top of instrument panel display is a text indicating the menu and sub-menu path during navigation through the settings.

To quit the Setting Menu you shall highlight "EXIT" and press button (4).

The functions that can be modified by the user are the following:

- Riding mode customisation (RIDING MODE): this menu allows customisation of:
 - Engine setting (ENGINE)
 - DTC level setting (DTC)
 - ABS setting (ABS)
 - DWC level (DWC)
 - DQS status setting (DQS) (if present)
 - Reset to default settings (DEFAULT)
- Display mode setting (INFO MODE)
- LAP (LAP activation/display/deletion)
- PIN CODE (enter/change)

- DRL CONTROL (AUTO/ MANUAL setting) (active only if the DRL lights are available)
- Display backlighting (BACKLIGHT)
- Date setting (DATE SET)
- Clock setting (CLOCK SET)
- Service information indication (INFO SERVICE): distance or time until next Oil Service, Desmo Service and Annual Service
- Unit setting (Speed Temperature Fuel consumption) (UNITS SETTING)
- Bluetooth setting, pairing and deleting any paired devices – active only if available (BLUETOOTH).





Setting menu - riding mode (RIDING MODE)

All settings of every riding mode can be customised. Enter the Setting Menu.

Select "RIDING MODE" option by pressing button (1) or (2). Once function is highlighted, press button (4). You open the "RIDING MODE" menu. Select the desired riding mode (SPORT, TOURING, URBAN), by pressing button (1) or (2). Once the desired mode is highlighted, press button (4). You open the selected riding mode customisation Menu.

While if you highlight "EXIT" and press button (4) you quit the sub-menu and go back to previous page.





The parameters that can be customised for every riding mode are the following:

- ENGINE
- DTC
- ABS
- DWC
- DQS (if present)

Press buttons (1) and (2) to highlight the customisable parameters one by one: in particular, use button (1) to highlight the following item and button (2) to highlight the previous item.


After highlighting the required parameter, press button (4) to open the corresponding menu page. Any parameter change made is saved and remains in the memory also after a battery-off.

The riding parameters set by Ducati can be restored for each single riding mode through the DEFAULT Function.

If you highlight "EXIT" and press button (4) you exit the sub-menu and go back to previous page.

Attention

Changes should only be made to the parameters by people who are experts in motorcycle set-up; if the parameters are changed accidentally, use the DEFAULT or ALL DEFAULT function to restore factory settings.



Setting menu - riding mode- setting the engine (ENGINE)

This function customises engine power associated with each riding mode.


Enter the Setting Menu. Select "RIDING MODE" option by pressing button (1) or (2).

Once function is highlighted, press button (4). You open the "RIDING MODE" menu.

Select the desired riding mode (SPORT, TOURING, or URBAN) from the drop-down menu, by pressing button (1) or (2). Once the desired mode is highlighted, press button (4).

You open the selected riding mode customisation Menu.

Select the parameter to be customised (ENGINE) from the drop-down menu, by pressing button (1) or (2). Once the desired parameter is highlighted, press button (4).



When entering the function, currently set engine power is indicated on the right (above the word EXIT) (e.g.: MEDIUM).


The central drop-down menu lists the available customisation options:

- LOW
- MEDIUM
- HIGH

Press buttons (1) and (2) to highlight the available power options one by one: in particular, use button (2) to highlight the following item and button (1) to highlight the previous item.

Once the desired power level is highlighted, press button (4) to highlight MEMORY in orange. To save the new setting, hold button (4) for two seconds while the message MEMORY is highlighted in orange.

If storage is successful, MEMORIZED will be highlighted in green for two seconds, power level will be refreshed and then EXIT will be highlighted in green.



Setting menu - riding mode- setting the DTC (DTC)

This function disables or sets DTC level for the selected riding mode.


Enter the Setting Menu. Select "RIDING MODE" option by pressing button (1) or (2). Once function is highlighted, press button (4).

You open the "RIDING MODE" menu. Select the desired riding mode (SPORT, TOURING, or URBAN) from the drop-down menu, by pressing button (1) or (2).

Once the desired mode is highlighted, press button (4).

You open the selected riding mode customisation Menu.

Select the parameter to be customised (DTC) from the drop-down menu, by pressing button (1) or (2). Once the desired parameter is highlighted, press button (4).




When entering the function, the currently set DTC level or status is indicated on the right (above the word EXIT) (e.g.: ON - 05, i.e. level 05). Customisation options are indicated on the central drop-down menu: levels 1 to 8 and status OFF.

Note

If DTC is set to OFF, also the DWC will be automatically set to OFF. The DWC will hence be greyed and not selectable.

Once the desired new setting is highlighted, press button (4) to highlight MEMORY in orange. To save the new setting, hold button (4) for two seconds while the message MEMORY is highlighted in orange.

If storage is successful, MEMORIZED will be highlighted in green for two seconds, set level or status will be refreshed and then EXIT will be highlighted in green.




Setting menu - riding mode- setting the ABS (ABS)

This function disables or sets ABS level for the selected riding mode. Enter the Setting Menu. Select "RIDING MODE" option by pressing button (1) or (2).

Once function is highlighted, press button (4). You open the "RIDING MODE" menu. Select the desired riding mode (SPORT, TOURING, or URBAN) from the drop-down menu, by pressing button (1) or (2).

Once the desired mode is highlighted, press button (4). You open the selected riding mode customisation Menu. Select the parameter to be customised (ABS) from the drop-down menu, by pressing button (1) or (2). Once the desired parameter is highlighted, press button (4).




When entering the function, the currently set ABS level or status is indicated on the right (above the word EXIT) (e.g.: ON - 03, i.e. level 03).

Customisation options are indicated on the central drop-down menu: levels 1 to 3.

Press buttons (1) and (2) to highlight the levels one by one: in particular, use button (1) to highlight the following item and button (2) to highlight the previous item.

Once desired level is selected, press CONFIRM MENU button (4) to highlight MEMORY item. Once the desired new setting is highlighted, press button (4) to highlight MEMORY in orange. To save the new setting, hold button (4) for two seconds while the message MEMORY is highlighted in orange.

If storage is successful, MEMORIZED will be highlighted in green for two seconds, set level or status will be refreshed and then EXIT will be highlighted in green.



Setting menu - riding mode- setting the DWC (DWC)

This function disables or sets DWC level for the selected riding mode.


Enter the Setting Menu. Select "RIDING MODE" option by pressing button (1) or (2).

Once function is highlighted, press button (4). You open the "RIDING MODE" menu. Select the desired riding mode (SPORT, TOURING, or URBAN) from the drop-down menu, by pressing button (1) or (2).

Once the desired mode is highlighted, press button (4).

You open the selected riding mode customisation Menu.

Select the parameter to be customised (DWC) from the drop-down menu, by pressing button (1) or (2). Once the desired parameter is highlighted, press button (4).




When entering the function, the currently set DWC level or status is indicated on the right (above the word EXIT) (e.g.: ON - 05, i.e. level 05). Customisation options are indicated on the central drop-down menu: levels 1 to 8 and status OFF.

Note

If DTC is set to OFF, also the DWC will be automatically set to OFF. The DWC will hence be greyed and not selectable.

Once the desired new setting is highlighted, press button (4) to highlight MEMORY in orange. To save the new setting, hold button (4) for two seconds while the message MEMORY is highlighted in orange.

If storage is successful, MEMORIZED will be highlighted in green for two seconds, set level or status will be refreshed and then EXIT will be highlighted in green.



Setting menu - riding mode- setting the DOS (DOS)

This function allows disabling or enabling the DQS for each riding mode, only if the feature is available on board the vehicle.


Enter the Setting Menu. Select "RIDING MODE" option by pressing button (1) or (2).

Once function is highlighted, press button (4). You open the "RIDING MODE" menu. Select the desired riding mode (SPORT, TOURING, or URBAN) from the drop-down menu, by pressing button (1) or (2).

Once the desired mode is highlighted, press button (4).

You open the selected riding mode customisation Menu.

Select the parameter to be customised (DQS) from the drop-down menu, by pressing button (1) or (2). Once the desired parameter is highlighted, press button (4).




When entering the function, the currently set DQS level or status is indicated on the right (above the word EXIT) (e.g.: OFF).

The central drop-down menu lists the available customisation options: "OFF" and "UP/DOWN". Press buttons (1) and (2) to highlight the available options one by one: in particular, use button (1) to highlight the following item and button (2) to highlight the previous item.

Once desired level is selected, press CONFIRM MENU button (4) to highlight MEMORY item. Once the desired new setting is highlighted, press button (4) to highlight MEMORY in orange. To save the new setting, hold button (4) for two seconds while the message MEMORY is highlighted in orange.

If storage is successful, MEMORIZED will be highlighted in green for two seconds, set level or status will be refreshed and then EXIT will be highlighted in green.



Setting menu - riding mode - restore all values for each single riding mode (DEFAULT)

This function allows restoring the default values set by Ducati for the parameters associated to a specific riding mode.


Enter the Setting Menu. Select "RIDING MODE" option by pressing button (1) or (2).

Once function is highlighted, press button (4). You open the "RIDING MODE" menu.

Select the desired riding mode (SPORT, TOURING, or URBAN) from the drop-down menu, by pressing button (1) or (2). Once the desired mode is highlighted, press button (4).

You open the selected riding mode customisation Menu.

Select DEFAULT option, by pressing button (1) or (2). Once desired parameter is highlighted, keep button (4) pressed for two seconds.



It will take three seconds to restore parameters, during which the display will show "WAIT...". Once procedure is completed, "OK" will appear for two seconds to confirm that default parameters have been restored and the message EXIT will be highlighted.

To exit the menu and go back to previous page, select "EXIT" and press button (4).

Note


If the DEFAULT option cannot be selected, it means that all parameters of the riding mode are already in the "Default" condition.

Setting menu - riding mode - value reset (ALL DEFAULT)

This function allows restoring the default values set by Ducati for all the parameters associated to all riding modes.

To gain access to this function, enter the Setting Menu, use button (1) or (2) to select RIDING MODE and press button (4). Then use button (1) or (2) to select ALL DEFAULT and keep button (4) pressed for two seconds.

Note If "ALL DEFAULT" option cannot be selected, it means that all parameters for all riding modes are already in the "Default" condition.




Setting Menu - display mode setting (INFO MODE)

The display mode can be customised by selecting one of the four available display modes: TRACK. FULL. CITY and CORE.

The default mode set by Ducati is CORE.

It is possible to select a mode different from the set one.

To select the display mode open the Setting Menu. Select INFO MODE option by pressing button (1) or (2). Once function is highlighted, press button (4).



Enter the INFO MODE menu.


To select a layout, press button (1) or button (2). Once mode is highlighted, press button (4). The selected option is stored, current mode indication is refreshed and the EXIT option is automatically highlighted. Press button (4) to go back to previous display mode.

By selecting DEFAULT, the display mode of all Riding modes becomes the CORE mode. By selecting RIDING MODE, the display mode becomes:

- the TRACK one for the SPORT Riding mode;
- the FULL one for the TOURING Riding mode;
- the CITY one for the URBAN Riding mode.

By selecting FULL, the display mode of all Riding modes becomes the FULL mode.

By selecting CITY, the display mode of all Riding modes becomes the CITY mode.





Setting menu - lap time (LAP)

To open the LAP function menu, enter the Setting Menu. Select LAP option, by pressing button (1) or (2). Once function is highlighted, press button (4). You open the LAP Menu.

The menu allows you to:

- OFF: disable the LAP function;
- ON: enable the LAP function;
- LAP DATA: view LAPs previously recorded by means of the "LAP recording" function;
- ERASE ALL: delete all recorded LAPs.





Displaying the stored Laps

To view the stored LAPs, you must enter the LAP menu.

Select "LAP DATA" option, by pressing button (1) or (2). Once function is highlighted, press button (4). When you enter the function, the following is displayed:

- TIME followed by the recorded lap time;
- SPEEDMAX followed by the top speed reached during the lap;
- RPMMAX followed by the maximum RPM value reached during the lap;
- The message LAP followed by the number of the LAP (e.g.: LAP 01).


Press buttons (1) and (2) to highlight stored LAPs one by one; in particular: use button (2) to view next lap (laps are displayed in increasing order, i.e. LAP 01 ... LAP 02 ... LAP 03 LAP 15), and then highlight EXIT; use button (1) to view the previous lap (laps are displayed in decreasing order, i.e. LAP 15 ... LAP 14 ... LAP 13 LAP 01), and then highlight EXIT. To exit the menu and go back to previous page, select EXIT and press button (4).

Note

The MAX stored speed is reached during lap (increased by 5%).

Note

If the memory is empty, the display shows the lap timer reading "-----", MAX RPM = ----- and MAX speed = -----



Erasing stored Laps

To delete the stored LAPs, you must enter the LAP menu.


LAPs can be erased from the LAP menu or from the LAP viewing page (LAP DATA).

Select "ERASE ALL" option, by pressing button (1) or (2). Once function is highlighted, press CONFIRM MENU button (4).

User must confirm deletion by pressing button (4) for two seconds.

After two seconds, the instrument panel display shows:


- WAIT... for two seconds;
- and then ERASE OK for 2 seconds to inform about the result of the deletion process.



Deletion is one single command that erases all stored laps.

After deletion, the Laps 01 to 15 are displayed with all parameters showing an indefinite value "-" (time = -' - -'' - - , rpm = - - - - - , speed = - - -).

To exit the menu and go back to previous page, select EXIT and press button (4).



Setting menu - pin code activation (PIN CODE)

This function allows the user to activate or modify the PIN CODE.

The PIN CODE is initially not present in the motorcycle, it must be activated by the user by entering his/her 4-digit PIN in the instrument panel, otherwise the motorcycle cannot be started temporarily in the case of a malfunction.

To activate this function, refer to "Entering the PIN CODE" procedure.

To change the PIN refer to "Changing the PIN CODE" procedure.


In order to temporarily start the motorcycle in case of malfunction, please refer to the Vehicle Overriding procedure page 82.

Attention

The motorcycle owner must activate (store) the PIN code; if there is already a stored PIN, contact an Authorised Ducati Dealer to have the function "reset". To perform this procedure, the Authorised Ducati Dealer may ask you to demonstrate that you are the owner of the motorcycle.

Activating the PIN CODE

To activate the PIN CODE function and enter your own PIN CODE you must open the Setting Menu. Select PIN CODE option, by pressing button (1) or (2). Once function is highlighted, press button (4). You open the PIN CODE menu.




When entering the function, the display shows the message INSERT NEW PIN CODE followed by the first digit in green and three dashes "0 - - - ".

Entering the code:

- 1) Press button (4), only one digit is highlighted in green indicating "0";
- 2) Each time you press the button (2) the displayed number increases by one (+ 1) up to "9" and then starts back from "0".
- Each time you press the button (1) the displayed number decreases by one (-1) up to "1" and then starts back from "0":
- 4) To confirm the number, press the button (4);

Repeat the procedures until you confirm all the 4 digits of the PIN CODE.




When you press button (4) to confirm the fourth and last digit, the instrument panel highlights MEMORY item.

To save the new setting, hold button (4) for two seconds while the message MEMORY is highlighted in orange.

If storage is successful, MEMORIZED will be highlighted in green for 1 second, and then EXIT will be highlighted in green.

Once the first PIN CODE is stored, this menu page is no longer available and is replaced by the page for changing the PIN CODE. The page for entering the very first PIN CODE is active and available again only in case the PIN CODE function is reset (but this is only possible at a DUCATI Authorised Service Centre).



Setting menu - pin code modification (PIN CODE)


To change the existing PIN CODE and activate a new one, you must open the Setting menu. Select "PIN CODE" option, by pressing button (1) or (2). Once function is highlighted, press button (4). You open the "PIN CODE" menu. When opening the function, the screen displays INSERT OLD PIN CODE and three dashes "0 - - -", the first digit "0" is highlighted in green.

Entering the "old" code:


- Press button (4), only one digit is highlighted in green indicating "0";
- 2) Each time you press the button (2) the displayed number increases by one (+ 1) up to "9" and then starts back from "0";
- 3) Each time you press the button (1) the displayed number decreases by one (-1) up to "1" and then starts back from "0";
- 4) To confirm the number, press the button (4);

Repeat the procedures until you confirm all the 4 digits of the PIN CODE.

When you press button (4) to confirm the fourth and last digit:




- if the PIN is not correct, the instrument panel displays WRONG for 3 seconds and then highlights the string of four dashes "- - - -" for the OLD PIN to allow you to try again;
- if the PIN code is correct, the instrument panel displays CORRECT for 3 seconds, the screen displays INSERT NEW PIN CODE and four dashes "----", the first of which is highlighted in green, for the user to enter the new PIN CODE.



Entering the "new" code:

- 1) Press button (4), only one digit is highlighted in green indicating "0":
- Each time you press the button (2) the displayed number increases by one (+1) up to "9" and then starts back from "0":
- Each time you press the button (1) the displayed number decreases by one (-1) up to "1" and then starts back from "0":
- 4) To confirm the number, press the button (4)

Repeat the procedures until you confirm all the 4 digits of the PIN CODE.




When you press button (4) to confirm the fourth and last digit, the instrument panel highlights MEMORY item.

To save the new setting, hold button (4) for two seconds while the message MEMORY is highlighted in orange.

If storage is successful, MEMORIZED will be highlighted in green for two seconds, and then EXIT will be highlighted in green.

If settings have not been saved, the instrument panel highlights again the string of four dashes "----" of the NEW PIN to allow the rider to try again and enter a new code.

To exit the menu and go back to previous page, select "EXIT" and press button (4).




Setting menu - DRL light mode setting (DRL CONTROL)

This function, active only if the DRL is available, allows the user to choose the DRL status: AUTO or MANUAL

Enter the Setting Menu. Select "DRL CONTROL" option, by pressing button (1) or (2). Once function is highlighted, press button (4).


Enter the "DRL CONTROL" menu.



When entering the function on the left, the display will show the DRL settings: AUTO, MANUAL whereas on the right (above the word EXIT) the currently set mode.

Press buttons (1) and (2) to highlight the available DRL status: in particular, use button (2) to highlight the following item and button (1) to highlight the previous item. Once the desired mode is selected, press button (4) to confirm. The instrument panel activates the selected mode and highlights the corresponding name.


When choosing the AUTO mode of the DRL lights, the high and/or low beams are automatically switched from the DAY mode to the NIGHT mode and vice versa according to the ambient light. To exit the menu and go back to previous page, select EXIT and press button (4).



Setting menu - tyre setting and drive ratio (TYRE CALIBRATION)

This function allows the user to run the procedure for calibrating and teaching in the tyre rolling circumference and final drive ratio.

Enter the Setting Menu. Select "TIRE CALIBRATION" option by pressing button (1) or (2). Once function is highlighted, press button (4). You open the "TIRE CALIBRATION" menu.



As you enter this function, the instrument panel displays the following indications (Fig 160):

- START
- DEFAULT
- EXIT

"DEFAULT" option is only available if the current calibration is not the default one.


Use buttons (1) and (2) to scroll through the available items.

To run a new calibration you shall highlight "START" and press button (4) for 2 seconds.

Then the instrument panel displays on the LH side the red message "READY", the message "KEEP SPEED" with speed range and the gear to be maintained by the user to complete the teach-in procedure (Fig 161). While on the RH side is the reference Riding Mode, current speed and gear engaged.

Important

The teach-in procedure is allowed only at a vehicle speed between 49 Km/h (30 mph) and 51 Km/h (32 mph) in the 2nd gear.



READY
KEEP SPEED
49-51 km/h
AND GEAR 2

km/h
Gear
2

When the rider complies with the required conditions of vehicle speed and gear displayed, the instrument panel starts system calibration: all previous information will be displayed showing "IN PROGRESS" instead of "READY" (Fig 162).

Calibration is performed by keeping speed and gear within the indicated range for 5 seconds.

If the teach-in procedure is completed correctly, the instrument panel shows "COMPLETED" (Fig 163) followed by the previous screen after a few seconds.

Note
During the calibration proces

During the calibration procedure, if the vehicle speed exceeds 62 mph (100 km/h), the procedure will stop.

Note

During calibration, the procedure can be aborted and user can go back to standard screen by pressing button (1) for 2 seconds.

Note Note

If during the calibration procedure a vehicle key-off is performed, the procedure will stop and end with negative result.

TIRE SETTING

IN PROGRESS KEEP SPEED 49-51 km/h AND GEAR 2

km/h

km/h

50
iear 2

SPORT

Fig 162

TIRE SETTING

COMPLETED KEEP SPEED 49-51 km/h AND GEAR 2 SPORT

50

Gear 2

Fig 163

If the calibration procedure is aborted by the user, the instrument panel shows "ABORTED" (Fig 164) followed by the previous screen after a few seconds.

If, on the other hand, an error or malfunction occurs during the calibration procedure, the instrument panel shows "FAILED" (Fig 165) followed by the previous screen after a few seconds.

TIRE SETTING

ABORTED KEEP SPEED 49-51 km/h AND GEAR 2

km/h

km/h

42

SPORT

Gear 2

Fig 164

TIRE SETTING

FAILED KEEP SPEED 49-51 km/h AND GEAR 2 SPORT

42

Gear 2

Fig 165

To reset to the default settings, use buttons (1) and (2) to select "DEFAULT" (Fig 160) and press button (4).

Then, the instrument panel shows "DEFAULT PLEASE WAIT..." (Fig 166) and after a while "DEFAULT OK" (Fig 167) for 2 seconds, then followed by the previous screen.

TIRE SETTING

DEFAULT PLEASE WAIT...

Fig 166


TIRE SETTING

DEFAULT DEFAULT OK

Fig 167

Setting menu - setting the backlighting (BACKLIGHT)

This function allows the user to choose the background of the instrument panel. Enter the Setting Menu. Select "BACKLIGHT" option, by pressing button (1) or (2). Once function is highlighted, press button (4). You open the "BACKLIGHT" menu.




When entering the function, available backlighting options are indicated on the left: DAY, NIGHT, AUTO, while currently selected option is indicated on the right (above the word EXIT).

Press buttons (1) and (2) to highlight the instrument panel backlighting options one by one: in particular, use button (2) to highlight the following item and button (1) to highlight the previous item. Once the desired backlighting option is highlighted, press button (4) to confirm. The instrument panel immediately activates the option selected by the user and highlights the corresponding name. To exit the menu and go back to previous page, select EXIT and press button (4).

Select DAY (day mode) to permanently set display "white" background for improved readability - recommended in conditions of strong ambient light. Select NIGHT (night mode) to permanently set display black background for dimmed visibility - recommended in case of poor ambient light and/or at night.

Select AUTO (automatic mode) to automatically adjust background colour according to ambient light (detected by a sensor).



It will be "white" for better visibility with high ambient light and "black" for a dimmed visibility with low ambient light.

Setting menu - setting the date (DATE SET)


This function allows user to set or change the date. Enter the Setting Menu.

Select "DATE SET" option, by pressing button (1) or (2).

Once function is highlighted, press button (4).

Important

Every time the battery is disconnected, the date is reset and must be set again.



When entering the function, available settings are indicated on the left: YEAR, MONTH, DAY, while current date is indicated on the right (e.g.: 2014/08/02).

Year setting


Select "YEAR" option, by pressing button (1) or (2). Once highlighted, press CONFIRM MENU button (4).

Year value starts flashing.

Press button (1) to decrease year value by 1 unit: 2099, 2098, ... 2000, 2099.

Press button (2) to increase year value by 1: 2000, 2001. 2099. 2000.

Once you reach the value to be set, press button (4) and the set year will stop flashing.



Month setting


Select "MONTH" option, by pressing button (1) or (2). Once option is highlighted, press button (4).

Month value starts flashing.

Press button (1) to decrease month value by 1 unit: 12, 11, \dots 01, 12.

Press button (2) to increase month value by 1: 01, 02, \dots 12, 01.

Once you reach the value to be set, press button (4) and the set month will stop flashing.




Day setting

Select "DAY" option, by pressing button (1) or (2). Once option is highlighted, press button (4). Day value starts flashing.

Press button (1) to decrease day value by 1 unit: 31, 30, ... 01, 31.


Press button (2) to increase day value by 1: 01, 02, \dots 31, 01.

Once you reach the value to be set, press button (4) and the set day will stop flashing.




Storing the date

To store set/modified date, select MEMORY using buttons (1) and (2) and press button (4) for 2 seconds. The instrument panel will display MEMORIZED for two seconds and then automatically highlight EXIT.



If date is not correct, the instrument panel will display "WRONG DATE" flashing for three seconds and then will automatically highlight EXIT, while date is indicated as "---- / -- " steady. It is still possible to set a new date.

To go back to previous page, press button (4) when EXIT is highlighted.




Setting menu - Setting the time (CLOCK SET)

This function allows user to set or adjust the time. Enter the Setting Menu. Select "CLOCK SET" option, by pressing button (1) or (2).

Once function is highlighted, press button (4). You open the "CLOCK SET" Menu. $\begin{tabular}{ll} \end{tabular}$

Note

Every time the battery is disconnected, the clock is reset and must be set again by the user.



When entering the function, available settings are indicated on the left: AM / PM, HOURS, MINUTES, while set time is indicated on the right (e.g.: AM 10: 30).

To exit the menu and go back to previous page, select EXIT and press button (4).


Setting AM/PM

Select "AM/PM" option, by pressing button (1) or (2). Once highlighted, press CONFIRM MENU button (4).

The value will start flashing.

Select AM or PM option, by pressing button (1) or (2) respectively.

Once you reach the value to be set, press button (4) and the set value will stop flashing.




Setting the hours

Select "HOURS" option, by pressing button (1) or (2). Once option is highlighted, press button (4). Hour value starts flashing.

Press button (1) to decrease hour value by 1 unit: 12, 11, ... 1, 12.

Press button (2) to increase hour value by 1: 12, 1, 12.

Once you reach the value to be set, press button (4) and the set hour value will stop flashing.



Setting the minutes

Select "MINUTES" option, by pressing button (1) or (2).


Once highlighted, press CONFIRM MENU button (4).

Minute value starts flashing.

Press button (1) to decrease minute value by 1 unit: 59, 58, ... 00, 59.

Press button (2) to increase minute value by 1: 00, 01, \dots 59, 00.

Once you reach the value to be set, press CONFIRM MENU button (4) and the set minutes will stop flashing.



Setting menu - service information (INFO SERVICE)

This Function allows viewing information about the remaining time or mileage until the next Oil Service, Desmo Service and Annual Service

To view them, enter the Setting Menu, use button (1) or (2) to select INFO SERVICE and press button (4). Available information:

- DESMO SERVICE: indicates the km (or mile) count-down to the next DESMO SERVICE;
- OIL SERVICE: indicates the km (or mile) countdown to the next OIL SERVICE;
- ANNUAL SERVICE: indicates the ANNUAL SERVICE expiration date.





Fig 180




Setting menu - setting the unit of measurement (UNITS SETTING)

This function allows you to change the units of measurement of the displayed values, regardless of the Country configuration.

To manually set the units of measurement, you must enter the Setting Menu.

Select "UNITS SETTING" option, by pressing button (1) or (2). Once function is highlighted, press CONFIRM MENU button (4).


You enter the "UNITS SETTING" menu.



When entering the function, the display shows on the left the list of values for which units of measurements can be set:

- SPEED;
- TEMPERATURE:
- fuel consumption (CONSUMPTION);
- reset to automatic settings (DEFAULT).

To exit the menu and go back to previous page, select EXIT and press button (4).



Setting the units of measurement: Speed

This function allows to change the units of measurement of speed (and hence even the ones of distance travelled).


You open the "UNITS SETTING" menu, as described on the previous pages.

Select "SPEED" option, by pressing button (1) or (2). Once function is highlighted, press CONFIRM MENU button (4). You open the "SPEED" menu. When you enter the function, the current unit of measurement is displayed, followed by the list of the possible units: km/h, mph.

Press buttons (1) and (2) to highlight the units of measurement one by one: in particular, use button (1) to highlight the following item and button (2) to highlight the previous item. Select the required unit of measurement and then press the CONFIRM MENU button (4) to confirm: the selected unit is stored and the EXIT option is highlighted.

The selected unit of measurement will be used by the instrument panel for the following indications:

- Motorcycle speed and Average speed (km/h or mph);
- Odometer, Trip1, Trip2 and Range (km or mi).



Setting the units of measurement: Temperature

This function allows you to change the units of measurement of the temperature.

You open the "UNITS SETTING" menu, as described on the previous pages.


Select "TEMPERATURE" option, by pressing button (1) or (2).

Once function is highlighted, press CONFIRM MENU button (4).

You open the "TEMPERATURE" menu. When you enter the function, the current unit of measurement is displayed, followed by the list of the possible units: °C, °F.

Press buttons (1) and (2) to highlight the units of measurement one by one: in particular, use button (1) to highlight the following item and button (2) to highlight the previous item. Select the required unit of measurement and then press the CONFIRM MENU button (4) to confirm: the selected unit is stored and the EXIT option is highlighted.

The selected unit of measurement will be used by the instrument panel for the following indications:



Engine coolant temperature and ambient air temperature.

Setting the units of measurement: Fuel consumption

This function allows you to change the units of measurement of the fuel consumption.

You open the "UNITS SETTING" menu, as described on the previous pages.

Select "CONSUMPTION" option, by pressing button (1) or (2).


Once function is highlighted, press CONFIRM MENU button (4). You open the "CONSUMPTION" menu.

When you enter the function, the current unit of measurement is displayed, followed by the list of the possible units: L / 100km, km / L, mpg (UK), mpg (USA).

Press buttons (1) and (2) to highlight the units of measurement one by one: in particular, use button (1) to highlight the following item and button (2) to highlight the previous item.

Select the required unit of measurement and then press the CONFIRM MENU button (4) to confirm: the selected unit is stored and the EXIT option is highlighted.

The selected unit of measurement will be used by the instrument panel for the following indications:




• Instantaneous fuel consumption and Average fuel consumption.

Setting the units of measurement: Reset to automatic settings

This function allows you to restore the automatic settings for the units of measurement of all indications displayed on the instrument panel. You open the "UNITS SETTING" menu, as described on the previous pages. Select "ALL DEFAULT" option, by pressing button (1) or (2). Once function is highlighted, press CONFIRM MENU button (4) for two seconds. WAIT... will be displayed for two seconds, and then the UNITS SETTING menu page with the EXIT option highlighted.

To exit the menu and go back to previous page, select EXIT and press button (4).



Setting menu - turn indicator mode setting (TURN INDICATORS)

This function allows user to set the strategy for automatically switching off the turn indicators based on lean angle, vehicle speed and distance run to automatic mode or manual mode.


Enter the Setting Menu. Select "TURN INDICATORS" option, by pressing button (1) or (2). Once function is highlighted, press button (4). You open the "TURN INDICATORS" menu.

When opening this function, "AUTO" and "MANUAL" settings are indicated on the LH side, while current setting is displayed on the RH side, above the "EXIT" option.

Use buttons (1) and (2) to select the desired setting:

- by selecting "AUTO", the system activates the self-cancel strategy of the turn indicators;
- by selecting "MANUAL", the system disabled the self-disabling strategy of the turn indicators (so the turn indicators can be turned off manually only by pressing the dedicated button).

Once the desired function is highlighted, press button (4) to set the selected mode.



To exit the menu and go back to previous page highlight the "EXIT" indication and press button (4).

Note

This setting ("AUTO" or "MANUAL") remains stored even after Key-Off. In the event of an interruption of the power supply from the battery (Battery Off), when power is restored at the next Key-On, the mode will always be set by default to the "AUTO" mode.

Note
The strategy for automatically switching off the turn indicators is not active if all turn indicators are on at the same time (Hazard function).

Setting menu - setting Bluetooth devices - accessory (BLUETOOTH)


This function allows pairing and/or deleting any paired Bluetooth devices (Diavel S).
To do this, you must enter the Setting Menu.
Select "BLUETOOTH" option, by pressing button (1) or (2). Once function is highlighted, press button (4). You enter the "BLUETOOTH" menu, which is active

The BLUETOOTH menu is not available if the player is active or being used, or when there is an incoming call, a call is in progress or during recall.

only if the Bluetooth function is active.

To carry out the pairing procedure, refer to "Pairing of a new device".

To delete any paired devices, refer to "Deleting a paired device".



Pairing of a new device

This function allows user to associate (pair) one or several Bluetooth devices by running the "PAIRING" control

Set the Bluetooth device to ensure it can be detected by the control unit, so turn device on and make it visible to other devices

A Bluetooth device in visible mode transmits a wireless signal allowing it to be detected by other devices. This function is called pairing mode. The motorcycle is equipped with a Bluetooth control unit that works as a hub between the various supported electronic devices relying on a Bluetooth communication interface

Attention

Smartphone and Bluetooth Headset device manufacturers may incorporate certain changes within the standard protocols over the course of the lifecycle of the device (Smartphones and Earphones).

Attention

These changes are outside the control of Ducati and may result in Bluetooth Headset devices functionality becoming impaired (sharing Music, multimedia player, etc.) and may equally affect some types of Smartphones (depending on supported Bluetooth profiles). This is why Ducati cannot quarantee multimedia player proper operation for:

- any earphones not coming with the "Ducati Kit part no. 981029498":
- any Smartphones not supporting the required Bluetooth profiles (even though paired to earphones coming with the "Ducati Kit part no. 981029498").

Attention

In case of interference or noise due to particular conditions of the external environment, the Ducati earphone kit part no. 981029498 also allows sharing the music being played directly from rider helmet to passenger helmet (for further details please refer to the manual of the earphones coming with the Ducati kit part no. 981029498).

Note

The Ducati kit part no. 981029498 can be purchased separately at a Ducati Dealer or Authorised Service Centre.

Upon the first access, the first default displayed label will be "PAIRING" and on the left side the list of the device already paired.


The Pairing function is activated by pressing button (4): this runs a search for all Bluetooth devices present within a certain range. Device search symbol is activated and message "WAIT..." is displayed. The pairing ends automatically when devices are detected within the range and shown in the list on the right.

If Pairing is not successful, "PAIRING LOST. PLEASE EXIT" message will be displayed. Now you can only quit, and then go back in to run a new Pairing procedure.

If Pairing is successful, as soon as Bluetooth devices are detected, their name is displayed in the device list on the right.

The list of devices found within the range during the Pairing stage does not include already paired devices, that are displayed in the list on the left.


If two or more Bluetooth devices have the same name, the list of the devices detected will include two or more labels with the same name. If one of the devices detected has no name, it is not included in the list of devices detected. During the search it is possible to scroll through the device list on the right by pressing buttons (1) and (2). In correspondence of the device that is to be paired, select "CONNECT" and press button (4) to pair it. To quit the Pairing stage, select EXIT and press button (4).



It is possible to pair up to:

- 2 smartphones;
- 1 navigator;
- 1 rider helmet;
- 1 passenger helmet.


If at least 5 devices have already been paired and the user attempts to run the Pairing, the following message will be displayed: "MAX 5 DEVICES CAN BE ASSOCIATED" and "REFER TO USER MANUAL". System automatically highlights DELETE indication for the first associated device and user can delete one or several devices (refer to Deleting associated devices) or quit using "EXIT".



When the device to be paired has been selected, the label in correspondence of that device replaces the word "CONNECTED" with "WAIT" and it is necessary to select the type of device to be paired. The display shows four icons that represent the available types. Types of devices can be:

- Smartphone;
- Rider helmet;
- · Passenger helmet;
- GPS navigation system.

Use buttons (1) and (2) to select the type and press button (4) to confirm.



Smartphone

To pair a Smartphone, the pairing procedure with the Bluetooth control unit requires user to enter a code (0000), which is only necessary the first time the device is paired with the Bluetooth control unit. In this case, during the pairing the display shows the PIN to be entered "INSERT PIN ON SMARTPHONE: 0000"

As soon as the user enters the PIN on the Smartphone, the device is paired and indicated in the list on the left

GPS navigation system

If you wish to pair a Bluetooth Navigator, the pairing procedure is completed on the navigator, by selecting on the latter the connection with the motorcycle Bluetooth control unit. In this case, during the pairing the display shows the message "CONNECT ON NAVI" that disappears when the connection between the control unit and the navigator is completed, and the name of the navigator is indicated in the list on the left.

If user does not complete the pairing procedure on the Navigator side within 90 seconds, pairing procedure cannot be completed.

If the navigator pairing is active for more than 90 seconds and so there have been errors in the procedure, it is not possible to select the detected devices. It is only possible to press on EXIT to abort the procedure if deemed necessary.

Once the pairing is completed, the name of the paired device is shown in the device list on the left: only the first characters of the device name are displayed.


Pairing deactivation takes place when guitting the function or when no more Bluetooth devices are detected

Attention
Ducati does not ensure a correct connection to the Ducati Multimedia System of Bluetooth navigators that are not provided in the following kits:

- Kit of Ducati Zumo satellite navigator 350
- Kit of Ducati Zumo satellite navigator 390
- Kit of Ducati Zumo satellite navigator 395

Note


The Ducati kits mentioned above can be purchased separately at a Ducati Dealer or Authorised Service Centre.



Deleting associated devices

From the Bluetooth Setting menu it is possible to access the list of the paired devices on the left. From the list of paired devices, user can select the device to be deleted by pressing button (1) or button (2). When the device is selected and the relevant DEL label is green, press button (4) for at least two seconds to eliminate the device from the paired device list


Select EXIT by pressing button (1) or (2) and pressing button (4) you quit the Bluetooth Setting Menu and go back to the main Setting Menu screen.




Setting menu - information (INFO)

This function allows displaying several useful details. To view the "INFO", enter the Setting Menu, use button (1) or (2) to select "INFO" and press button (4). Available information:

- BATTERY (battery voltage);
- RPM (engine rpm indication);
- BLUETOOTH version (Bluetooth module version).






LAP TIME

LAP

The instrument panel displays the LAP function status (LAP recording on or off).

LAP message at top left-hand side is on if the LAP function is active, and is off if the LAP function is not active; the same message will flash in the recording stage.

Considering that the FULL, CORE and CITY layouts show the values for this function in a similar to the TRACK layout, the example shown depicts the function in TRACK layout.



Assisted start (LAUNCH CONTROL - DPL)

This Function allows activating the assisted start function (called DPL - Ducati Power Launch).


By pressing button (12) it is possible to access the Launch Control menu only if the vehicle speed is \leq (equal to or less than) 5 Km/h (3.1 mph).

In the Launch Control menu, it is possible to select the desired DPL level (1, 2, 3) by pressing buttons (1) and (2), and to set the selected level by keeping button (4) pressed for two seconds.

Note

If no change is made in this menu within ten seconds, the instrument panel will set DPL to OFF and go back to the previous screen.

Once the DPL level is set, the instrument panel shows the wait screen for two seconds: during this time, if you press button (4) the wait phase is interrupted and the instrument panel displays the main screen and sets the DPL to OFF.




Note

If the DTC is set to "OFF", the DPL function can not be activated

If the DTC is set to OFF and you press button (12), the instrument panel shows for five seconds the indication DTC OFF - DPL NOT AVAILABLE: when the five seconds are over, the instrument panel goes back to the main screen


Note

If the instrument panel detects a control unit error when entering the DPL menu, regardless of the currently set display mode, it will show the blinking message LAUNCH CONTROL ERROR for three seconds and then again the main screen.





Note
If the available launches are finished, the instrument panel shows the message NO LAUNCHES AVAILABLE.



The Ducati Power Launch (DPL) helps the rider in the delicate sport starting phase from a standstill to control the power delivered by the vehicle.

The DPL system works with three intervention levels, each calibrated to offer a different start assist degree. The following table indicates the most suitable DPL intervention level depending on the various riding modes. All levels are to be intended optimised for OEM (Original Equipment Manufactured) tyres.

DPL level	Performance	Use
1	High	Use focused on the best performance for very expert riders. The system allows the wheelie and the rear wheel slipping, but reduces the speed at which these two situations take place.
2	Medium	Use for expert riders. The system reduces the tendency to wheelie and rear wheel slipping, besides intervening considerably in case these two situations take place.
3	Medium	Use for all kinds of riders. The system minimises the tendency to wheelie and rear wheel slipping, besides intervening considerably in case these two situations take place.

Attention

The DPL system is to be used exclusively on straight and level paths, on optimal grip conditions of the road

The DPL system is conceived to be used within a controlled environment or in a closed circuit. For safety reasons it must not be used in unsuitable places.

Starting procedure

The starting procedure basically consists of two phases:

- The first: with completely released clutch so that the torque transmitted to the ground depends on the clutch position and slipping:
- The second: with clutch not released so that the torque transmitted to the ground depends on the torque delivered by the engine.

The DPL system helps the rider to start from a standstill and during the first phase by automatically adjusting the torque delivered by the engine to keep the engine rpm at the ideal value to start. This allows the rider to concentrate only on the clutch release that must be progressive and "smooth" instead of fast or abruptly. The engine torque is adjusted also in

the second phase, by maximising the delivered power and limiting the vehicle wheeling or rear wheel slipping.

To preserve the clutch, the DPL system calculates in real time and shows in the dedicated menu on the instrument panel the number of starts that can be performed consecutively by decreasing it by one unit every time a start is completed. The DPL system increases the value by one unit according to the distance covered by the vehicle and the time during which the vehicle engine was on and off.

The DPL system allows performing other assisted starts only when the number of remaining starts is higher than zero.

Attention
Using the DPL system could reduce the useful life of the engine and transmission mechanical parts. The DPL system should be used only when the engine has reached the operating temperature.

To perform an assisted start with the DPL, the rider must first of all set the vehicle in the following condition:

- vehicle speed at zero;
- vertical position;
- engine on:

DTC set to ON

If the count of the residual assisted starts is above zero, the rider can select on the instrument panel the desired DPL level by accessing the DPL level menu by pressing button (12).

After selecting the level, the rider must pull the clutch, engage the first gear and fully open the throttle twistgrip.

If all operations indicated above have been performed, the DPL system will show a confirmation screen on the instrument panel indicating that the system is ready to start.

The rider must then release the clutch progressively by keeping the throttle twistgrip fully open. When the vehicle speed exceeds 20 km/h (12.4 mph). the instrument panel shows the standard screen while keeping the indication of the selected DPL system level for the entire duration of the start phase.

The DPL system is switched off when one of the following conditions is met after completely releasing the clutch:

- vehicle speed higher than 120 km/h (74.6 mph);
- third gear engaged.

The DPL system is switched off also if, after releasing the clutch, the rider decides to interrupt the start phase by closing the throttle and bringing the vehicle speed under 5 km/h (3.1 mph).

Attention

The system manages the power delivered by the engine but not the clutch lever release that remains under the control of the rider During the starting phase, an abrupt release of the clutch will prevent an optimal behaviour of the vehicle. Likewise, a prolonged activation of the clutch may overheat and thus damage it.

Attention

Attention
The rider position on the bike may influence the system behaviour.

Tips on how to select the intervention level

If level 3 is set, the DPL system intervenes by reducing the tendency to wheelie or rear wheel slipping during the starting phase. Levels 2 and 1 provide a limited intervention of the system.

To identify the DPL level most suitable to your riding style we recommend to activate the system, select level 3 and perform a start to become familiar with

the system. Then we recommend to try levels 2 and 1 in sequence until finding the best intervention.

If non-OEM tyres of a different size class are used or if the tyre size differs significantly from the original tyres, it may be that the system operation is compromised.

Attention
The DPL is a rider assist system. The system is designed to make riding easier and to enhance safety, but in no way relieves the rider of the obligation to drive responsibly and to maintain a high standard of riding in order to avoid accidents. whether caused by his own errors or those of other road users, through making emergency manoeuvres, in accordance with the prescriptions of the road traffic code

The rider must always be aware that active safety systems have a preventive function. The active elements help the rider control the motorcycle, making it as easy and safe to ride as possible. The presence of an active safety system should not encourage the rider to ride at speeds beyond the reasonable limits, not in accordance with the road conditions, the laws of physics, good riding standards and the requirements of the road traffic code

Cruise Control


Diavel 1260 is equipped with a system for maintaining the cruise speed: Ducati Cruise Control.

This function displays Cruise Control status and "target" speed.

The Cruise Control can be turned on/off by pressing the ON/OFF button (5). When the system is on, the Cruise Control light (A) on the instrument panel turns on.

Upon first activation, the Ducati Cruise Control system is in stand-by mode and is ready to receive the target speed value to be maintained automatically if the operating conditions are met (see below).

Considering that the TRACK, FULL and CITY layouts show the values for this function in a similar way to the CORE layout, the example shown depicts the function in CORE layout.




Once the system is on, it is possible to set the current speed as target speed by pressing the SET button (7). If no target speed had been previously set, it will be possible to set the current speed as target also by pressing the RES button (6) instead of button SET (7).

In this case, the system saves the vehicle current speed and keeps it without having to work on the twistgrip.

To confirm correct setting of cruise speed, the target speed is shown on the instrument panel for 5 seconds then followed by the SET icon.

In stand-by mode, if you press RES (6) and a target speed has been previously set and the operating conditions are met, the system starts working again and brings the vehicle to the last set target speed. Also in this case the instrument panel shows the target speed for 5 seconds.



It is possible to increase or decrease set cruise speed, by pressing buttons (6) and (7), respectively. Every "click" corresponds to a speed increase or decrease of 1 Km/h (0.62 mph).

By keeping the RES button (6) pressed, the target speed increases progressively.

By keeping the SET button (7) pressed, the target speed decreases progressively.

Each time the target speed is modified, this is shown for 5 seconds instead of the SET icon.

Important

In case of a long DTC (Traction Control) event, the Cruise Control will automatically turn off.

It is possible to enable the Ducati Cruise Control only if all the below conditions are met:

- second gear or higher engaged;
- vehicle speed higher than or equal to 50 Km/h (30 mph) or lower than or equal to 200 Km/h (125 mph).

The Ducati Cruise Control can be disabled as follows:

- 1) by pressing button (5);
- 2) by pulling the front brake lever;
- 3) by pressing the rear brake pedal;
- 4) by pulling the clutch lever.

Conditions 2-3-4 bring the system in stand-by mode: the Cruise Control light remains on. Condition 1 brings the system in OFF condition: the Cruise Control is switched off.

The Ducati Cruise Control system controls the vehicle speed only between 50 Km/h (30 mph) and 200 Km/h (125 mph).

Infotainment

Diavel S fits the Ducati Multimedia System (DMS) as standard, thanks to which the user can answer phone calls, select and listen to music tracks, and receive SMS notifications by means of the Bluetooth technology.


The instrument panel displays the Infotainment function status: Bluetooth activation and any connected devices (smartphone, earphones, navigator).

When the Bluetooth is active, the main screen displays the Bluetooth icon (A).

In the FULL and CITY modes all Infotainment functions are displayed; in the CORE and TRACK modes none of these functions is displayed but it is nevertheless possible to answer/reject/terminate calls using the relevant function buttons.

Attention

All data concerning the Infotainment (Player, access to Contact List, Name of devices, etc.) are managed for use of Western character sets.



If Bluetooth is active, apart from the Bluetooth icon, also connected device indication is displayed, such as smartphone, rider and passenger helmet earphones, Ducati GPS navigator.

It is possible to connect up to a maximum of 4 devices.

Phone


Use the PHONE function:

- to manage incoming calls by means of button (1) and button (2);
- to recall the last calling number within 5 seconds from call interruption (RECALL function).

○ Note

It is not possible to make a call by selecting the name/number from the contact list through the function buttons.

When there is an incoming call (B) the blue colour filling the rectangle is flashing; while, when you answer the call, the blue background stops flashing. In the TRACK and CORE layouts, when there is an incoming call, the instrument panel will not display the caller's name or number. The rider will hear the ringing tone through Bluetooth earphones upon any incoming call.



If there is an incoming call while the Player (E) is active, the latter is paused throughout the phone call and will resume operation when call is over.

To answer the call, press button (2).

To terminate the call, keep button (1) pressed for 2 seconds.


If main screen is set to FULL or CITY layout, during 5 seconds after hang-up, the rectangle corresponding to the Recall function is activated to allow the recall. After this 5 second time, the rectangle for the recall function is disabled.

To activate the Recall function within the 5 seconds, press button (2).

In TRACK and CORE layouts, no recall function is provided.

In case of missed calls from the moment the smartphone is connected to the bike to the moment it is disconnected, the missed call symbol will be displayed (timed) (C). The number of missed calls is not displayed.

In case there is at least one SMS/MMS/EMAIL not read from the moment the smartphone is connected to the bike to the moment it is disconnected, the unread message symbol will be displayed (timed) (D). The number of unread messages is not displayed.



Player

The Player can be activated in the FULL and CITY modes. If at least one Smartphone device is connected (blue icon on main screen), Menu 1 will include PLAYER OFF (F) option.

Only in the CITY display mode, press button (1) for 2 seconds to activate the Player, in correspondence of the PLAYER OFF item shown upon activation. The instrument panel shows the PLAYER ON item in Menu 1. The Player graphics is activated for both FULL and CITY modes: dedicated control panel and track name (E). If the Player is turned on, button (1), button (2) and button (4) can only be used to control the PLAYER.

If the Player is ON, but instrument panel is not receiving track name, it automatically pauses the track being played and the message NOT AVAILABLE is displayed instead of the track name.

Important

The Player function can not be activated through Menu 1 when a call is incoming, in progress or in recall.

Adjust volume as follows:


increase volume: press button (1);

decrease volume: press button (2).

The Player can be cyclically set to pause/play by pressing button (4) for two seconds. It is possible to skip to next track, pressing button (4): system will skip forward once every time button is pressed.

Press button (2) for two seconds to quit Player controls, although maintaining Player ON, in the current status.

The Player can be turned off by quitting the player control and pressing, within three seconds, button (1) for two seconds in correspondence of the PLAYER ON item: Menu 1 will show PLAYER OFF option.



F.A.Q.

1) Why don't I receive any notification of received e-mails?

E-mails are notified only if configured on the telephone source application. Check also that your phone supports the MAP profile.

If so, the DUCATI MULTIMEDIA SYSTEM, during the pairing phase, will send an access request to such profile which can be notified to the user explicitly (depending on the operating system) by requesting access authorisation to message notifications.

2) Why don't I receive any notification of received messages?

Check that your phone supports the MAP profile. If so, the DUCATI MULTIMEDIA SYSTEM, during the pairing phase, will send an access request to such profile which can be notified to the user explicitly (depending on the operating system) by requesting access authorisation to message notifications.

3) Earphones do not connect. Why?

If they have been already paired once, we recommend resetting the earphones and pair them again with the motorcycle (see earphones instruction manual).

4) When I receive a call, the instrument panel displays the caller number but not the name (despite being saved in the contact list).

Check that the phone supports the PBAP profile. If so, the DUCATI MULTIMEDIA SYSTEM, during the pairing phase, will send an access request to such profile which can be notified to the user explicitly (depending on the operating system) by requesting access authorisation to the phone contact list.

5) By activating the Player through the instrument panel, music does not start.

The activation depends on the phone settings. In this case, after activating the Player through the instrument panel, also start the music application on your Smartphone.

6) It happens that the music is played with continuous interruptions.

If the devices have just been connected, it may be that the Bluetooth control unit is still completing the connection phase with the concerned devices. It is furthermore necessary to activate the PBAP and MAP profiles. Therefore, in case of iOS, please refer to point 7). In case of Android, please refer to points 2)4)

7) I do not receive any message notification on my iPhone. Why?

Select Bluetooth in the Setting Menu. In the list "My devices" select "i" next to "Ducati Media System". Flag "Show notifications".

Service indication (SERVICE)

This indication shows the user that the motorcycle is due for service and must be taken to a Ducati Authorised Service Centre.

The service warning indication can be reset only by the Ducati Authorised Service Centre during servicing.

There are 3 types of scheduled maintenance interventions:

- OIL SERVICE ZERO: service at the first 600 mi (1000 km);
- OIL SERVICE and ANNUAL SERVICE: oil service or annual service (requiring the same maintenance operations);
- DESMO SERVICE

Attention

The ANNUAL SERVICE function is available (active) only if the date has been set.





Fig 208

OIL SERVICE zero warning

The first service warning is the Oil Service (OIL) zero and is triggered as soon as the odometer reaches the first 1,000 km (600 mi). Warning is displayed until "Reset" by the Ducati authorised service centre, during maintenance.




OIL SERVICE or ANNUAL SERVICE or DESMO SERVICE countdown indication

After Oil Service zero indication first reset (at 1,000 km - 600 mi), the instrument panel activates the following indications in yellow for 5 seconds upon Key-ON:

- the count of the mileage in miles (kilometres) remaining before the next OIL SERVICE (A) 600 mi (1000 km) earlier than the service threshold;
- the count of the days remaining before the next ANNUAL SERVICE (B) 30 days earlier than the service threshold;
- the count of the mileage in miles (kilometres) remaining before the next DESMO SERVICE (C) 600 mi (1000 km) earlier than the service threshold.

To know exactly the kilometres missing until the service threshold or maintenance date, it is possible to access the Setting menu and select the "INFO SERVICE" function.




OIL SERVICE or ANNUAL SERVICE or DESMO SERVICE indication

When the service threshold is reached, the warning for the type of service required is triggered:

- Oil Service (A):
- Annual Service (B);
- Desmo Service (C).


To know the kilometres missing until the service threshold or maintenance date, access the Setting menu and select the "INFO SERVICE" function. Required service warning is triggered and displayed in red until "Reset" by the Ducati authorised service centre, during maintenance.



Light mode indication (DRL)

The instrument panel indicates if the DRL control is set to AUTO, by showing the relevant black icon bearing the letter "A".

When DRL is in MANUAL mode, the instrument panel does not show any icon.



Viewing side stand status


The instrument panel shows the side stand status and if side stand is down/open, the icon SIDE STAND is displayed on a red background.

In case of Side stand sensor fault, the instrument panel will display the stand down/up indication with MIL light on.

If instrument panel does not receive side stand status, stand down/open SIDE STAND indication will flash to indicate an undefined status.

○ Note

With side stand down and gear engaged it is not possible to start the motorcycle. If you start with gearbox in neutral and then engage a gear with side stand down, the motorcycle turns off.



Warnings/Alarms (WARNING)


The instrument panel manages a number of warnings / alarms, aimed at giving useful information to the rider during use.

Upon Key-On, if there are active warnings the instrument panel displays the indication of the present warnings.

During normal vehicle operation, when a warning is triggered the instrument panel automatically displays the warning. When a warning is triggered. the indication remains well visible for 10 seconds ("large" icon) then becomes smaller ("small" icon). If several live warnings are present, the corresponding icons will be displayed one after the other and every one will stay on for 3 seconds.

Attention

If one or several warnings are triggered and, at the same time, the Generic Error light turns on, the small warning icon is not displayed on instrument panel until the Generic Error light stays on; warnings will only be displayed within the first 10 seconds as a large-size icon.



Ice

This function warns the rider when there might be ice on the road, due to the low external temperature. This warning turns on when temperature drops to 4°C (39°F) and turns off when temperature rises to 6°C (43°F).

Attention

This warning does not eliminate the possibility of icy road areas even with temperatures above 4°C (39°F); when ambient temperature is "low", ride responsibly, especially on road areas not exposed to sunlight and/or on bridges.





Fig 215


Low battery indication (LOW Battery)

This function warns the user that the status of the vehicle battery is low.

Warning is activated when battery voltage is approx. lower than/equal to 11.0 Volt.

Note

In this case, Ducati recommends charging battery in the shortest delay using the special instrument as engine could not be started.




Hands Free (HF) Key not acknowledged

The activation of this "warning" indicates that the Hands Free system does not detect the "active key" near the vehicle.

○ Note

In this case, Ducati recommends making sure that the active key is nearby (and that it was not lost) or that it works properly.




"Low" battery level of Hands Free (HF) key

The activation of this "warning" indicates that the Hands Free system has detected that the battery that permits the active key to communicate and turn the vehicle on is almost discharged.

Note

In this case, Ducati recommends changing battery in the shortest delay.


To change battery, refer to chapter "Keys".



Date setting

This function prompts the user to enter the date via the Setting menu.

Note
In this case Ducati recommends to stop and enter the calendar date using the function "DATESET".



Steering unlock error - Steering still locked

The activation of this "warning" indicates that the Hands Free System was not able to disengage the steering lock.

Attention

In this case, Ducati recommends switching vehicle off and on again (Key-Off / Key-On), keeping handlebar fully turned. If warning is still present (and steering does not "unlock"), contact a Ducati Authorised Service Centre.





Fig 220

Error warnings


The instrument panel manages error warnings in order to allow the rider to identify any abnormal motorcycle behaviour in real time.

Upon Key-On, in case of errors, the instrument panel turns on the MIL light (B) (in case of errors directly connected to the engine control unit) or the Generic Error light (A) (in case of any other errors). During normal operation, when an error is triggered,

During normal operation, when an error is triggered, the instrument panel turns on the MIL light (B) or the Generic Error light (A).

Attention

When one or more errors are displayed, always contact a Ducati Dealer or authorised Service Centre.





Main use and maintenance operations

Checking coolant level and topping up, if necessary

The expansion reservoir (1) is located under the tank. Check that the coolant level is between the MIN and MAX notches on the expansion reservoir side, on the motorcycle's left side.

To see the notches, turn handlebar to the right and check as specified after setting the vehicle perfectly level and in a vertical position.







Unscrew the filler plug (2) of the expansion reservoir, on the motorcycle's right side, and add ENI Agip Permanent Spezial antifreeze (do not dilute, use pure), until reaching the MAX level. Screw plug (2).

This type of mixture ensures the best operating conditions (the coolant starts to freeze at $-20 \, ^{\circ}\text{C}/-4 \, ^{\circ}\text{F}$).

Cooling circuit capacity: 2.5 cu. dm (litres) (0.66 gal). Turn handlebar to the left to reach the filler plug (2).

Attention
This operation must be performed with cold engine. Failure to observe the above recommendation may lead to coolant or hot vapour leakage with possible consequent severe burns.





Check clutch and brake fluid level

The level must not fall below the MIN marks on the respective reservoirs: for clutch fluid (1) and front brake fluid (2).


On the rear brake fluid reservoir (3), check that level is between the MIN and MAX reference notches. The clutch and front brake fluid tanks are represented in (Fig 226).


The rear brake tank is represented in (Fig 227). If level drops below the limit, air might get into the circuit and affect the operation of the system involved.

Engine oil and oil filters must be changed by a Ducati Dealer or Authorised Service Centre at the intervals specified in the scheduled maintenance chart contained in this manual, sub-section "Scheduled maintenance chart".

Brake system

If you find exceeding clearance on brake lever or pedal and brake pads are still in good condition, contact your Ducati Dealer or authorised Service Centre to have the system inspected and any air drained out of the circuit.





Attention

Brake and clutch fluid can damage paintwork and plastic parts, so avoid contact.

Hydraulic fluid is corrosive; it may cause damage and lead to severe injuries. Never mix fluids of different qualities. Check seals for proper sealing.

Clutch system

If the control lever has exceeding clearance and the transmission snatches or jams as you try to engage a gear, it means that there might be air in the circuit. Contact your Ducati Dealer or authorised Service Centre to have the system inspected and air drained out

Attention

Clutch fluid level will increase as clutch plate friction material wears down. Do not exceed the specified level (3 mm - 0.12 in above the minimum level).

Checking brake pads for wear

Check brake pads wear through the inspection hole in the callipers.


Change both pads if friction material thickness of even just one pad is about 1 mm (0.04 in).


Attention

Friction material wear beyond this limit would lead to metal support contact with the brake disc thus compromising braking efficiency, disc integrity and rider safety.

Important

Have the brake pads replaced at a Ducati
Dealer or authorised Service Centre.





Charging the battery Removing the battery

Before charging the battery, it is best to remove it from the motorcycle.


Important


The battery is located under the cowling; to remove it, ALWAYS contact a Ducati Dealer or authorised Service Centre.

Remove the right cowling (A) and conveyor (B), by loosening:

- the side screw (1) securing it to the electrical components compartment;
- the three screws (2) for lower securing to the central cowling;
- screw (3) securing central cowling to right cowling;
- the front retaining screw (4).

Remove quick-release fastener (C).







Then, loosen two screws (5) and remove the battery support bracket (6).

Slide out the battery (7) from its housing and, always starting from the negative terminal (-), loosen the two screws (8).

Remove the positive cable (9), the ABS positive cable (10) from the positive terminal and the negative cable (11) from the negative terminal.






Refitting the battery

Connect the battery charger leads to the battery terminals: the red one to the positive terminal (+), the black one to the negative terminal (-).


Lay down the ABS positive cable (10), onto positive cable (9) and start screw (8) on these cables. Connect the positive cable (9), previously assembled to ABS cable (10), to battery positive terminal, and negative cable (11) to battery negative terminal, by starting the other screw (8).

Tighten the terminal two screws (8) to a torque of 4 Nm $\pm 10\%$ and apply grease onto the battery terminals to prevent oxidation.



Refit the battery support bracket (6) by inserting the bracket end in the relevant seats (D) on the electric component support.

Start and tighten the two screws (5) to a torque of 5 $\text{Nm} \pm 10\%$.



Reposition conveyor (B) and right cowling (A), then fasten them as follows:

- start the side screw (1) securing it to the electrical components compartment;
- start the screws (2) for lower securing to the central cowling;
- start screw (3) securing central cowling to right cowling;
- start the front retaining screw (4).


Tighten screws (1), (2) and (3) to a torque of 4 Nm ±10%.


Tighten screw (4) to a torque of 4 Nm ±10%. Fit quick-release fastener (C).

Attention

The battery gives off explosive gases; never cause sparks or allow naked flames and cigarettes near the battery. When charging the battery, ensure that the working area is properly ventilated.

Charge the battery in a ventilated room. Connect the battery charger leads to the battery terminals: the red one to the positive terminal (+), the black one to the negative terminal (-). Ducati disclaims any liability deriving from the use of non-original Ducati chargers or maintainers. It is





recommended to use the Ducati dedicated battery charge maintainer (Battery Maintenance Kit part no. 69928471A (Europe), part no. 69928471AW (Japan), 69928471AX (Australia), 69928471AY (UK), 69928471AZ (USA), available from our sales network), and to operate as described in the subsection "Maintaining the battery charge".



Attention

Keep the battery out of the reach of children.

Important

Make sure the charger is OFF when you connect the battery to it, or you might get sparks at the battery terminals that could ignite the gases inside the cells. Always connect the red positive (+) terminal first.

Attention

NEVER connect the battery in parallel with that of other vehicles, as this may cause a short circuit or overheating of the battery.

Checking drive chain tension

Important

Have chain tension adjusted by a Ducati Dealer or authorised Service Centre.

Make the rear wheel turn until you find the position where chain is tightest.


Set the motorcycle on the side stand.

With the chain in its rest position, measure the distance setting the measurement instrument in front of screw (C), fastening the chain sliding shoe, at right angles with the swinging arm until the chain link in the centre of pin (B).

The value must be: $A = 31 \div 33$ mm (1.22 \div 1.30 in).

Important

This only applies to the motorcycle STANDARD settings, available upon delivery.



Important
If the drive chain is too taut or slack, contact a Ducati Dealer or authorised Service Centre

Important


Improper chain tension will lead to early wear of transmission parts.

Important

To ensure the best performance and long life of the chain, please follow the information related to chain cleaning, lubrication, inspection and tensioning.

Attention

Correct tightening of swinging arm screw (1) is critical to rider and passenger safety.



Lubricating the drive chain

Important

Have drive chain cleaned by a Ducati Dealer or authorised Service Centre.

Attention

Carry out these inspection operations with the engine off, the vehicle at a standstill, on a flat ground and on the stand


Cleaning

Before proceeding with the chain lubrication it is important to correctly wash and clean it.

The chain cleaning is extremely important for its duration. In fact, it is necessary to remove any mud, soil, sand or dirt from the chain first using a soft damp cloth (1) to soften the most resistant dirt and then with a jet of water and then dry it immediately using compressed air at a distance of at least 30 cm (11.81 in).

Checking the chain

The chain fitted on your motorcycle has O-rings that keep dirt out of and lubricant inside the sliding parts. Check the chain for wear by checking the links at the points indicated (2).



Attention

Avoid the use of steam, fuel, solvents, hard brushes or other methods that could damage the Orings; also avoid direct contact with the battery acid as it could cause mini cracks in the links as shown in the figure.

Attention

In particular, in case of Off-Road use of the bike, it is possible that excessive wear of the links occurs due to the contact with the chain sliding shoe; friction could in fact cause the chain to overheat, altering the heat treatment of the links and making them particularly fragile.

Checking the sliding shoe

Check the wear of the sliding shoe (3) and, if necessary, contact a Ducati Dealer or Authorised Service Centre.

Checking the tension

Check the chain tension (4) as indicated in the subsection "Checking the drive chain tension". Have the chain tension adjusted by a Ducati Dealer or authorised Service Centre.

Lubrication

Important


Have drive chain cleaned by a Ducati Dealer or

Attention

Use SHELL Advance Chain to lubricate the chain; the use of non-specific lubricants could damage the O-rings and therefore the entire drive system.

It is recommendable to lubricate the chain without waiting for it to cool down after using the motorcycle, so that the new lubricant can penetrate better between the inner and outer links and be more effective in its protective action.


Place the bike on the rear paddock stand. Make the rear wheel turns fast in the opposite direction to the direction of travel.




Apply the lubricant jet (1) inside the chain between the inner and outer links, in point (2) immediately before the engagement point on the sprocket.

Due to the centrifugal force, the lubricant, made fluid by the solvents contained in the spray, will expand in the working area between the pin and the bush, ensuring perfect lubrication.

Repeat the operation by aiming the lubricant jet to the central part (5) of the chain so as to lubricate the rollers (4), and to the outer plates (6) as shown in the figure.






After lubrication, wait 10-15 minutes to allow the lubricant to act on the internal and external surfaces of the chain and then remove the excess lubricant with a clean cloth

Important
Do not use the motorcycle immediately after lubricating the chain as the lubricant, still fluid, would be centrifuged outwards causing possible soiling of the rear tyre or the rider's footpeg.

Important

Check the chain often, taking care to lubricate it, as also indicated in the table below: at least every 1000 km (621 mi) or more frequently (about every 400 km (248 mi)) when using the bike with high outside temperatures (40°C) or after long travels on the highway at high speed.



Replacing the high and low beam bulbs

Headlight

The headlight is a full LED unit.

Figure shows the locations of the low beam (LO), high beam (HI) and parking lights (1).


The light voltage and power values are indicated in paragraph "Electric System".

Important

Have the headlight lights replaced by a Ducati Dealer or an Authorised Service Centre.

Attention

The headlight might fog up if the motorcycle is used under the rain or after washing. Switch headlight on for a short time to dry up any condensate




Aligning the headlight

Check correct headlight aiming. Position the motorcycle 10 metres (32.8 foot) from a wall or a screen, the motorcycle must be perfectly upright with the Tyres inflated to the correct pressure and with a rider seated, perfectly perpendicular to the longitudinal axis. On the wall or surface, draw a horizontal line at the same height from the ground as the centre of the headlight and a vertical line aligned with the longitudinal axis of the motorcycle. If possible, perform this check in dim light. Switch on the low beam.


The height of the upper limit between the dark area and the lit area must not be more than 9/10 of the height from the ground of the headlight centre.

Note

This is the procedure specified by Italian regulations for checking the maximum height of the light beam. Please adapt said procedure to the provisions in force in your own country.




To vertically align the low beam, turn the screws (1). To vertically align the high beam, turn the screw (2).



Adjusting the rear-view mirrors

Manually adjust the rear-view mirror by pushing at points (A).



Tyres

As tire pressure is affected by ambient temperature and altitude variations;

you are advised to check and adjust it whenever you are riding in areas where ample variations in temperature or altitude occur.

Attention

Check and set tyre pressure when tyres are cold. To avoid front wheel rim distortion, when riding on bumpy roads, increase tyre pressure by 0.2 ÷ 0.3 bar (2.9÷4.35 PSI).

Tyre repair or change (Tubeless tyres)

In the event of a tiny puncture, tubeless tyres will take a long time to deflate, as they tend to keep air inside. If you find low pressure on one tyre, check the tyre for punctures.

Attention

Punctured tyres must be replaced. Replace the tyres with recommended standard tyres only. Be sure to tighten the valve caps securely to avoid leaks when riding. Never use tube type tyres. Failure to heed this warning may lead to sudden tyre bursting and to serious danger to rider and passenger.

After replacing a tyre, the wheel must be balanced.

Attention

Do not remove or shift the wheel balancing weights.

Note


Have the tyres replaced at a Ducati Dealer or authorised Service Centre. Correct removal and installation of the wheels is essential. Some parts of the ABS (such as sensors and phonic wheels) are mounted to the wheels and require specific adjustment.

Minimum tread depth

Measure tread depth (S, Fig 249) at the point where tread is most worn down: it should not be less than 2 mm (0.08 in), and in any case not less than the legal limit.

■ Important

Visually inspect the tyres at regular intervals for detecting cracks and cuts, especially on the side walls, bulges or large spots that are indicative of internal damage. Replace them if badly damaged. Remove any stones or other foreign bodies caught in the tread.



Check engine oil level

Check the engine oil level through the sight glass (1) on the clutch cover

Oil level should be between the marks on the sight glass. If the level is low, top up with engine oil. Ducati prescribes the only use of SAE 15W -50/JASO MA2 oil and recommends the use of Shell Advance 4T Ultra 15W -50 oil (JASO: MA2 and API: SN). Remove the oil filler cap (2) and top up until the oil reaches the required level. Refit the plug.


Important
UK VERSION: Ducati recommends you use Shell Advance DUCATI 15W-50 Fully Synthetic Oil.

Attention

Engine oil and oil filters must be changed by a Ducati Dealer or Authorised Service Centre at the intervals specified in the scheduled maintenance chart contained in this manual, sub-section "Scheduled maintenance chart"

To check the oil level correctly, carefully follow the instructions below

1) The level should be checked at warm engine, about 15 minutes after the engine has been stopped.



- 2) Turn off the engine and wait 10\15 minutes to allow the oil to flow completely inside the sump.
- 3) Position the bike with both wheels on a flat ground and in straight position.
- 4) Then, check the engine oil through the sight glass. 5) If the oil level is below the middle line between the MIN and MAX marks, add oil until reaching the maximum level indication.



Never exceed the MAX mark

Attention

In engines equipped with timing variators it may happen that a certain quantity of engine oil remains in the cylinder heads when the engine is off and requires a certain amount of time to flow completely into the oil sump. This could lead to an incorrect measurement of the oil level

Recommendations concerning oil

It is recommended to use oil complying with the following specifications:

- viscosity grade SAE 15W-50;
- standard API: SN:
- standard JASO: MA2

Attention

L UK VERSION: It is recommended to use oil complying with the following specifications:

viscosity grade SAE 15W-50.

SAE 15W-50 is an alphanumerical code identifying oil class based on viscosity: two figures with a W ("winter") in-between; the first figure indicates oil viscosity at low temperature; the second figure indicates its viscosity at high temperature. API

(American standard) and JASO (Japanese standard) standards specify oil characteristics.

Cleaning the motorcycle

To preserve the finish of metal parts and paintwork, wash and clean your motorcycle at regular intervals, anyway according to road conditions. Use specific products only. Prefer biodegradable products. Avoid aggressive detergents or solvents.

Use only water and neutral soap to clean the Plexiglas and the seat.

Periodically clean by hand all aluminium components. Use special detergents, suitable for aluminium parts. Do NOT use abrasive detergents or caustic soda.

Note

Do not use sponges with abrasive parts or steel wool: only use soft cloths.

However, the warranty does not apply to motorcycles whenever poor maintenance status is ascertained.

Important

Do not wash your motorcycle right after use. When the motorcycle is still hot, water drops will evaporate faster and spot hot surfaces.

Never clean the motorcycle using hot or highpressure water jets.

Cleaning the motorcycle with a high pressure water jet may lead to seizure or serious faults in forks, wheel hubs, electric system, headlight (fogging), fork seals, air inlets or exhaust silencers, with consequent loss of compliance with the safety requirements.

Clean off stubborn dirt or exceeding grease from engine parts using a degreasing agent. Be sure to avoid contact with drive parts (chain, sprockets, etc.).

Rinse with warm water and dry all surfaces with chamois leather.

Attention

Braking performance may be impaired immediately after washing the motorcycle. Never grease or lubricate the brake discs to avoid losing braking power. Clean the discs with an oil-free solvent.

Attention

The headlight might fog up due to washing, rain or moisture. Switch headlight on for a short time to help and dry up any condensate.

Carefully clean the phonic wheels of the ABS in order to ensure system efficiency. Do not use aggressive products in order to avoid damaging the phonic wheels and the sensors.

Attention

Avoid direct contact between instrument panel lens and oils/fuels that may stain or damage it thereby impairing information readability. To clean such parts, do not use alcohol-based detergents, containing solvent or abrasive agents; do not use sponges or cloths featuring hard or rough areas since they might scratch the surface.

Note

Clean instrument panel lens using soft cloths with water and mild soap or detergents specific for cleaning clear plastic parts.

Note

To clean the instrument panel do not use alcohol or its by-products.

Pay special attention when cleaning the wheel rims since they have parts in machined aluminium; clean and dry them every time you use the vehicle.

Important

To clean and lubricate the drive chain, refer to the paragraph "Lubricating the drive chain".

Storing the motorcycle

If the motorcycle is to be left unridden over long periods, it is advisable to carry out the following operations before storing it away:

- clean the motorcycle;
- place the motorcycle on a service stand;

Battery should be checked and charged (or replaced, as required) whenever the motorcycle has been left unridden for over a month.

Protect the motorcycle with a suitable canvas. This will protect paintwork and prevent retaining condensate.

The canvas is available from Ducati Performance.

Important notes

Laws in some countries (France, Germany, Great Britain, Switzerland, etc.) set certain noise and pollution standards.

Periodically carry out the required checks and renew parts as necessary, using Ducati original spare parts, in compliance with the regulations in the country concerned.

Various electronic components of your vehicle have data memories that temporarily or permanently store technical information on the status, events and faults of the vehicle.

In general, this information documents the status of a component, module, system or environment.

- Operating status of system components (e.g. emission control system).
- Status messages of the vehicle and its components (e.g. wheel rotation speed, engine rpm, engaged gear, etc.)
- Malfunctions and faults of important system components (e.g. lights, brakes, etc.)
- Vehicle response in particular riding situations (e.g. traction control system, etc.)
- Environmental conditions (e.g. temperature, etc.)

These data are always of a technical nature and are used to detect and correct faults and optimise vehicle functions.

During service operations such as repairs, maintenance activities, operations under warranty, and quality assurance, service network personnel (including manufacturers) can read this technical information from the event and fault data memory using special diagnostic tools. Once the fault has been eliminated, it is possible to progressively delete or overwrite the information in the fault memory.

Vehicle data are collected as a result of a service requested by the Customer or provided under a contract (on the vehicle).

Within the scope of these services, personal data are processed in compliance with current legislation on data protection, based on a legitimate interest of Ducati to ensure increasingly efficient assistance, and finally to comply with legal obligations (e.g. information obligations on repairs and maintenance). If necessary, personal data are read and used in combination with the vehicle identification number.


Our control units do not collect geolocation data.

Vehicle transport

Before transporting the motorcycle using another vehicle, follow the safety instructions below.

- Remove all loose objects and accessories from the vehicle;
- Align the front wheel straight in the riding direction and lock it properly to prevent any movement:
- 3) Engage the first gear;
- 4) Use the anchoring straps and apply them to strong components (e.g. frame) and NOT to the handlebar (or handlebars, where present) or to components that could break (e.g. handgrips, rear-view mirrors, etc.);
- 5) The straps or ropes must NOT rub against any painted motorcycle components;
- 6) The suspensions, if possible, must be in a partially compressed position so as to allow less movement of the vehicle with respect to the road surface during transport.

Do NOT attach the ropes to the handlebar.



Scheduled maintenance chart

Scheduled maintenance chart: operations to be carried out by the dealer

Important

Using the motorcycle under extreme conditions, such as very damp and muddy roads or dusty and dry environment, could cause above-average wear of components like the drive system, the brakes or the air filter. If the air filter is dirty, the engine could get damaged. Therefore, this might translate in required service or replacement of the wear parts earlier than specified in the scheduled maintenance chart.

List of operations and type of inter- Km. x1,000	1	15	30	45	60	
vention [set mileage (km/mi) or time interval mi. x1,000 *]	0.6	9	18	27	36	Time (months)
Reading of the error memory with DDS 2.0 and check of software version update on control units	•	•	•	•	•	12
Check the presence of any technical updates and recall campaigns	•	•	•	•	•	12
Change engine oil and filter	•	•	•	•	•	12
Clean the engine oil mesh filter assembly	•					-
Check and/or adjust valve clearance			•		•	-
Change timing belts			•		•	60

List of operations and type of inter- Km. x1,000	1	15	30	45	60	
vention [set mileage (km/mi) or time interval mi. x1,000 *]	0.6	9	18	27	36	Time (months)
Change water pump belt			•		•	60
Change spark plugs			•		•	-
Clean plugs with metal mesh filters on heads					•	-
Clean air filter		•		•		12
Change air filter			•		•	-
Check brake and clutch fluid level	•	•	•	•	•	12
Change brake and clutch fluid						36
Check brake disk and pad wear. Change if necessary	•	•	•	•	•	12
Check the proper tightening of brake calliper bolts and brake disk flange screws	•	•	•	•	•	12
Check front and rear wheel nuts tightening		•	•	•	•	12
Check frame-to-engine fasteners tightening		•	•	•	•	-
Check wheel hub bearings			•		•	-
Check and lubricate the rear wheel shaft			•		•	-
Check the cush drive damper on rear sprocket			•		•	-

List of operations and type of inter- Km. x1,000	1	15	30	45	60		
vention [set mileage (km/mi) or time interval mi. x1,000 *]		9	18	27	36	Time (months)	
Check the proper tightening of final drive front and rear sprocket nuts	•	•	•	•	•	12	
Check final drive (chain, front and rear sprocket) wear.		•	•	•	•	12	
Check final drive chain tension and lubrication	•	•	•	•	•	12	
Check steering bearings and lubricate, if necessary			•		•	=	
Change front fork fluid				•		=	
Visually check the front fork and rear shock absorber seals		•	•	•	•	12	
Check the freedom of movement and tightening of the side and central stand (if any)	•	•	•	•	•	12	
Visually check the fuel lines			•		•	=	
Check rubbing points, clearance, freedom of movement and positioning of hoses and electric wiring in view		•	•	•	•	12	
Lubricate the levers at the handlebar and pedal controls		•	•	•	•	12	
Change coolant				•		48	
Visually check the coolant level and sealing of the circuit		•	•	•	•	12	
Check tyre pressure and wear	•	•	•	•	•	12	

List of operations and type of inter- Km. x1,000	1	15	30	45	60		
vention [set mileage (km/mi) or time interval mi. x1,000 *]	0.6	9	18	27	36	Time (months)	
Check the battery charge level	•	•	•	•	•	12	
Check the operation of all electric safety devices (side stand sensor, front and rear brake switches, engine kill switch, gear/neutral sensor)	•	•	•	•	•	12	
Check lighting, turn indicators, horn and controls		•	•	•	•	12	
Reset the Service indication through the DDS 2.0	•	•	•	•	•	-	
Final test and road test of the motorcycle, testing safety devices (ex. ABS and DTC), Cruise Control device, electric fans and idling		•	•	•	•	12	
Softly clean the motorcycle	•	•	•	•	•	12	
Fill out that the service was performed in on-board documentation (Service Booklet)	•	•	•	•	•	12	

^{*} Service operation to be carried out in accordance with the specified distance or time intervals (km, miles or months), whichever occurs first.

Scheduled maintenance chart: operations to be carried out by the customer

Important

Using the motorcycle under extreme conditions, such as very damp and muddy roads or dusty and dry environment, could cause above–average wear of components like the drive system, the brakes or the air filter. If the air filter is dirty, the engine could get damaged. Therefore, this might translate in required service or replacement of the wear parts earlier than specified in the scheduled maintenance chart.

	Km. x1,000		
List of operations and type of intervention [set mileage (km/mi) or time interval *]	mi. x1,000		
dime interval 1	Months	6	
Check engine oil level		•	
Check brake and clutch fluid level		•	
Check tyre pressure and wear		•	
Check the drive chain tension and lubrication		•	
Check brake pads. If necessary, contact your dealer to replace components		•	

^{*} Service operation to be carried out in accordance with the specified distance or time intervals (km, miles or months), whichever occurs first.


Technical data

Weights

Overall weight (in running order with 90% of fuel -44/2014/EU Annex XI): 244 Kg (537.93 lb). Overall weight (dry conditions, without fluids and battery): 218 Kg (480.61 lb). Maximum allowed weight (carrying full load): 440 kg (970 lb).

Attention
Failure to observe weight limits could result in poor handling and impair the performance of your motorcycle, and you may lose control of the motorcycle.

Dimensions



Fuel, lubricants and other fluids

TOP-UPS	TYPE	
Fuel tank, including a reserve of 4 litres (0.88 UK gal)	Ducati recommends SHELL V-Power un- leaded premium fuel with a minimum of octane rating of RON 95	
Oil sump and filter	Ducati prescribes the only use of SAE 15W-50/JASO MA2 oil and recommends the use of Shell Advance 4T Ultra 15W-50 oil (JASO: MA2 and API: SN).	` ,
	SHELL Advance DUCATI 15W-50 Fully Synthetic Oil (UK VERSION)	
Front/rear brake and clutch circuits	DOT 4	-
Protectant for electric contacts	Protective spray for electric systems.	-
Front fork (Diavel 1260)	SHELL Donax TA	840 cc (51.26 cu.in) per leg Without spring, no pre- load tube and with fork leg fully home; from plug, measure 85±2mm (3.35±0.08 in)
Front fork (Diavel 1260 S)	SHELL Donax TA	648 cc (39.54 cu.in) per leg

TOP-UPS	TYPE	
Cooling circuit	ENI Agip Permanent Spezial antifreeze (do not dilute, use pure)	2.5 litres (0.55 UK gal)

Important

Do not use any additives in fuel or lubricants. Using them could result in severe damage of the engine and motorcycle components.

Attention

The motorcycle is only compatible with fuel having a maximum content of ethanol of 10% (E10). Using fuel with ethanol content over 10% is forbidden. Using it could result in severe damage of the engine and motorcycle components. Using fuel with ethanol content over 10% will make the warranty null and void.

Important

These references indicate the fuel recommended for this vehicle as specified by the European regulation EN228.



Engine

Ducati Testastretta DVT 1262, "L" twin-cylinder, Dual Spark engine, liquid-cooled, with 4 valves per cylinder, Desmodromic Variable Timing system. Gear-type oil pump with built-in by-pass valve and oil cooler.

Bore: 106 mm (4.17 in).

Stroke: 71.5 mm (2.82 in).

Total displacement: 1262 cu. cm (77.01 cu in).

Compression ratio: 13.1±0.5:1.

Maximum power at crankshaft (EU) Regulation no.

134/2014, Annex X, kW/HP: 116.7 kW/158.7 HP at 9.500 rpm.

Max. power at crankshaft Regulation (EU) no. 134/2014 Annex X kW/HP, for Belgium/France versions only:

74 kW/100.6 HP at 6500 rpm.

Maximum torque at crankshaft (EU) Regulation no. 134/2014 Annex X:

129.2 Nm/13.2 kgm at 7,500 rpm.

Max. torque at crankshaft Regulation (EU) no. 134/2014 Annex X, for Belgium/France versions only:

123.6 Nm/12.6 kgm at 4,500 rpm.

Max. rotation speed: 10,300 rpm.

Important

Do not exceed the specified rpm limits in any running conditions.

Note

The indicated power/torque values have been measured with a static test bench according to type-approval standards and match with the data detected during type-approval process; they are indicated in the vehicle registration document.

Lubrication


Gear-type oil pump with built-in by-pass valve and oil cooler.

Timing system

DESMODROMIC system with four valves per cylinder controlled by eight rocker arms (four opening and four closing ones) and two overhead camshafts with variable valve timing (DVT) both for the exhaust and intake side. This system is driven by the crankshaft through spur gears, pulleys and toothed belts.

Desmodromic timing system

- 1) Opening (or upper) rocker arm;
- 2) Upper rocker arm shim;
- 3) Closing (or lower) rocker arm shim;
- 4) Return spring for lower rocker arm;
- 5) Closing (or lower) rocker arm;
- 6) Camshaft;
- 7) Valve.
- 8) Timing Variator.
- 9) Actuators.



Performance data

Maximum speed in any gear should be reached only after a correct running-in period with the motorcycle properly serviced at the recommended intervals.

Important

Failure to follow these instructions releases Ducati Motor Holding S.p.A. from any liability whatsoever for any engine damage or shorter engine life.

Spark plugs

Make: NGK. Type: MAR9A-J.

Fuel system

BOSCH electronic injection.

Type of throttle body: elliptical, Ø56 mm (2.20 in), with full Ride-by-Wire system.

Diameter of throttle body: 56 mm (2.20 in).

Injectors per cylinder: 1. Firing points per injector: 10. Fuel supply: 95-98 RON.

Attention

The motorcycle is only compatible with fuel having a maximum content of ethanol of 10% (E10). Using fuel with ethanol content over 10% is forbidden. Using it could result in severe damage to the engine and motorcycle components. Using fuel with ethanol content over 10% will make the warranty null and void.

Brakes

Separate-action anti-lock braking system (ABS), equipped also with "Cornering Evo" function, operated by hall-type sensors mounted to each wheel with phonic wheel detection: ABS can be disabled

FRONT

Front brake discs

Semi-floating drilled twin-disc. Braking material: stainless steel. Disc diameter: 320 mm (12.59 in).

Carrier material: stainless steel, black colour.

Disc thickness: 4.5 mm (0.18 in).

Maximum wear on disc thickness: 4 mm (0.16 in).

Disc braking surface: 263 sq. cm (40.77 in²).

Front brake control

Hydraulic control through lever on RH side of handlebar, equipped with a knob for adjusting the distance of the lever from the handgrip.

Front brake calliper

Brake calliper make: BREMBO.

Front brake calliper type: Radially-mounted

monobloc M4.32 callipers

Number of pistons per calliper: 4.

Calliper piston diameter: Ø32 mm (1.26 in). Calliper friction material: TOSHIBA TT 2182 FF.

Front brake master cylinder

Brake lever master cylinder diameter: 18 mm (0.71 in).

REAR

Front brake disc

With fixed drilled disc.

Braking material: stainless steel.

Disc diameter: 265 mm (10.43 in). Disc thickness: 6 mm (0.24 in).

Maximum wear on disc thickness: 5.4 mm (0.21 in).

Disc braking surface: 220 sq. cm (34.1 in²).

Rear brake control

Hydraulically operated by a pedal on RH side.

Rear brake calliper

Brake calliper make: BREMBO.

Rear brake calliper type: with 2 pistons.

Number of pistons per calliper: 2.

Calliper piston diameter: Ø30 mm - Ø32 mm (1.18 in – 1.26 in).

Rear brake master cylinder

Master cylinder type: PS13.

Master cylinder diameter: 13 mm (0.51 in). Friction material: TOSHIBA TT 2182 FF.

Attention

The brake fluid used in the brake system is corrosive.

In the event of accidental contact with eyes or skin, wash the affected area with abundant running water.

Transmission

Hydraulically-controlled slipper/progressive selfservo wet multiplate clutch.

Spur gear drive (1.80:1 ratio).

Gearbox output sprocket/rear sprocket ratio: 15/43. Front chain sprocket/clutch gearwheel ratio: 33/61. 6-speed gearbox (Diavel 1260) with constant mesh gears, gear change pedal on left side of motorcycle. 6-gear gearbox (Diavel 1260 S) with Ducati Quick Shift (DQS) up/down EVO.

Total gear ratios:

1st 37/15

2nd 30/17 3rd 27/20 4th 24/22

5th 23/24 6th 22/25

Drive chain from gearbox to rear wheel.

Make: DID 525 HV3

Links: 112

Important

The above gear ratios are the homologated ones and under no circumstances must they be modified

However, if you wish to tune up your motorcycle for competitions or special tracks, Ducati Motor Holding S.p.A. will be pleased to provide information about the special ratios available. Contact a Ducati Dealer or Authorised Service Centre.

Attention

Ducati Dealer or authorised Service Centre. Incorrect replacement of this component could seriously compromise your safety and cause irreparable damage to the motorcycle.

Frame

Steel tubular trellis.

Steering head angle: 27°.

Steering angle: 34° LH side / 34° RH side.

Trail: 120 mm (4.72 in).

Wheels

Front

Diavel 1260

14-spoke, light-alloy cast rims.

Size: MT3.50x17".

Diavel 1260 S

10-spoke, light-alloy cast rims.

Size: MT3.50x17".

Rear

Light alloy cast rims. Size: MT8.00x17".

Tyres Tyre type

Front

"Tubeless", radial tyre.

Size: 120/70-ZR17 M/C (58W) TL Make and type: Pirelli Diablo Rosso III.

Rear

"Tubeless", radial tyre.

Size: 240/45-ZR17 M/C (82W) T

Make and type: Pirelli Diablo Rosso III.

Tyre pressure

Front

2.50 bar (250 kPa - 36.26 PSI) (rider only)

2.6 bar (260 kPa - 37.71 PSI) (with passenger and/or bags).

Rear

2.50 bar (250 kPa - 36.26 PSI) (rider only) 2.9 bar (290 kPa - 42 PSI) (with passenger and/or

bags).

Suspension

Front

Diavel 1260

Make: Marzocchi

Hydraulic fork with Ø50 mm (1.97 in) upside-down legs fully adjustable in rebound and compression

hydraulic damping.

Front wheel travel: 120 mm (4.72 in).

Diavel 1260 S

Make: Ohlins.

Hydraulic fork with Ø48 mm (1.89 in) upside-down legs with TiN treatment fully adjustable in rebound and compression hydraulic damping.

Rear

Diavel 1260

Make: Marzocchi

Adjustable preload and rebound.

Stroke: 63 mm (2.48 in).

Rear wheel travel: 130 mm (5.12 in).

Front wheel travel: 120 mm (4.72 in).

Diavel 1260 S Make: Ohlins

Fully adjustable rebound and compression damping

and spring preload. Stroke: 62.5 mm (2.46 in).

Rear wheel travel: 130 mm (5.12 in).

Exhaust system

Stainless steel pipes and silencer with double outlet. Lambda sensors: 2.

Catalytic converters: 2.

Available colours

DARK STEALTH

Primer (Primer 2 K Black) code 873.A002 (PALINAL).

Primer (Black Stealth - Black 94) code 929.R223 (PALINAL).

Clear coat (Matt Clear Coat 2K) code 923I.2176 (PALINAL).

Frame, Carbon Black code 4497 (INVER). Rims, Matt Black 10 Gloss consisting of: Powder primer code EP050V (AKZO NOBEL). Base coat (Enkote Ducati DU5 Black) Code 43NL0007 (AKZO NOBEL).

Clear coat (Enkote clear matte 10 gloss) code 43NX0016 (AKZO NOBEL).

Ducati Red

Primer Ducati Red code 473.101 (PPG). Clear coat Tixo Klarlack code 96230 (LECHLER).

Electric system

Basic electric items are:

Hermetic type battery:

12V 10Ah

Generator:

14V 490W 35A

Electronic regulator:

protected by a 30A fuse

Headlight

LED low beam light type: No. 4 LEDs (13.5V - 24.3W); LED high beam light type: No. 5 LEDs (13.5V -

18.9W);

LED parking light type: No. 5 LEDs (13.5V - 6.2W).

Turn indicators

Front turn indicators: LED (13.5V - 4.7W). rear turn indicators: LED (13.5V - 2.06W).

Electrical switches on handlebar.

Tail light

Parking light: (13.5V - 0.3W); LED stop light: (13.5V - 1.4W);

Number plate light: LED (13.5V - 0.7W).

Tail light

Parking light: (13.5V - 0.3W); LED stop light: (13.5V - 1.4W);

Number plate light: LED (13.5V - 0.7W).

Instrument panel


Dashboard: 3.55 inch.


Fuses

There are thirteen fuses that protect the electric components, located inside the upper and lower fuse boxes, and one on the solenoid starter. There is a spare fuse (S) in every box.

Refer to the table below to identify the circuits protected by the various fuses and their ratings. The upper (A) and lower (B) fuse boxes are located on the right side of the electric component support, next to the battery.

To reach the fuse boxes, remove the right cowling, see procedure described in Chapter Seat lock. To expose the fuses, lift the box protective cover. Mounting position and ampere capacity are marked on box cover.





Upper fuse box key (A)		
Pos	El. item	Rat.
1	KEYEMS/ABS/IMU	5 A
2	KEY DSB / BBS	15 A
3	-	-
4	-	-
5	KEY Accessories	10 A
6	+30 Hands Free	25 A
7	+30 Diagnosis / charge	7.5 A

Lower fuse box key (B)		
5	+30 Black Box Sys- tem (BBS)	10 A
6	+30 ABS UBMR	25 A
7	+30 ABS UBVR	10 A

Lower fuse box key (B)		
Pos	El. item	Rat.
1	+30 EMS LOAD RE- LAY	25 A
2	+30 FUEL PUMP RE- LAY	
3	+30 Starter RELAY	7.5 A
4	+30 Instrument panel	15 A

The main fuse (C) (30A) is positioned on the solenoid starter.

Remove the fuse cap to reach it.


A blown fuse can be identified by breakage of the inner filament (F).


Important

Switch the ignition key to OFF before replacing the fuse to avoid possible short-circuits.

Attention Never use a fuse with a rating other than

specified. Failure to observe this rule may damage the electric system or even cause fire.





Open source software

Information about open source software

Some vehicle components use open source software. The source code used and information on open source is available online at the following link: https://www.ducati.com/ww/en/home/open-source-software

Declarations of conformity

Declarations of conformity

EU Directive 2014/53/EU



Addresses of radio component manufacturers

All radio components must carry the manufacturer's address according to the provisions of directive 2014/53/EU. For components that, due to their size or nature, cannot be furnished with a sticker, the respective manufacturers' addresses as required by law are listed in the table 2.



Note

Only skilled person can access and install the device.

Table 1

Radio equip-	Frequency band	Max. transmission power
ment instal-		
led in the ve-		
hicle		

Hands Free Unit	133.8 KHz ÷ 134.6 KHz	< 73dBμV/m (10m)
Hands Free Key	433.91 MHz ÷ 433.93 MHz	-20 dBμV/m (3m)
Ducati Multi- media Sys- tem (Bluetooth)	2402 ÷ 2480 MHz	4.4mW
Antitheft	433.92MHz (±75KHz)	<0.6mA

Table 2

Radio equipment installed in the vehicle	Manufacturers' addresses
Hands Free Unit	ASAHI DENSO CO.,LTD. 6-2-1 Somejidai, Hamakita-ku, Hamamatsu, Shizuoka, 434-0046 Japan
Hands Free Key	ASAHI DENSO CO.,LTD. 6-2-1 Somejidai, Hamakita-ku, Hamamatsu, Shizuoka, 434-0046 Japan
Ducati Multimedia Sys- tem (Bluetooth)	COBO S.p.a. Via Tito Speri, 10 25024 Leno (BS), Italy

Antitheft	PATROLLINE
	Via Cesare Cantù, 15/C 22031 Albavilla (CO), Italy

Simplified EU declaration of conformity

[Austria]

Ihr Fahrzeug ist mit einer Reihe von Funkgeräten ausgestattet. Die Hersteller dieser Funkgeräte erklären, dass diese, wo gesetzlich vorgeschrieben, mit der Richtlinie 2014/53/EU übereinstimmen. Der vollständige Text der EU-Konformitätserklärung ist unter folgender Adresse verfügbar: certifications.ducati.com

[Belgium]

Votre véhicule est équipé d'une série d'appareillages radio. Les constructeurs de ces appareillages radio déclarent que ces derniers sont conformes à la directive 2014/53/UE lorsque la loi le requiert. Le texte complet de la déclaration de conformité UE est disponible à l'adresse suivante : certifications.ducati.com

[Bulgaria]

Твоят мотоциклет е оборудван с различна по вид радиоапаратура. Производителите на тази радиоапаратура декларират, че тя съответства на Директива 2014/53/EC, съгласно изискванията по закон. Пълният текст на декларацията за съответствие EC, ще намерите на следния адрес: certifications.ducati.com

[Cyprus]

Το όχημά σας εξοπλίζεται με μια σειρά από ραδιοσυσκευές. Οι κατασκευαστές των συσκευών αυτών δηλώνουν ότι οι συσκευές συμμορφώνονται με την οδηγία 2014/53/ΕΕ, όπου απαιτείται από το νόμο. Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ είναι διαθέσιμο στη διεύθυνση: certifications.ducati.com

[Czech Republic]

Vaše vozidlo je vybaveno řadou rádiových zařízení. Výrobci těchto radio zařízení, prohlašují, že zařízení jsou v souladu se směrnicí 2014/53/EU, pokud to vyžaduje zákon. Úplné znění prohlášení o shodě EU je k dispozici na internetových stránkách: certifications.ducati.com

[Germany]

Ihr Fahrzeug ist mit einer Reihe von Funkgeräten ausgestattet. Die Hersteller dieser Funkgeräte erklären, dass diese, wo gesetzlich vorgeschrieben, mit der Richtlinie 2014/53/EU übereinstimmen. Der vollständige Text der EU-Konformitätserklärung ist unter folgender Adresse verfügbar: certifications.ducati.com

[Denmark]

Dit køretøj er udstyret med et udvalg af radioudstyr. Producenterne af dette radioudstyr erklærer, at dette udstyr overholder direktiv 2014/53/EU, hvis det kræves i henhold til loven. Den komplette tekst af EU-overensstemmelseserklæringen findes på følgende webadresse: certifications.ducati.com

[Estonia]

Teie sõiduk on varustatud raadioseadmete seeriaga. Selle raadioseadme tootjad kinnitavad, et see seade vastab direktiivile 2014/53/EÜ, kui seadus seda nõuab. EÜ vastavusdeklaratsiooni terviktekst on saadaval järgmisel veebisaidil: certifications.ducati.com

[Spain]

Su vehículo está equipado con una serie de equipos de radio. Los fabricantes de dichos equipos de radio declaran su conformidad con la directiva 2014/53/UE, como requiere la ley. El texto completo de la declaración de conformidad UE está disponible en el siguiente sitio: certifications.ducati.com

[Finland]

Ajoneuvossasi on radiolaitteita. Näiden radiolaitteiden valmistajat vakuuttavat, että laitteet vastaavat direktiiviä 2014/53/EU lain edellyttämällä tavalla. EU-vaatimustenmukaisuusvakuutuksen täydellinen teksti on saatavilla seuraavasta osoitteesta: certifications.ducati.com

[France]

Votre véhicule est équipé d'une série d'appareillages radio. Les constructeurs de ces appareillages radio déclarent que ces derniers sont conformes à la directive 2014/53/UE lorsque la loi le requiert. Le texte complet de la déclaration de conformité UE est disponible à l'adresse suivante : certifications.ducati.com

[United Kingdom]

Your vehicle is equipped with a range of radio equipment. The manufacturers of this radio equipment declare that these equipment complies with Directive 2014/53/EU where required by law. The complete text of the EU declaration of conformity is available at the following web address: certifications.ducati.com

[Greece]

Το όχημά σας εξοπλίζεται με μια σειρά από ραδιοσυσκευές. Οι κατασκευαστές των συσκευών αυτών δηλώνουν ότι οι συσκευές συμμορφώνονται με την οδηγία 2014/53/ΕΕ, όπου απαιτείται από το νόμο. Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ είναι διαθέσιμο στη διεύθυνση: certifications.ducati.com

[Croatia]

Vaše vozilo je opremljeno nizom radio uređaja. Proizvođači ovih radio uređaja tvrde da su uređaji u skladu s Direktivom 2014/53/UE ako je propisano zakonom. Cjelokupan tekst deklaracije o sukladnosti dostupan je na: certifications.ducati.com

[Hungary]

Járműved egy sor rádió készülékkel van felszerelve. Ezeknek a rádióberendezéseknek a gyártói kijelentik, hogy a készülékek megfelelnek a 2014/53/EU irányelvnek, ahol ezt a törvény megköveteli. Az EU megfelelőségi nyilatkozat teljes szövege az alábbi címen érhető el: certifications.ducati.com

[Ireland]

Your vehicle is equipped with a range of radio equipment. The manufacturers of this radio equipment declare that these equipment complies with Directive 2014/53/EU where required by law. The complete text of the EU declaration of conformity is available at the following web address: certifications.ducati.com

[Italy]

Il tuo veicolo è dotato di una serie di apparecchiature radio. I costruttori di queste apparecchiature radio dichiarano che esse sono conformi alla direttiva 2014/53/UE laddove richiesto per legge. Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo: certifications.ducati.com

[Lithuania]

Jūsų transporto priemonėje įdiegta daug įvairios radijo įrangos. Šios radijo įrangos gamintojai patvirtina, kad ji atitinka 2014/53/ES direktyvos reikalavimus, kaip tai numato galiojantys įstatymai. Visas ES atitikties deklaracijos tekstas pateikiamas svetainėje adresu certifications.ducati.com

[Luxembourg]

Votre véhicule est équipé d'une série d'appareillages radio. Les constructeurs de ces appareillages radio déclarent que ces derniers sont conformes à la directive 2014/53/UE lorsque la loi le requiert. Le texte complet de la déclaration de conformité UE est disponible à l'adresse suivante : certifications.ducati.com

[Latvia]

Jūsu transportlīdzeklis ir aprīkots ar dažādām radioierīcēm. Šo radioierīču ražotājs apliecina, ka ierīces atbilst Direktīvas 2014/53/ES prasībām, ja to paredz attiecīgie tiesību akti. Pilnīgo ES atbilstības deklarāciju skatiet šajā tīmekļa vietnē: certifications.ducati.com

[Malta]

Il-vettura tiegħek hija mgħammra b'firxa ta' tagħmir tar-radju. Il-manufatturi ta' dan it-tagħmir tar-radju jiddikjaraw li dan it-tagħmir jikkonforma mad-Direttiva 2014/53/UE fejn meħtieġ mil-liġi. It-test kollu taddikjarazzjoni ta' konformità tal-UE huwa disponibbli fuq l-indirizz tal-web: certifications.ducati.com

[Netherlands]

Uw voertuig is voorzien van diverse draadloze apparatuur. De fabrikanten van deze draadloze apparatuur verklaren dat deze, daar waar dit door de wet voorschreven wordt, overeenstemmen met de richtlijn 2014/53/EU. De volledige tekst van de EU-verklaring van overeenstemming is beschikbaar op het volgende webadres: certifications.ducati.com

[Poland]

Państwa pojazd został wyposażony w szereg urządzeń radiowych. Producenci tych urządzeń radiowych oświadczają, że są one zgodne z dyrektywą 2014/53/UE, tam, gdzie wymaga tego prawo. Pełny tekst deklaracji zgodności UE jest dostępny pod następującym adresem internetowym: certifications.ducati.com

[Portugal]

O seu veículo é dotado de uma série de equipamentos de rádio. Os construtores desses equipamentos de rádio declaram que os mesmos estão em conformidade com a diretiva 2014/53/UE sempre que a lei o

determinar. O texto completo da declaração de conformidade UE está disponível no seguinte endereço: certifications.ducati.com

[Romania]

Vehiculul dvs. este dotat cu o serie de aparate radio. Producătorii acestor aparate radio declară că acestea sunt conforme cu directiva 2014/53/UE, dacă legea impune acest lucru. Textul complet al declarației de conformitate UE este disponibil la următoarea adresă: certifications.ducati.com

[Sweden]

Ditt fordon är utrustat med radioutrustning. Radioutrustningens tillverkare förklarar att denna utrustning uppfyller direktiv 2014/53/EU där så lagen kräver det. Fullständig text om EU-försäkran om överensstämmelse finns på följande adress: certifications.ducati.com

[Slovenia]

Vaše vozilo ima tudi vrsto radijske opreme. Proizvajalci eteh radijskih naprav izjavljajo, da so ti v skladu z uredbo 2014/53/UE, kjer zakon to predvideva. Celotno besedilo izjave o skladnosti EU je na voljo na spodnjem naslovu: certifications.ducati.com

[Slovakia]

Vaše vozidlo je vybavené rádiofónnymi zariadeniami. Výrobcovia týchto rádiofónnych zariadení prehlasujú, že tieto zariadenia sú v zhode so smernicou 2014/53/EÚ v rozsahu predpísanom zákonom. Úplný text ES prehlásenia o zhode je k dispozícii na nasledujúcej adrese: certifications.ducati.com

HANDS FREE KEY

Warnings on batteries



Please read the operating instructions carefully!





This product contains a button cell battery that could be swallowed.

Always keep the battery out of the reach of children!

Swallowing the battery can cause serious injury in as little as 2 hours or death due to chemical burns and potential esophageal perforation.

If you think the batteries may have been swallowed or placed inside any part of the body, seek medical advice immediately.

Only install new batteries of the same type in the product.

Keep batteries away from sources of heat or moisture.

Keep batteries away from low or high pressure, and low or high temperature environments.

Do not compress, drop, damage or puncture the battery with foreign objects.

Dispose of used batteries immediately and safely in accordance with national and local regulations.

Discharged batteries can still be dangerous.

United States (USA)

"This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation."

"Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment." "NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment gene rates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interfere nee to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help."
- RF exposure Information according 2.1091/2.1093 / OET bulletin 65:

Radiofrequency radiation exposure Information: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The manufacturers of these radio equipment declare that devices comply with the FCC

DUCATI MULTIMEDIA SYSTEM (Bluetooth)	FCC ID: Z64-2564N
Hands Free Unit	FCC ID: T8VCL6
Hands Free Key	FCC ID: T8VCL6-904

Canada

This device contains licence-exempt transmitter(s)/ receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF Exposure Information:

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

Déclaration d'exposition aux radiations: Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

DASHBOARD	IC: 23285-ZDM1604D00
DUCATI MULTIMEDIA SYSTEM (Bluetooth)	IC: 4511-2564N
Hands Free Unit	IC: 6505A-CL6
Hands Free Key	IC: 6505A-CL6904

DASHBOARD

Brasil

Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário. Para consultas, visite: www.anatel.gov.br .



DUCATI MULTIMEDIA SYSTEM (Bluetooth)

Brasil

Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário. Para consultas, visite: www.anatel.gov.br .



Japan

当該機器には電波法に基づく、技術基準適合証明等を受けた特定無線設備を装着している。

This equipment contains specified radio equipment that has been certified to the technical regulation conformity certification under the Radio Law.

本無線機器の改造を禁ずる (これに反した場合は当該認証登録番号は無効となる)

This radio device should not be modified (otherwise the granted designation number will become invalid)

South Korea

해당 무선설비는 전파혼신 가능성이 있으므로 인명안전과 관련된 서비스는 할 수 없습니다



HANDS FREE UNIT

Brasil

Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário. Para consultas, visite: www.anatel.gov.br .



South Korea

해당 무선설비는 전파혼신 가능성이 있으므로 인명안전과 관련된 서비스는 할 수 없습니다



HANDS FREE KEY

Brasil

Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário. Para consultas, visite: www.anatel.gov.br .



Japan

当該機器には電波法に基づく、技術基準適合証明等を受けた特定無線設備を装着している。

This equipment contains specified radio equipment that has been certified to the technical regulation conformity certification under the Radio Law.

本無線機器の改造を禁ずる (これに反した場合は当該認証登録番号は無効となる)

This radio device should not be modified (otherwise the granted designation number will become invalid) ID: 007-AF0150

South Korea

해당 무선설비는 전파혼신 가능성이 있으므로 인명안전과 관련된 서비스는 할 수 없습니다







Ducati Motor Holding spa

Via Cavalieri Ducati, 3 40132 Bologna, Italy Ph. +39 051 6413111 Fax +39 051 406580 A Sole Shareholder Company A Company subject to the Management and Coordination activities of AUDI AG